

## SERIAL NUMBERS

This manual applies directly to model 6060A Signal Generators with serial numbers 3650000 and up.

## NOTE

This manual documents the Model 6060A and its assemblies at the revision levels identified in Section 7A. If your instrument contains assemblies with different revision letters, it will be necessary for you to either update or backdate this manual. Refer to the supplemental change/errata sheet for newer assemblies, or to the backdating information in Section 7A for older assemblies.

# 6060A

*SYNTHESIZED RF SIGNAL GENERATOR*

## Instruction Manual

P/N 704841

January 1985

©1985 John Fluke Mfg. Co., Inc. All rights reserved. Litho in U.S.A.



# WARRANTY

Notwithstanding any provision of any agreement the following warranty is exclusive:

The JOHN FLUKE MFG. CO., INC., warrants each instrument it manufactures to be free from defects in material and workmanship under normal use and service for the period of 1-year from date of purchase. This warranty extends only to the original purchaser. This warranty shall not apply to fuses, disposable batteries (rechargeable type batteries are warranted for 90-days), or any product or parts which have been subject to misuse, neglect, accident, or abnormal conditions of operations.

In the event of failure of a product covered by this warranty, John Fluke Mfg. Co., Inc., will repair and calibrate an instrument returned to an authorized Service Facility within 1 year of the original purchase; provided the warrantor's examination discloses to its satisfaction that the product was defective. The warrantor may, at its option, replace the product in lieu of repair. With regard to any instrument returned within 1 year of the original purchase, said repairs or replacement will be made without charge. If the failure has been caused by misuse, neglect, accident, or abnormal conditions of operations, repairs will be billed at a nominal cost. In such case, an estimate will be submitted before work is started, if requested.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS, OR ADEQUACY FOR ANY PARTICULAR PURPOSE OR USE. JOHN FLUKE MFG. CO., INC., SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTRACT, TORT, OR OTHERWISE.

## **If any failure occurs, the following steps should be taken:**

1. Notify the JOHN FLUKE MFG. CO., INC., or nearest Service facility, giving full details of the difficulty, and include the model number, type number, and serial number. On receipt of this information, service data, or shipping instructions will be forwarded to you.
2. On receipt of the shipping instructions, forward the instrument, transportation prepaid. Repairs will be made at the Service Facility and the instrument returned, transportation prepaid.

## **SHIPPING TO MANUFACTURER FOR REPAIR OR ADJUSTMENT**

All shipments of JOHN FLUKE MFG. CO., INC., instruments should be made via United Parcel Service or "Best Way"® prepaid. The instrument should be shipped in the original packing carton; or if it is not available, use any suitable container that is rigid and of adequate size. If a substitute container is used, the instrument should be wrapped in paper and surrounded with at least four inches of excelsior or similar shock-absorbing material.

## **CLAIM FOR DAMAGE IN SHIPMENT TO ORIGINAL PURCHASER**

The instrument should be thoroughly inspected immediately upon original delivery to purchaser. All material in the container should be checked against the enclosed packing list. The manufacturer will not be responsible for shortages against the packing sheet unless notified immediately. If the instrument is damaged in any way, a claim should be filed with the carrier immediately. (To obtain a quotation to repair shipment damage, contact the nearest Fluke Technical Center.) Final claim and negotiations with the carrier must be completed by the customer.

The JOHN FLUKE MFG. CO., INC., will be happy to answer all applications or use questions, which will enhance your use of this instrument. Please address your requests or correspondence to: JOHN FLUKE MFG. CO., INC., P.O. BOX C9090, EVERETT, WASHINGTON 98206, ATTN: Sales Dept. For European Customers: Fluke (Holland) B.V., P.O. Box 5053, 5004 EB, Tilburg, The Netherlands.

\*For European customers, Air Freight prepaid.

**John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett, Washington 98206**

# Table of Contents

SECTION	TITLE	PAGE
<b>1</b>	<b>INTRODUCTION AND SPECIFICATIONS</b>	<b>1-1</b>
1-1.	INTRODUCTION	1-1
1-2.	UNPACKING THE GENERATOR	1-1
1-3.	SAFETY	1-1
1-4.	OPERATOR INFORMATION CARD	1-2
1-5.	GENERATOR DESCRIPTION	1-2
1-6.	Controller Functions	1-2
1-10.	Frequency	1-3
1-11.	Reference	1-3
1-12.	Amplitude	1-3
1-13.	Modulation	1-4
1-14.	OPTIONS AND ACCESSORIES	1-4
1-15.	RECOMMENDED TEST EQUIPMENT	1-4
1-16.	MNEMONICS	1-4
1-17.	SIGNAL GENERATOR SPECIFICATIONS	1-4
<b>2</b>	<b>INSTALLATION AND OPERATION</b>	<b>2-1</b>
2-1.	INTRODUCTION	2-1
2-2.	INITIAL INSPECTION	2-1
2-3.	SETTING UP THE GENERATOR	2-1
2-4.	Line Power Requirements	2-1
2-5.	Line Voltage and Fuse Selection	2-1
2-6.	IEEE-488 Address	2-2
2-7.	RACK OR BENCH MOUNTING THE GENERATOR	2-2
2-8.	GENERAL OPERATING INFORMATION	2-3
2-9.	Familiarization	2-3
2-10.	Local Versus Remote Operation	2-3
2-11.	Power-On Sequence	2-3
2-12.	Changing Output Parameters	2-3
2-13.	Function Entry	2-9
2-14.	Bright-Digit Edit Operation	2-11
2-15.	Step Operation	2-11
2-16.	Status and Clear Entries	2-12
2-17.	RF Output On/Off	2-12
2-18.	Modulation On/Off and Rate	2-12
2-19.	Memory	2-12
2-20.	Special Function	2-13

# TABLE OF CONTENTS, *continued*

SECTION	TITLE	PAGE
2-21.	OPERATING REFERENCE MATERIAL .....	2-13
2-22.	Amplitude and Frequency Entry .....	2-13
2-23.	Amplitude Fixed Range .....	2-16
2-24.	Amplitude Units Conversion .....	2-17
2-25.	Bright-Digit Edit Entry .....	2-17
2-26.	Memory Entry .....	2-19
2-27.	Modulation Entry .....	2-20
2-28.	Relative Function .....	2-22
2-29.	RF Output On/Off Entry .....	2-23
2-30.	Special Function Entry .....	2-24
2-31.	Status and Clear Entry .....	2-24
2-32.	Step Entry .....	2-26
2-33.	REMOTE OPERATION (IEEE-488 INTERFACE) .....	2-27
2-34.	Setting Up The IEEE-488 Interface .....	2-28
2-35.	Programming Commands .....	2-29
2-36.	Programming Examples .....	2-29
2-40.	Interface Functions .....	2-38
2-41.	Address Mode .....	2-38
2-46.	Talk-Only Mode .....	2-41
2-47.	Listen-Only Mode .....	2-42
2-48.	Command Syntax .....	2-42
2-52.	Command Descriptions .....	2-44
2-60.	Command Processing .....	2-60
2-63.	Timing Data .....	2-61
2-69.	Power-on Conditions .....	2-63
<b>3</b>	<b>THEORY OF OPERATION .....</b>	<b>3-1</b>
3-1.	INTRODUCTION .....	3-1
3-2.	GENERAL DESCRIPTION .....	3-1
3-3.	Front Section .....	3-1
3-4.	Module Section .....	3-1
3-5.	Rear Section .....	3-1
3-6.	FUNCTIONAL DESCRIPTION .....	3-2
3-7.	Level .....	3-2
3-8.	Amplitude Modulation .....	3-2
3-9.	Frequency .....	3-3
3-10.	Frequency Modulation .....	3-3
3-11.	SOFTWARE OPERATION .....	3-3
3-12.	User Interface .....	3-4
3-13.	Amplitude Control .....	3-4
3-14.	Attenuators .....	3-4
3-15.	Level DAC .....	3-4
3-16.	Temperature Compensation .....	3-5
3-17.	Reverse Power Protector Option .....	3-5
3-18.	Frequency Reference Control .....	3-5
3-19.	Frequency Control .....	3-5
3-20.	Modulation On/Off .....	3-5
3-21.	Modulation Frequency .....	3-5
3-22.	Amplitude Modulation .....	3-6
3-23.	Frequency Modulation .....	3-6
3-24.	FM Deviation .....	3-6
3-25.	Self Test .....	3-6
3-26.	Service Special Functions .....	3-7



SECTION	TITLE	PAGE
3-27.	Status Signals .....	3-7
3-28.	DETAILED CIRCUIT DESCRIPTIONS .....	3-8
3-29.	FRONT SECTION, A1 .....	3-8
3-30.	Display PCA, A1A1 .....	3-9
3-37.	Switch PCB, A1A2 .....	3-9
3-38.	MODULE SECTION, A2 .....	3-10
3-39.	Synthesizer PCA, A2A1 .....	3-10
3-50.	VCO PCA, A2A2 .....	3-18
3-51.	Output PCA, A2A4 .....	3-19
3-57.	Attenuator PCA, A2A6 .....	3-22
3-58.	Controller PCA, A2A7 .....	3-23
3-67.	REAR SECTION, A3 .....	3-24
3-68.	Power Supply PCA, A3A1 .....	3-25
<b>4</b>	<b>MAINTENANCE .....</b>	<b>4-1</b>
4-1.	INTRODUCTION .....	4-1
4-2.	SERVICE METHODS .....	4-1
4-3.	Fluke Service .....	4-1
4-4.	Module Replacement .....	4-1
4-5.	Parts Replacement .....	4-1
<b>4A</b>	<b>PERFORMANCE TESTS .....</b>	<b>4A-1</b>
4A-1.	INTRODUCTION .....	4A-1
4A-2.	TEST EQUIPMENT .....	4A-1
4A-3.	POWER-ON TEST .....	4A-3
4A-4.	SYNTHESIS TEST .....	4A-3
4A-5.	HIGH-LEVEL ACCURACY TEST .....	4A-4
4A-6.	MID-LEVEL ACCURACY TEST .....	4A-6
4A-7.	LOW-LEVEL TEST .....	4A-7
4A-8.	ALTERNATE-LEVEL ACCURACY TEST .....	4A-8
4A-9.	OUTPUT LEAKAGE TEST .....	4A-9
4A-10.	ALTERNATE OUTPUT LEAKAGE TEST .....	4A-10
4A-11.	HARMONIC AND SPURIOUS TEST .....	4A-11
4A-12.	MODULATION TESTS .....	4A-12
<b>4B</b>	<b>ACCESS PROCEDURES .....</b>	<b>4B-1</b>
4B-1.	INTRODUCTION .....	4B-1
4B-2.	LOCATION OF MAJOR ASSEMBLIES .....	4B-1
4B-3.	ACCESS INSTRUCTIONS .....	4B-1
4B-4.	Removing the Front Section Assembly, A1 .....	4B-1
4B-5.	Removing the Rear Section Assembly, A3 .....	4B-2
4B-6.	Removing the Synthesizer Board, A2A1 .....	4B-2
4B-7.	Removing the Output Board, A2A4 .....	4B-2
4B-8.	Removing the Attenuator A2A6, or Attenuator/RPP A2A5 Assembly .....	4B-2
4B-9.	Removing the VCO Board, A2A1 .....	4B-3
<b>4C</b>	<b>CALIBRATION ADJUSTMENTS .....</b>	<b>4C-1</b>
4C-1.	INTRODUCTION .....	4C-1
4C-2.	SAFETY .....	4C-1
4C-3.	POWER SUPPLY, A3A1, ADJUSTMENT .....	4C-1

## TABLE OF CONTENTS, *continued*

SECTION	TITLE	PAGE
4C-4.	DISPLAY ASSEMBLY, A1A1, ADJUSTMENT PROCEDURE ...	4C-2
4C-5.	OUTPUT ASSEMBLY, A2A4, ADJUSTMENT .....	4C-4
4C-6.	SYNTHESIZER ASSEMBLY, A2A1 ADJUSTMENT .....	4C-10
<b>4D</b>	<b>TROUBLESHOOTING AND REPAIR .....</b>	<b>4D-1</b>
4D-1.	INTRODUCTION .....	4D-1
4D-2.	MODULE REPLACEMENT .....	4D-1
4D-3.	Power Supply PCA, A3A1 .....	4D-2
4D-4.	Sub-Harmonic Reference PCA, A2A3 .....	4D-2
4D-5.	Synthesizer PCA, A2A1 .....	4D-2
4D-6.	VCO PCA, A2A2 .....	4D-3
4D-7.	Output PCA, A2A4 .....	4D-3
4D-8.	Controller PCA, A2A7 .....	4D-3
4D-9.	Display PCA, A1A1 .....	4D-3
4D-10.	Attenuator (Attenuator/RPP) PCA, A2A6 (A2A5) .....	4D-3
4D-11.	IEEE-488 PCA, A3A3 .....	4D-3
4D-12.	Non-Volatile Memory PCA, A2A8 .....	4D-3
4D-13.	PARTS REPLACEMENT .....	4D-4
4D-14.	TROUBLESHOOTING .....	4D-4
4D-15.	Service Special Functions .....	4D-4
4D-16.	UNCAL Conditions .....	4D-5
4D-17.	Self Test Description .....	4D-5
4D-22.	Check Output Signal .....	4D-8
4D-23.	Auxiliary Power Supply, PCA, A3A2 .....	4D-8
4D-24.	Check Power Supply Voltages .....	4D-9
4D-25.	DIGITAL AND CONTROL TROUBLESHOOTING .....	4D-10
4D-26.	Control Activity .....	4D-10
4D-27.	Latch Control .....	4D-11
4D-28.	Microprocessor Kernel .....	4D-11
4D-29.	Power Reset .....	4D-11
4D-30.	Microprocessor Inputs .....	4D-11
4D-31.	IEEE-488 Interrupt .....	4D-11
4D-32.	Microprocessor Bus .....	4D-11
4D-33.	Address Decoder .....	4D-11
4D-34.	Display and Controls .....	4D-12
4D-35.	SYNTHESIZER TROUBLESHOOTING .....	4D-13
4D-36.	Reference Circuitry Check .....	4D-13
4D-37.	Main Phase Lock Loop .....	4D-13
4D-38.	Sub-Synthesizer and HET (800 MHz), 40-MHz Loop .....	4D-16
4D-39.	FM Circuitry .....	4D-16
4D-40.	LEVEL TROUBLESHOOTING .....	4D-17
4D-41.	Output Assembly Test Point Signal Information .....	4D-17
4D-42.	ATTENUATOR LEVEL CONTROL .....	4D-17
4D-43.	Attenuator Check .....	4D-17
4D-44.	Unleveled Condition .....	4D-19
4D-45.	AM TROUBLESHOOTING .....	4D-20
4D-46.	Internal/External AM .....	4D-20
4D-47.	ALC Loop Control Voltage .....	4D-21
4D-48.	Detector Linearity .....	4D-21
<b>5</b>	<b>LIST OF REPLACEABLE PARTS .....</b>	<b>5-1</b>
	TABLE OF CONTENTS .....	5-1

SECTION	TITLE	PAGE
5-1.	INTRODUCTION .....	5-2
5-2.	Parts List Information .....	5-2
5-3.	HOW TO OBTAIN PARTS .....	5-2
5-4.	Recommended Spare Parts Kit .....	5-3
<b>6</b>	<b>OPTIONS .....</b>	<b>6-1</b>
	TABLE OF CONTENTS .....	6-1
<b>7</b>	<b>GENERAL INFORMATION .....</b>	<b>7-1</b>
7-1.	FEDERAL SUPPLY CODES FOR MANUFACTURERS .....	7-2
7-2.	U.S. SALES AREAS FOR ALL FLUKE PRODUCTS .....	7-3
7-3.	INTERNATIONAL SALES OFFICES .....	7-5
7-4.	TECHNICAL SERVICE CENTERS .....	7-6
<b>7A</b>	<b>MANUAL CHANGE INFORMATION .....</b>	<b>7A-1</b>
<b>8</b>	<b>SCHEMATIC DIAGRAMS .....</b>	<b>8-1</b>
	TABLE OF CONTENTS .....	8-1



# List of Tables


TABLE	TITLE	PAGE
1-1.	Signal Generator Specifications .....	1-5
2-1.	Front Panel Controls, Indicators, and Connectors .....	2-5
2-2.	Rear Panel Controls, Connectors, and Switches .....	2-10
2-3.	Instrument Preset State .....	2-11
2-4.	Special Functions .....	2-14
2-5.	UNCAL Error Codes .....	2-25
2-6.	REJect ENTRY Codes .....	2-25
2-7.	Index of IEEE-488 Commands .....	2-29
2-8.	IEEE-488 Commands .....	2-30
2-9.	IEEE-488 Interface Functions List .....	2-38
2-10.	IEEE-488 Address Mode Message Descriptions .....	2-39
2-11.	Suffix Types .....	2-45
2-12.	Learn Character to Hexadecimal Conversion .....	2-53
2-13.	Interface Mode Commands .....	2-54
2-14.	Self-Test Error Codes .....	2-56
2-15.	Input/Output Monitor Commands .....	2-58
2-16.	Read/Write Monitor Commands .....	2-59
2-17.	Hardware Control Monitor Commands .....	2-59
2-18.	SRQ Mask and Status Values .....	2-60
2-19.	Command-Parsing Time .....	2-62
2-20.	Typical Programming Time of the Generator Functions .....	2-62
2-21.	IEEE-488 Power-On State .....	2-63
3-1.	Power Supply Rectifier Configurations .....	3-25
4A-1.	Recommended Test Equipment .....	4A-2
4A-2.	Modulation Tests Requirements .....	4A-12
4A-3.	AM Test Conditions .....	4A-15
4A-4.	AM Depth Range .....	4A-15
4D-1.	Module Exchange Assemblies .....	4D-2
4D-2.	Self Test Display Field .....	4D-6
4D-3.	AAA Field AM and FM Tests .....	4D-6
4D-4.	BBB Field Test Results .....	4D-7
4D-5.	CCC Field Test Results .....	4D-7
4D-6.	DDD Field Test Results .....	4D-8
4D-7.	Band, Filter, and Frequency Programming Data .....	4D-8
4D-8.	Power Supply Characteristics .....	4D-10
4D-9.	Address Codes for the Front Panel Keys .....	4D-12
4D-10.	Synthesizer PCA Test Points .....	4D-14
4D-11.	Frequency Reference Control .....	4D-15
4D-12.	FM Ranges .....	4D-17

**LIST OF TABLES, *continued***

<b>TABLE</b>	<b>TITLE</b>	<b>PAGE</b>
4D-13.	FM DAC Control .....	4D-17
4D-14.	Output PCA Test Points .....	4D-18
4D-15.	Attenuator Levels Control .....	4D-19
4D-16.	Attenuator Levels .....	4D-19
4D-17.	Modulation On/Off Control .....	4D-20
4D-18.	Modulation Frequency Control .....	4D-20

## List of Illustrations

FIGURE	TITLE	PAGE
Frontispiece	6060A Signal Generator .....	x
2-1.	Fuse/Filter/Line Voltage Selection Assembly .....	2-2
2-2.	6060A Outside Dimensions .....	2-4
2-3.	Front Panel Controls, Indicators, and Connectors .....	2-5
2-4.	Rear Panel Controls, Connectors, and Switches .....	2-10
2-5.	6060A Signal Generator Connected to a I722A .....	2-28
2-6.	6060A IEEE-488 Bus Connected to a 6060A IEEE-488 Bus .....	2-42
2-7.	Learn String Example .....	2-47
3-1.	Triple-Modulus Prescaler Operation .....	3-12
3-2.	N-Divider Operation .....	3-13
3-3.	N-Divider Timing Diagram .....	3-15
4A-1.	Two-Turn Loop .....	4A-2
4A-2.	High-Level Accuracy Test Conditions .....	4A-5
4A-3.	High-Level Accuracy Test Conditions .....	4A-7
4C-1.	Power Supply Test Points .....	4C-3
4C-2.	Module Plate, Bottom View .....	4C-5
4C-3.	Module Plate, Top View .....	4C-12



6060A Synthesized Signal Generator



# Section 1

## Introduction and Specifications

### 1-1. INTRODUCTION

The 6060A Synthesized Signal Generator (referred to as the Generator or instrument) is a fully-programmable, precision, synthesized signal generator. The Generator is designed for applications that require good modulation, frequency accuracy, and output level performance with moderate spectral purity. It is well suited for testing a wide variety of RF components and systems including filters, amplifiers, mixers, and radios, particularly on-channel radio testing.

### 1-2. UNPACKING THE GENERATOR

This shipping container should include a 6060A Signal Generator, an Operator Information Card, a Getting Started Manual, an Instruction Manual, a line power cord, and a BNC dust cap (for the 10 MHz IN/OUT connector). Any accessories ordered for the Generator are shipped in a separate container.

Section 2, Installation and Operation, gives instructions on inspecting your new Generator, and what to do if the instrument arrives with shipping damage. Reshipment information is also included.

### 1-3. SAFETY

This instruction manual contains information, warnings, and cautions that should be followed to ensure safe operation and to maintain the Generator in a safe condition.

The Generator is designed primarily for indoor use, and it may be operated in temperatures from 0°C to and 50°C without degradation of its safety.

#### WARNING

**TO AVOID ELECTRIC SHOCK, USE A POWER CORD THAT HAS A THREE-PRONG PLUG. IF YOU DO NOT USE A PROPER POWER CORD, THE 6060A CASE CAN DEVELOP AN ELECTRICAL POTENTIAL ABOVE EARTH GROUND.**

#### CAUTION

**To avoid damage to the 6060A, check that the rear panel line voltage selection card and fuse are correct for the line voltage in your area. The correct line voltage and fuse combinations are:**

LINE VOLTAGE	FUSE
100/120V ac, $\pm 10\%$ , 47 Hz to 63 Hz	1.5 AMP
220/240V ac, $\pm 10\%$ , 47 Hz to 63 Hz	.75 AMP

### CAUTION

**If your Generator does not have Option -870 Reverse Power Protection, do not allow an input over 1/8 watt of sustained power to the RF OUTPUT. Such input could damage the Generator.**

#### 1-4. OPERATOR INFORMATION CARD

The Operator Information Card has an adhesive backing so it may be affixed to the top of the Generator in bench applications or to the operator console in remote applications. A copy of the card is located at the end of Section 8 of this manual as a convenient reference or for duplication.

#### 1-5. GENERATOR DESCRIPTION

Fundamental features of the Generator are as follows:

0.1-MHz to 1050-MHz frequency range in 10-Hz steps

+13-dB to -137-dBm level range in 0.1-dB steps

AM and FM, internal or external

Internal 400-Hz and 1000-Hz modulation oscillator

Relative frequency and amplitude

Volts/dBm conversion

Store/recall memory

Master/slave for frequency, amplitude, and modulation step (IEEE-488 Interface controlled.)

Fluorescent display

5 1/4-inches high, rack mountable

#### 1-6. Controller Functions

The Controller microprocessor controls all operator interface functions, performs background operations such as status checks, and updates (strokes) the front panel displays. Whether you are using local control with the front panel, or remote control with the IEEE-488 Interface option, the microprocessor provides self test and diagnostic capability. Economical instrument performance is achieved by using software compensation EPROMs and accuracy-enhancement circuitry.

#### 1-7. LOCAL CONTROL

The value of the basic output parameters of the Generator, i.e., amplitude, frequency, or modulation can be controlled in three ways:

Direct numeric entry

Incrementing or decrementing the bright digit

Step-up or step-down entry where the step size can be operator programmed

Other controls provide selection of the POWER ON/OFF, RF OUTPUT ON/OFF, MODULATION ON/OFF, internal/external frequency reference, and STATUS.

**1-8. DISPLAY FIELD**

The programmed values of modulation, frequency, and amplitude are displayed in the three display fields.

**1-9. REMOTE-CONTROL PROGRAMMING**

The Option -488 IEEE-488 Interface allows the Generator to be remotely controlled with any IEEE-488 bus controller. The instrument can also be used on the IEEE-488 bus without a controller in a listen-only or talk-only mode by selecting the appropriate Generator rear panel IEEE-488 switch settings.

All instrument controls can be remotely controlled except the POWER ON/OFF and the rear panel REF INT/EXT switches. The Option -488 IEEE-488 Interface provides additional commands not available with local control, such as data transfer and individual control of internal I/O control bits.

The Option -488 IEEE-488 Interface allows two Generators to track amplitude, frequency, or modulation in a master/slave configuration when using the front panel step-up and step-down entries on one of the instruments. For instance, frequency tracking is convenient for tests involving mixers, and amplitude tracking is useful for two-tone intermodulation testing.

**1-10. Frequency**

The specified frequency range is 0.1 to 1050 MHz. The frequency is synthesized from a 10-MHz reference and provides an output resolution of 10 Hz over the entire frequency range. The relative frequency mode allows the frequency to be programmed in relation to a center frequency or an offset frequency. This is convenient for testing filters and mixers. The output frequency stability and accuracy depends on the reference, whether that reference is internal or external.

**1-11. Reference**

The internal frequency reference is either a 10-MHz ambient crystal oscillator, or the Option -130 High Stability Reference. With the rear panel REF INT/EXT switch set to INT, the Generator output frequency is synthesized from the internal 10-MHz crystal oscillator reference, and the internal oscillator (timebase) TTL signal is available at the 10 MHz IN/OUT connector.

The Generator can be operated from an external 10-MHz timebase by setting the rear panel REF INT/EXT switch to EXT and applying a TTL timebase signal to the 10 MHz IN/OUT connector.

With the Option -131 Sub-Harmonic Reference installed and the REF INT/EXT switch set to EXT, the Generator can be operated from an external 1-, 2-, 2.5-, 5-, or 10-MHz, 0.3V to 4V peak-to-peak sine or square-wave reference applied to the REF IN connector. In either position of the INT/EXT switch, the selected reference is available as a 10-MHz TTL signal at the rear panel 10 MHz OUT connector.

**1-12. Amplitude**

The Generator has a specified signal level range from +13 to -137 dBm with programming limits of +19 and -147.4 dBm. This corresponds to specified terminated voltages of 1V to 0.03  $\mu$ V and limits of 2V to 0.01  $\mu$ V, respectively. The maximum usable signal level is approximately +17 dBm. The level entry can be in dBm or volts, or it can be converted from one to the other. In addition, the relative amplitude mode allows you to account for cascaded gain or loss, or to display the level (in dB) relative to 1  $\mu$ V or 1 mV.

1-13. Modulation

Both internal and external amplitude modulation and frequency modulation capability is available. The internal modulation oscillator is selectable between 400 Hz and 1000 Hz. AM depths of 0% to 99% are available in 1% steps. FM deviation ranges of 1 kHz, 10 kHz, and 100 kHz are available in steps of 1 Hz, 10 Hz, and 100 Hz, respectively.

1-14. OPTIONS AND ACCESSORIES

The following options are available for the Generator:

- Option -130 High-Stability (Ovened) Reference
- Option -131 Sub-Harmonic Reference (1-, 2-, 2.5-, 5-, and 10-MHz)
- Option -488 IEEE Interface
- Option -570 Non-Volatile (Store/Recall) Memory ( 50 locations)
- Option -651 Low-Rate FM (External only)
- Option -830 Rear RF OUT and MOD IN Connectors
- Option -870 Reverse Power Protection (50W protection)

Section 6 provides more detailed information on the options.

The following accessories are included with each Generator:

The following accessories are available for the Generator:

DESCRIPTION	ACCESSORY NO.
Rack Mount Kit. Includes M05-205-600 (5 1/4-inch Rack Mount Ears) and M00-280-610 (24-inch Rack Slides)	Y6001
IEEE-488 Shielded Cable, 1 meter	Y8021
IEEE-488 Shielded Cable, 2 meters	Y8022
IEEE-488 Shielded Cable, 4 meters	Y8023
Coaxial Cable, 50 ohms, 3 feet, BNC (m) both ends	Y9111
Coaxial Cable, 50 ohms, 6 feet, BNC (m) both ends	Y9112

1-15. RECOMMENDED TEST EQUIPMENT

The test equipment recommended for the performance tests, calibration adjustments, and troubleshooting are listed in Table 4A-1. This equipment is assumed to be calibrated to the manufacturer's specifications. If the recommended test equipment is not available, equivalent test equipment can be substituted.

1-16. MNEMONICS

The mnemonics used on the schematics, block diagrams, wiring diagrams, truth tables, and in the text, are listed in Figure 8-1.

1-17. SIGNAL GENERATOR SPECIFICATIONS

Unless otherwise noted, the following performance is guaranteed over the specified environmental and ac power line conditions 20 minutes after turn-on. Table 1-1 lists the Generator specifications.

Table 1-1. Signal Generator Specifications

Warranted performance, 20 minutes after turn-on within operating temperature range.

FREQUENCY (8 1/2-Digit Display)

RANGE .....	0.1 MHz to 1050.0 MHz in 3 bands; 0.1 MHz to 244.99999 MHz, 245 MHz to 511.99999 MHz, 512 MHz to 1050 MHz.
RESOLUTION .....	10 Hz.
ACCURACY .....	Same as reference (See REFERENCE).
REFERENCE (Internal) .....	The unit operates on an internal free-air 10-MHz crystal oscillator, < +0.5ppm/month and < $\pm 5$ ppm for 25°C, $\pm 25^\circ\text{C}$ . Internal reference signal (10-MHz TTL) available at rear connector.
REFERENCE (External) .....	Accepts 10-MHz TTL signal.

AMPLITUDE (3 1/2-Digit Display)

RANGE (Indicated) .....	+13 (+13 peak on AM) to -137 dBm; (Autoranging 6-dB step attenuator).
RESOLUTION .....	0.1 dB (< 1% or 1 nV in volts).
ACCURACY .....	$\pm 1.5$ dB at and above 0.4 MHz; below 0.4 MHz $\pm 2$ dB at or above -100 dBm and $\pm 3$ dB below -100 dBm.
SOURCE SWR .....	< 1.5 below 1 dBm and at or above 0.4 MHz; < 2.0 elsewhere.

SPECTRAL PURITY (CW ONLY)

SPURIOUS .....	< -60 dBc for offsets greater than 10 kHz. Fixed frequency spurs are < -60 dBc or < -140 dBm whichever is larger.
----------------	---

NOTE

dBc refers to decibels relative to the  
carrier frequency, or in this case,  
relative to the signal level.

HARMONICS .....	< -30 dBc.
RESIDUAL FM (rms in 0.3-kHz to 3-kHz Band) .....	< 13 Hz for 245 MHz to 512 MHz; < 27 Hz elsewhere.
RESIDUAL FM (rms in 0.05-kHz to 15-kHz Band) .....	< 30 Hz for 245 MHz to 512 MHz; < 60 Hz elsewhere.

## INTRODUCTION AND SPECIFICATIONS

**Table 1-1. Signal Generator Specifications (cont)**

RESIDUAL AM (in 0.05-kHz to 15-kHz Band) .....	< -60 dBc.
<b>AMPLITUDE MODULATION (2-Digit Display)</b>	
DEPTH RANGE .....	0% to 99%.
RESOLUTION .....	1%.
ACCURACY .....	$\pm(2\% + 4\%$ of setting) for internal rates, for depths 90% or less and peak amplitude of +13 dBm or less.
DISTORTION .....	< 1.5% total harmonic distortion (THD) to 30% AM, < 3% to 70% AM, < 5% to 90% AM at internal rates.
BANDWIDTH (3dB) .....	20 Hz to 30 kHz.
INCIDENTAL FM .....	< $0.3f_m$ for internal rates and 30% AM.
<b>FREQUENCY MODULATION (3-Digit Display)</b>	
DEVIATION RANGES .....	100 Hz to 999 Hz, 1 kHz to 9.99 kHz, and 10 kHz to 99.9 kHz.
MAXIMUM DEVIATION .....	Lesser of 99.9 kHz and $2f_m$ above 245 MHz, or $2f_m (f_o + 800)$ below 245 MHz, where $f_m$ is in MHz; $(f_o - 100)/3$ kHz, below 0.4 MHz ( $f_o$ in kHz).
RESOLUTION .....	3 digits.
ACCURACY .....	$\pm 7\%$ for rates of 0.3 kHz to 20 kHz (0.3 to 1 kHz for $f_o < 0.4$ MHz) and > 100-Hz deviation.
DISTORTION .....	< 1% THD for rates of 0.3 kHz to 20 kHz (0.3 to 1 kHz for $f_o < 0.4$ MHz) and > 100-Hz deviation.
BANDWIDTH (3dB) .....	0.02 kHz to 100 kHz; unspecified for $f_o < 0.4$ MHz.
INCIDENTAL AM .....	< 1% AM at 1-kHz rate, for the maximum deviation or 50 kHz, whichever is less.
<b>MODULATION SOURCE</b>	
INTERNAL .....	0.4 kHz or 1 kHz, $\pm 3\%$ for 20°C to 30°C; add $\pm 0.1\%/^{\circ}\text{C}$ outside this range.
EXTERNAL .....	$\pm 5\text{V}$ max.; 1V peak provides indicated modulation index. Nominal input impedance is 600 ohms.

Table 1-1. Signal Generator Specifications (cont)

MODES .....	Any combination of internal AM, internal FM, external AM, and external FM. Modulation may also be disabled. The nominal input impedance with both external AM and external FM enabled is 560 ohms.		
GENERAL			
TEMPERATURE			
Operating .....	0°C to 50°C (32°F to 122°F).		
Non-Operating .....	-40°C to 75°C (-40°F to 167°F).		
HUMIDITY RANGE			
Operating .....	95% to 30°C, 75% to 40°C, 45% to 50°C.		
ALTITUDE			
Operating .....	Up to 10,000 ft.		
VIBRATION			
Non-Operating .....	5 Hz to 15 Hz at 0.06 inch, 15 Hz to 25 Hz at 0.04 inch, and 25 Hz to 55 Hz at 0.02 inch, double amplitude (DA).		
SHOCK			
Non-Operating .....	Bench handling per MIL T 28800C Class 5, Style E.		
ELECTROMAGNETIC COMPATIBILITY .....			
	The radiated emissions induce < 3 uV (< 1 uV of the Generator's output signal) into a 1-inch diameter, 2-turn loop, 1-inch from any surface as measured into a 50-ohm receiver.		
Also complies with the following standards:			
CEO3 of MIL-STD-461B (Power and interconnecting leads), 0.015 MHz to 50 MHz.			
REQ2 of MIL-STD-461B (14 kHz to 10 GHz).			
FCC Part 15 (j), class A.			
CISPR 11.			
SIZE .....	Width	Height	Depth
	43 cm	13.3 cm	50.8 cm
	17 in	5.25 in	20 in
POWER .....	100, 120, 220, 240V ac $\pm 10\%$ , 47 to 63 Hz, < 180 VA (< 15 VA, with Option -130 installed, and the Generator turned off (standby)).		
WEIGHT .....	< 15.7 kg (35 lbs).		

## INTRODUCTION AND SPECIFICATIONS

Table 1-1. Signal Generator Specifications (cont)

### 6060A OPTION -130 HIGH STABILITY REFERENCE

AGING RATE .....  $< \pm 5 \times 10^{-10}/\text{day}$ , after 21 days.

TEMPERATURE STABILITY .....  $< \pm 2 \times 10^{-10}/^{\circ}\text{C}$  (Oven remains powered in standby).

### 6060A OPTION -131 SUB-HARMONIC REFERENCE

INPUT ..... 1, 2, 2.5, 5, or 10 MHz at 0.3 to 4V p-p, sine wave or square wave, into 50-ohm nominal impedance.

### 6060A OPTION -488 IEEE INTERFACE (IEEE-488-1978 STD)

INTERFACE FUNCTIONS ..... SH1, AH1, T5, TE0, L3, LE0, SR1, RL1, PPO, DC1, DT1, CO, and E2.

### 6060A OPTION -570 NON-VOLATILE MEMORY

50 instrument states are retained for 2 years (typically), even without ac line power applied.

### 6060A OPTION -870 REVERSE POWER PROTECTION

PROTECTION LEVEL ..... Up to 50 watts from a 50-ohm source, 0.1 MHz to 1050 MHz. Withstands up to 50V dc. Protection is not provided when the Generator is off.

### 6060A OPTION -651 LOW RATE EXTERNAL FM

MAXIMUM DEVIATION ..... 9.99 kHz.

DROOP .....  $< 15\%$  on a 10-Hz square wave.

BANDWIDTH (3dB) ..... 0.5 Hz to 100 kHz (typical).

MAX DC INPUT .....  $\pm 10$  mV.

INCIDENTAL AM .....  $< 1\%$  AM at 1-kHz rate and deviation  $< 10$  kHz.

### SUPPLEMENTAL CHARACTERISTICS

The following characteristics are provided to assist in the application of the Generator and to describe the typical performance that can be expected.

FREQUENCY SWITCHING SPEED .....  $< 100$  ms to be within 100 Hz.

AMPLITUDE SWITCHING SPEED .....  $< 100$  ms to be within 0.1 dB.

AMPLITUDE RANGE ..... Programmable to +19 dBm and -147.4 dBm, usable to +17 dBm. Fixed-range, selected by special function, allows for more than 12 dB of vernier without switching the attenuator.



Table 1-1. Signal Generator Specifications (cont)

NOISE (at 20-kHz offset) .....	<-113 dBc/Hz (except <-107 dBc/Hz below 245 MHz and above 512 MHz).
RESIDUAL FM (rms in 0.3 to 3 kHz)	Approximately a linear function of output frequency between the following typical band-edge values:  15 Hz at 0.1 MHz to 20 Hz at 244.99999 MHz.  6 Hz at 245 MHz to 10 Hz at 511.99999 MHz.  12 Hz at 512 MHz to 20 Hz at 1050 MHz.
EXTERNAL MODULATION .....	Annunciators indicate when a 1V peak signal is applied, $\pm 2\%$ , over a 0.02-kHz to 100-kHz band.
IEEE-488 .....	All controls except the power switch and the internal/external reference switch are remotely programmable via IEEE-488 Interface (Std 488-1978). All status including the option complement are available remotely. The Store/Recall memory data may be transferred via an external controller. In talk-only, the appropriate commands are generated when the front panel step-up and step-down entries are made to control another 6060A, 6070A, or 6071A. (6070/71A only have FREQUENCY STEP.)



## **Section 2**

# **Installation and Operation**

### **2-1. INTRODUCTION**

This section describes how to install and operate the Generator. This section contains information for an initial inspection, setting up the instrument, and local and remote operation.

### **2-2. INITIAL INSPECTION**

The Generator is shipped in a special protective container that should prevent damage during shipment. Check the shipping order against the contents of the container, and report any damage or short shipment to the place of purchase or the nearest Fluke Technical Service Center. Instructions for inspection and claims are included on the shipping container.

If reshipment of the Generator is necessary, please use the original shipping container. If the original container is not available, use a container that provides adequate protection during shipment. It is recommended that the Generator be surrounded by at least three inches of shock-absorbing material on all sides of the container. Do not use loose fill to pad the shipping container. Loose fill allows the Generator to settle to one corner of the shipping container, which could result in the Generator being damaged during shipment.

### **2-3. SETTING UP THE GENERATOR**

The following paragraphs describe how to set up the Generator for operation. This information includes: line power requirements, line voltage selection procedures, fuse replacement procedures, and rack mounting instructions.

### **2-4. Line Power Requirements**

The Generator uses a line voltage of 100 or 120V ac rms ( $\pm 10\%$ ) with a 1.5A fuse; or 220V or 240V ac ( $\pm 10\%$ ) with a 0.75A fuse. The line frequency must be between 48 to 63 Hz. The power consumption of the instrument is  $<180$  VA with a full option complement.

### **2-5. Line Voltage and Fuse Selection**

#### **CAUTION**

**Verify that the intended line power source matches the line voltage setting of your Generator before plugging in the line power cord.**

Refer to Figure 2-1 to set the line voltage of the Generator to match your available source. Figure 2-1 also shows how to replace the line fuse of the Generator. The correct fuse value for each of the four line voltages is listed on a plate attached to the rear panel of the Generator.




Figure 2-1. Fuse/Filter/Line Voltage Selection Assembly

### 2-6. IEEE-488 Address

If the IEEE-488 Interface option is installed, the IEEE-488 address can be selected using the switches located next to the IEEE-488 connector on the rear panel. Talk-only and listen-only modes can also be selected on this switch.

### 2-7. RACK OR BENCH MOUNTING THE GENERATOR

#### CAUTION

**Allow at least 3 inches of clearance behind and on each side of the Generator to ensure proper air circulation. Clean the fan filter regularly. Determine the cleaning interval by the type of environment.**

**To meet the specified radiated emissions, the IEEE-488 connector must be terminated with a shielded IEEE-488 cable, such as a Fluke Y8021.**

The Generator normally operates on an internal reference oscillator. However, if desired, the Generator can be operated on an external reference by setting the rear panel REF INT/EXT switch to EXT and connecting the external reference to the 10 MHz IN/OUT connector. Use the REF IN connector if the Generator has the Sub-Harmonic Reference option.

#### CAUTION

**When operating on the internal reference, a 10-MHz TTL signal is present at the 10 MHz IN/OUT connector on the rear panel. To meet the specified radiated emissions, this connector must be terminated with a BNC non-shorting dust cap. A dust cap, JF 478982, is supplied with the Generator. If a cable is connected, it must be a double-shielded coaxial cable such as RG-223 terminated in a TTL load.**

#### CAUTION

**Output spectral degradation occurs if the Generator is operated on internal reference with an external reference signal applied.**

The Generator may be placed directly on a work bench or mounted in a standard (24-inch deep) equipment rack. Use the Fluke Y6001 Rack Mount Kit for mounting the Generator

on an equipment rack. Instructions for installing the Generator with the Rack Mount Kit are provided in the kit. The outside dimensions of the Generator are shown in Figure 2-2. The Rack Mount Kit is composed of the following parts:

- 5-1/4-inch Rack Adapter, P/N M05-205-600
- 24-inch Rack Slides, P/N M00-280-610

## 2-8. GENERAL OPERATING INFORMATION

The following paragraphs contain general information on the operation of the Generator. This includes all the information required to familiarize the you with the instrument and the differences between local and remote operation.

### 2-9. Familiarization

Figure 2-3 shows the front panel controls, indicator, and connectors and Table 2-1 describes the features.

Figure 2-4 shows the rear panel controls, connectors, and switches and Table 2-2 describes the features.

### 2-10. Local Verses Remote Operation

There are two modes of controlling the output of the Generator. One mode uses the keys on the front panel; this is called local operation. The other mode is available when the IEEE-488 Interface option has been installed, and an IEEE-488 controller is used to control the Generator. This is referred to as remote operation. An overview of local control is presented first. The next heading, Operating Reference Material, is divided into two parts. The first part covers local and remote control operations that have similar entry methods. The second part, Remote Operation, contains information on commands or descriptions that pertain only to remote operations.

### 2-11. Power-On Sequence

When the Generator is turned on, a power-on sequence is started. During the power-on sequence, the microprocessor tests the analog circuitry, the program ROM, the scratch-pad RAM, and the front panel displays. The front panel displays are tested by lighting all segments for a brief period at the same time the rest of the self tests are performed.

If any of the self tests fail, an error code is displayed. If the operator initiates any front panel entry before the power-on sequence is completed, the self test is aborted, and the Generator is placed in the Instrument Preset State [RCL] [9][8]. In addition, the RF output is turned on. Table 2-3 lists the Instrument Preset State. If the Non-Volatile Memory Option is installed, the Generator is set to the state it was in when turned off. Power-on instrument settings that relate to the optional IEEE-488 Interface are described in the Remote Operation paragraphs in this section.

### 2-12. Changing Output Parameters

The four parameters of the Generator (i.e., frequency, amplitude, amplitude modulation (AM), and frequency modulation (FM)) may be changed by one of three methods:

- FUNCTION-DATA-UNIT
- Bright-Digit Edit
- Step Entry

These different methods all accomplish the same result but use different approaches. The reason for this apparent redundancy is to reduce the chance of error during complex test procedures that require continuously resetting parameters or in those cases when a test is partly under remote control and only some of the parameters require changes.

2-4






Figure 2-3. Front Panel Controls, Indicators, and Connectors

Table 2-1. Front Panel Controls, Indicators, and Connectors


①	<b>MODULATION DISPLAY FIELD</b>	A three-digit display, with associated indicators used to display the AM depth, FM deviation, source of modulation signal, and modulation frequency.
	INT AM	Indicates that the internal modulation oscillator signal is amplitude modulating the Generator.
	EXT AM	Indicates that the Generator is amplitude modulated by the signal connected to the MOD INPUT connector.
	INT FM	Indicates that the internal modulation oscillator signal is frequency modulating the Generator.
	EXT FM	Indicates that the Generator is frequency modulated by the signal connected to the MOD INPUT connector.
	STEP	Indicates that the Step [↑] or [↓] keys (Step Entry) affect the current Modulation display value.
	%	Indicates that the value displayed is the AM Depth in percent.
	kHz DEV	Indicates that the value displayed is the FM Deviation in kHz.
	400 Hz	Indicates that the internal modulating frequency is 400 Hz.
	1000 Hz	Indicates that the internal modulating frequency is 1000 Hz.
	EXT HI	Indicates that the external modulation signal is more than 2% above the nominal 1V peak requirement for calibrated operation.
	EXT LO	Indicates that the external modulation signal is more than 2% below the nominal 1V peak input requirement.

**Table 2-1. Front Panel Controls, Indicators, and Connectors (cont)**


②	FREQUENCY DISPLAY FIELD	An 8 1/2-digit display, with two indicators used to display the output frequency of the Generator. Also used to display the special function code, status error codes, or the memory location being stored or recalled, as well as relative and actual frequency, when 'REL' is lit, and step frequency.
	STEP	Indicates that the Step [ $\uparrow$ ] or [ $\downarrow$ ] keys (Step Entry) affect the output frequency.
	REL	Indicates that the displayed frequency is relative to a reference frequency.
③	AMPLITUDE DISPLAY FIELD	A 3 1/2- (and sign) digit display, with six indicators, used to display the output amplitude of the Generator into a 50-ohm load.
	STEP	Indicates that the Step [ $\uparrow$ ] or [ $\downarrow$ ] keys (Step Entry) affect the output amplitude.
	REL	Indicates that the displayed amplitude is relative to a reference amplitude.
	dBm	Indicates that the output amplitude is in decibels relative to one milliwatt.
	V	Indicates that the output amplitude is in volts.
	$\mu$ V	Indicates that the output amplitude is in microvolts.
④	mV	Indicates that the output amplitude is in millivolts.
	STATUS DISPLAY FIELD	The status display field is composed of 11 indicators used to denote the current status of the Generator or instrument entry.
	EXT REF	Indicates that the rear panel REF switch is in the EXT (external) position.
	REJ ENTRY	Lights when an invalid entry is made.
	UNCAL	Lights when a parameter entry is outside its specified range. This indicator flashes when any of the internal DAC's are over or under-flow or when any abnormal operation is detected.
	RF OFF	Lights when the RF OUTPUT is disabled.
	REMOTE	Lights when the Generator is in the remote (IEEE-488 Interface) mode of operation.
	ADDR	Lights when the Generator is addressed to listen or talk.
	SRQ	Lights when the Generator has asserted the IEEE-488 SRQ signal.
⑤	MODULATION ON/OFF	Used to select type, source, and frequency of modulation. With the exception of the [400/1000] key, these keys operate as independent push-on/push-off switches for the given function. Any combination is allowed.
	INT AM	Enables internal amplitude modulation at the frequency annunciated by the '400/1000' Hz indicator.



Table 2-1. Front Panel Controls, Indicators, and Connectors (cont)

INT FM	Enables internal frequency modulation at the frequency annunciated by the '400/1000' Hz indicator.
EXT AM	Enables external amplitude modulation using the signal applied to the MOD INPUT connector.
EXT FM	Enables external frequency modulation using the signal applied to the MOD INPUT connector.
400/1000	Alternately sets the internal modulation oscillator's frequency to 400 or 1000 Hz. Selected frequency is displayed only when INT AM or INT FM is enabled.
<b>6</b> FUNCTION	With the exception of the [STEP] and [SPCL] keys, these keys operate as interlocked switches that select the parameter to be entered or edited. For the [FREQ], [AMPL], [AM], and [FM] FUNCTION keys, the bright digit appears in the corresponding display of the selected function.
FREQ	Selects the frequency parameter of the Generator to be programmed by using the DATA, EDIT, or STEP entry keys.
AMPL	Selects the amplitude parameter of the Generator to be programmed by using the DATA, EDIT, or STEP entry keys.
AM	Selects the amplitude modulation (AM) parameter of the Generator to be programmed by using the DATA, EDIT, or STEP entry keys.
FM	Selects the frequency modulation (FM) parameter of the Generator to be programmed by using the DATA, EDIT, or STEP entry keys.
SPCL	Enables the special function mode. Special functions are called up by a two-digit code, that is entered by using the DATA keys. Refer to the paragraphs on Special Function in this section for a detailed description and a list of the special functions.
 STEP	After one of the four parameter functions has been selected for programming, pressing this key allows you to program a step-wise change to that parameter. The step increase or decrease is then performed every time the STEP [↑] or [↓] keys are pressed.
<b>7</b> DATA	A ten-digit (plus sign and decimal key) keypad used for entering a parameter's value, the special function code, or a memory recall/store location.
<b>8</b> Memory	
STO	Used with the DATA keys to store the current instrument state in a memory location. Memory locations 01 through 07 are available (01 through 50 with the Non-Volatile Memory option installed).
RCL	Used with the DATA keys to recall an instrument state from a memory location. Memory locations 01 through 07 (01 through 50 with the optional Non-Volatile Memory) are available for operator-stored states; memory location 98 contains the Instrument Preset State (see Table 2-3.)

**Table 2-1. Front Panel Controls, Indicators, and Connectors (cont)**

SEQ	Sequentially recalls, in increasing location order, the instrument states stored in memory. While the [SEQ] key is pressed, successive memory locations are displayed. When the key is released, the location last displayed is recalled.
<b>⑨</b> UNITS	These keys, with the exception of [CLR/LCL], serve as the terminating keystroke of a function entry, thereby causing the Generator to be programmed. The amplitude units keys are also used during Amplitude Units Conversion entries.
MHz V 	Used with the [FREQ], [FM], and [AMPL] function keys to program the numerical DATA entries in terms of megahertz (frequency or frequency modulation) or volts (amplitude).
dB(m)	Used with the [AMPL] function key to program the numerical DATA entries in terms of decibels per milliwatt.
kHz mV	Used with the [FREQ], [FM], and [AMPL] function keys to program the numerical DATA in terms of kilohertz (frequency or frequency modulation) or millivolts (amplitude).
%	Used with the [AM] function key to program the numerical DATA entries in terms of percentage AM depth.
Hz uV	Used with the [FREQ], [FM], and [AMPL] function keys to program the numerical DATA in terms of hertz (frequency or frequency modulation) or microvolts (amplitude).
CLR LCL	When the Generator is in local operation, this key is used to clear the current entry and returns the Generator to the previous state. When the instrument is in remote operation, this key is used to return local control.
<b>⑩</b> STEP	These two keys work in conjunction with the STEP Function key. These keys repeat while they remain pressed.
[+]	After a parameter is set to the step function mode, and the 'STEP' indicator appears in the display field, this key increments the parameter by the step value previously programmed.
[-]	After a parameter is set to the step function mode, and the 'STEP' indicator appears in the display field, this key decrements the parameter by the step value previously programmed.
<b>⑪</b> EDIT	These keys are used to position the bright digit within a display field and to increase or decrease the bright digit value. All four keys repeat while they remain pressed. The function keys are used to move the bright digit to the desired display field.
[+]	Increases the bright-digit value.
[←]	Moves the bright digit one digit to the left.
[-]	Decreases the bright-digit value.
[→]	Moves the bright digit one digit to the right.

**Table 2-1. Front Panel Controls, Indicators, and Connectors (cont)**

<b>12</b>	<b>STATUS</b>	A push and hold key that displays the Uncal and Reject Entry status codes in the MODULATION, FREQUENCY, and AMPLITUDE display fields.
<b>13</b>	<b>ON/OFF</b>	A push-on/push-off key (with a corresponding 'RF OFF' indicator in the STATUS display field) that enables or disables the output of the Generator.
<b>14</b>	<b>Connector</b>	A BNC connector for input of a 1V peak, external modulation signal.
<b>15</b>	<b>Connector</b>	A standard RF connector at the output of the Generator.
<b>16</b>	<b>POWER</b>	A push-on/push-off detent switch that applies line power to the Generator.

### 2-13. Function Entry

Changing an instrument parameter with the FUNCTION-DATA-UNIT entry method of consists of:

- Selecting the Function to be changed
- Entering the new numerical value of the parameter
- Selecting the Units of the numerical value (megahertz, millivolts, etc).

The command syntax for function entries is:

Select Function -- Enter Data -- Select Unit

1. Select one of the four parameters using the FUNCTION keys. The bright digit appears in the corresponding display field. The presence of the bright digit in the display field indicates that the value of the selected parameter is ready to be programmed or changed.
2. Enter the data with the DATA keys. The numerics appear in the appropriate display field.
3. Select a UNIT key. This gives the data its absolute value, and causes the microprocessor to internally program the Generator to the new state.

For the amplitude and frequency functions, the entered data programs the displayed value. If the relative mode is enabled, the displayed value may be different from the actual output value.

Once a function is selected, that parameter or feature remains in the active programming mode until a new function is selected. Data for a selected parameter must be followed by a unit value and must be within the range specified for the function. The display field flashes and, the 'REJ ENTRY' status indicator flashes if the entered data is not within the specified range. A rejected entry does not affect the output of the Signal Generator. The output of the Generator remains at its previous values until a new value is accepted.

A function entry may be terminated at any time by the [CLR/LCL] key or by selecting another function.

## INSTALLATION AND OPERATION




Figure 2-4. Rear Panel Controls, Connectors, and Switches

Table 2-2. Rear Panel Controls, Connectors, and Switches

① AC INPUT	Permits operation from 100, 120, 220, or 240V ac. The number visible through the window on the selector card indicates the nominal line voltage to which the Generator must be connected. The line voltage is selected by orienting the selector card appropriately. A 1 1/2-ampere fuse is required for 100/120V operation and a 3/4-ampere fuse is required for 220/240V operation.
② REF INT/EXT	Permits selection of the Generator frequency reference. When set to INT, the Generator operates on the internal reference, which is either the standard oscillator or the high-stability oscillator if the High-Stability Reference is installed. In either case, the internal 10-MHz reference signal is available at the 10 MHz IN/OUT connector as a TTL level. When set to EXT, the Generator reference is the 10-MHz TTL signal applied to the external 10 MHz IN/OUT connector.  10 MHz IN/OUT connector (BNC) provides a 10-MHz TTL signal when the Generator is operating on the internal reference, or accepts a 10-MHz TTL signal when operating on external reference.
③ 10 MHZ IN/OUT	If the Sub-Harmonic option is installed, then the REF IN connector is added and the 10 MHz IN/OUT connector is relabeled 10 MHz OUT.
④ REF IN	Connector (BNC) is present only with the Sub-Harmonic reference option to accept a 1-, 2-, 2.5-, 5-, or 10-MHz, 0.3 to 4V p-p sine or square wave signal into nominally 50 ohms.
⑤ MOD INPUT	Connector (BNC) is present only with the REAR RF OUT and MOD IN option to accept a 1V peak external modulation signal.
⑥ RF OUTPUT	Connector (type N) is present only with the REAR RF OUT and MOD IN option to provide the Generator output signal.
⑦ IEEE-488 CONNECTOR	Present only with the IEEE-488 Interface option to allow remote operation of the Generator via the IEEE-488 bus.
⑧ IEEE-488 ADDRESS SWITCH	Present only with the IEEE-488 Interface option and allows the selection of the Generator bus address.

Table 2-3. Instrument Preset State

FUNCTION	SETTING
Frequency . . . . .	300.00000 MHz
Frequency Step . . . . .	1.00000 MHz
Amplitude . . . . .	-10.0 dBm
Amplitude Step . . . . .	1 dB
Modulation Rate . . . . .	1000 Hz
AM Depth . . . . .	30%
AM Depth Step . . . . .	1%
FM Deviation without/with Option -651 . . . . .	5.0/.5 kHz
FM Deviation Step without/with Option -651 . . . . .	100/10 Hz
Modulation Display . . . . .	AM Depth
Bright-Digit Location . . . . .	Frequency Bright Digit
Frequency Bright-Digit Position . . . . .	1 MHz
Amplitude Bright-Digit Position . . . . .	1 dBm
AM Bright-Digit Position . . . . .	1%
FM Bright-Digit Position without/with Option -651 . . . . .	10/1 Hz
Special Functions . . . . .	20,30,70,80,90
INT AM . . . . .	Off
EXT AM . . . . .	Off
INT FM . . . . .	Off
EXT FM . . . . .	Off
Step Function . . . . .	Frequency Step

## 2-14. Bright-Digit Edit Operation

Changing an instrument parameter by the edit entry method is the fastest way to make vernier (incremental) changes to one of the four parameters. The EDIT keys are used with the four parameter FUNCTION keys to position the bright digit in the desired display field and then increase or decrease the bright-digit value.

The command syntax for bright-digit edit entries is:

Select Display Field -- Position Bright Digit -- Change Bright-Digit Value

1. Use one of the four FUNCTION keys to position the bright digit in the appropriate display field.
2. Use the [↔] or [←] EDIT keys to position the bright digit to the desired resolution, and use the [↑] or [↓] EDIT keys to increase or decrease the value of the bright digit.

The position of the bright digit within a display field is maintained when the bright digit is moved from one display field to another.

The repeat rate of the [↑] or [↓] EDIT keys may be changed to a faster or slower rate (a medium repeat rate is the default) with a special function code. Refer to the paragraphs on Special Function and the reference pages in this section for the method and code.

## 2-15. Step Operation

Changing parameters by the Step Entry method allows you to preset step-wise increments of a parameter then change that parameter (by the amount programmed in the step function) [↑] or [↓] with a single keystroke.

The command syntax for step entries is:

Select Step Function -- Enter Data -- Select Units -- Change Parameter

1. Select the parameter to be changed step-wise using one of the FUNCTION key.
2. Press the **[STEP]** key to enable the Step function.
3. Program the step amount using the DATA and UNIT keys.
4. The parameter value can now be changed, up or down by the programmed step amount by using the **[↑]** or **[↓]** STEP keys.

While the **[STEP]** key is pressed, the display field of the selected parameter shows the step amount. The 'STEP' indicator is lit in the display field currently affected by the **[STEP]** key.

**[↑] or [↓] STEP**

The repeat rate of the ~~STEP~~ keys may be changed to a faster or slower rate (a medium repeat rate is the default) with a Special Function code. Refer to the paragraphs on Special Functions and the reference material for the method and code.

A step entry is ignored when the result of that step entry would cause the value of the parameter to exceed its programmable limit.

### 2-16. Status and Clear Entries

The Status entry allows you to interrogate the Generator for an explanation of uncalibrated or rejected entry operation ('UNCAL' or 'REJ ENTRY') indicator is lit. Refer to the paragraphs on Status and Clear Entry in the reference section for a complete list of status codes.

The **[CLR|LCL]** key may be used to clear a partial DATA entry or clear the flashing 'REJ ENTRY' indicator.

### 2-17. RF Output On/Off

The RF OUTPUT **[ON/OFF]** key allows the operator to enable or disable the RF output of the Generator. This feature is useful in zeroing a power meter, finding the noise floor of a system, or determining the presence or source of an unknown signal.

On power-up, the RF output of the Generator is enabled. Pressing the RF OUTPUT **[ON/OFF]** key disables the output of the Generator and causes the 'RF OFF' indicator (in the STATUS display field) to light. If the Non-Volatile Memory option is installed, the RF ON/OFF status on power-up assumes the state it was in when the Generator was turned off.

### 2-18. Modulation On/Off and Rate

The MODULATION ON/OFF keys allow you to select any combination of modulation or no modulation. The MODULATION display field indicates what combination of modulation has been selected. Each modulation key is a push-on push-off type (except the **[400/1000]** key).

The **[400/1000]** key toggles the internal modulation oscillator between 400 and 1000 Hz. The '400 Hz' and '1000 Hz' indicators are lit only when INT AM or FM modulation is enabled.

### 2-19. Memory

Memory entry using the **[STO]** key allows you to save up to seven complete front panel settings for later recall. If the Non-Volatile Memory option is installed, the capacity for front panel settings is increased to 50.

The command syntax for memory operations follows. No memory location needs to be specified for the sequence operation.

#### Select Memory Function -- Enter Memory Location

To store the current front panel setting, press the [STO] key (located below the DATA keys). The last memory location stored or recalled is displayed in the FREQUENCY display field. Next, use the DATA keys to enter the two-digit memory location code. The location code must contain both digits (e.g., 01, 02, ...07). The two-digit code appears in the FREQUENCY display field as it is entered.

To recall a front panel setting, press the [RCL] key (located below the DATA keys). The last memory location stored or recalled is displayed in the FREQUENCY display field. Next, use the DATA keys to enter the memory location code of the desired front panel setting. Remember, the location code must contain both digits of the memory location code.

Memory location 98 contains the Instrument Preset State that can be recalled at any time.

The [SEQ] key allows the front panel settings stored in memory to be sequentially recalled. This process is activated by pressing the [SEQ] key at any time. When the [SEQ] key is pressed, the memory location code of the currently recalled setting appears in the FREQUENCY display field, and the location is recalled. When the last memory location is reached (07 for standard instruments, 50 with the Non-Volatile Memory option), the [SEQ] key starts over at 01. The [SEQ] key repeats while pressed.

### 2-20. Special Function

Special Function Entries allow the operator to enable several special operating functions in the Generator. For example, special functions allow the operator to change the repeat rate of the STEP and EDIT keys, start the self tests, display the results of the power-up self tests, display the IEEE-488 address, enable relative and fixed-range features, and disable or enable special attenuation features. A complete list of the special functions available are presented in Table 2-4.

The command syntax for special function entries is as follows:

#### Select Special Function -- Enter Special Function Code

The special function is selected by pressing the [SPCL] key. The special function code is entered using the DATA keys.

### 2-21. OPERATING REFERENCE MATERIAL

This reference section describes local and remote operation for each Generator function. The functions are arranged in alphabetical order. For each function, the syntax of the command, allowable data ranges, and other information is presented.

### 2-22. Amplitude and Frequency Entry

The following information describes how to control the carrier frequency and amplitude by the FUNCTION-DATA-UNIT entry sequence. This method applies to both normal and relative operations. The frequency display is a fixed-point display in MHz. The amplitude display is fixed point while displaying dBm but is floating point when displaying voltage units.

The RF OUTPUT [ON/OFF] must be enabled for the Generator to produce an output (see the reference material on RF OUTPUT ON/OFF Entry).

**Table 2-4. Special Functions**

SPECIAL FUNCTION	OPERATION
00	Clears all currently set special functions.
02	Initiates self tests.
03	Display test. This test is detailed in Section 4D.
04	Key test. This test is detailed in Section 4D.
07	Set SRQ if IEEE-488 Interface option is installed.
08	Reset SRQ if IEEE-488 Interface option is installed.
09	Display instrument software revision level. Information appears in the MODULATION and FREQUENCY display fields for approximately 3 seconds or until another key is pressed.
10	Display IEEE-488 mode and address in decimal form if the IEEE-488 Interface option is installed.
11	Display self-test results. Zeros in the display fields indicate that the self tests have passed. See Section 4D for details of the self-test display.
12	Turn on displays.
13	Turn off all displays. All other functions still operate.
14	Initialize memory locations to Instrument Preset State. 'Sto' appears in the FREQUENCY display field for 3 seconds. If during this time, the [STO] key is pressed, all memory locations are initialized.
15	Latch test. This test is detailed in Section 4D.
20	Disable Relative Frequency. See reference page on Relative Function.
21	Enable Relative Frequency. See reference page on Relative Function.
30	Disable Relative Amplitude. See reference page on Relative Function.
31	Enable Relative Amplitude. See reference page on Relative Function.
70	Set repeat rate for EDIT and STEP keys to medium.
71	Set repeat rate for EDIT and STEP keys to fast.
72	Set repeat rate for EDIT and STEP keys to slow.
80	Enable Amplitude correction. Normal operation.
81	Disable Amplitude correction. If level accuracy is not critical, level correction circuitry can be disabled for improved programming speed. Level accuracy may be up to 7 dB low.
82	Disable attenuator correction. Useful as a troubleshooting tool. RF input to attenuator is flat.
83	Program alternate 24 dB attenuation. See Section 4D.
84	Program alternate 24 dB attenuation. See Section 4D.
85	Program alternate 24 dB attenuation. See Section 4D.
86	Program alternate 24 dB attenuation. See Section 4D.
90	Disable Amplitude Fixed Range. See reference material on Amplitude Fixed Range.
91	Enable Amplitude Fixed Range. See reference material on Amplitude Fixed Range.



## Command Syntax

Select Function -- Enter Data -- Select Unit

## Summary

	COMMAND	RANGE	RESOLUTION	NOTES
Set Frequency				
Local:	[FREQ] -- DATA -- [MHz V] [kHz mV] [Hz uV]	0.1 to 1050 MHz	10 Hz	1,2
Remote:	"FR" -- float -- "GZ" "MZ" "KZ" "HZ"	0.1 to 1050 MHz	10 Hz	1,3
Set Amplitude				
Local:	[AMPL] -- DATA -- [dB(m)] [MHz V] [kHz mV] [Hz uV]	-137 to +13 dBm 0.03 uV to 1 V	0.1 dBm 3 digits	2,4,5
Remote:	"AP" -- float -- "DB" "V" "MV" "UV" "NV"	-137 to +13 dBm 0.03 uV to 1 V	0.1 dBm 3 digits	3,4,5

## Example

Set Frequency to 10.7 MHz and Amplitude to -7.5 dBm.

Local: [FREQ] [1] [0] [.] [7] [MHz|V]  
[AMPL] [-] [7] [.] [5] [dB(m)]

Remote: "FR10.7MZ,AP-7.5DB"

## Notes

1. Frequency ranging occurs at 245 and 512 MHz.
2. FUNCTION ([FREQ] or [AMPL]) remains selected until another FUNCTION or [STEP], [STO], [RCL], or [SPCL] is pressed.
3. float equals floating-point number.
4. Amplitude uncalibrated range from -147.4 to -137.1 dBm and from +13.1 to +19 dBm.
5. Amplitude ranging occurs at 1/2V, 1/4V, 1/8V, ... 1/2<sup>23</sup>V with AM off and 1/4V, 1/8V, 1/16V, ... 1/2<sup>24</sup>V with AM on.

## Related Operations

Amplitude Fixed Range  
Bright-Digit Edit Entry  
Relative Function  
Step Entry

### 2-23. Amplitude Fixed Range

The following information describes how to use the Fixed-Range special function. This special function fixes the current amplitude range (holds the currently selected step of the Step Attenuator). This function allows monotonic and nontransient level control over a limited range around those levels where the Step Attenuator normally autoranges. This level control may be accomplished with the Bright-Digit Edit Entry only.

The level vernier in fixed range has at least 12 dB of range.

## Command Syntax

Select Fixed Range -- Enable or Disable

## Summary

COMMAND	NOTES
Enable Fixed Range	
Local: [SPCL] [9] -- [1]	1
Remote: "SP" "9" -- "1"	
Disable Fixed Range	
Local: [SPCL] [9] -- [0]	2
Remote: "SP" "9" -- "0"	

## Example

Set the Generator for monotonic and nontransient amplitude control (Bright-Digit Edit only) over the range of the vernier level control below 0.25V.

Local: [AMPL] [.] [2] [5] [MHz|V] [SPCL] [9] [1]

Remote: "AP.25V,SP91"

## Notes

1. The amplitude range is fixed only for Bright-Digit Edit operations. Other methods of changing the amplitude cause the step attenuator to autorange if necessary.
2. With amplitude fixed range disabled, amplitude ranging occurs at 1/2V, 1/4V, 1/8V, ... 1/2<sup>23</sup> V with AM off and 1/4V, 1/8V, 1/16V, ... 1/2<sup>24</sup> V with AM on.

## Related Operations

Bright-Digit Edit Entry  
Relative Function

## 2-24. Amplitude Units Conversion

The following information describes how to convert the displayed amplitude level from dBm to volts and volts to dBm. The output of the Generator does not change during these operations.

### Command Syntax

Select Amplitude Function -- Select Unit

### Summary

COMMAND	NOTE
Convert dBm to volts	
Local: [AMPL] -- [MHz V] [kHz mV] [Hz uV]	1
Remote: "AP" -- "V" "mV" "uV" "nV"	1
Convert volts to dBm	
Local: [AMPL] -- [dB(m)]	
Remote: "AP" -- "dB"	

### Example

Change the displayed amplitude of -10.0 dBm to its voltage equivalent.

Local: [AMPL] [MHz|V]

Remote: "APV"

### Note

1. Any voltage unit is accepted since the microprocessor automatically selects the units appropriate for the value being displayed.

### Related Operations

Relative Function

## 2-25. Bright-Digit Edit Entry

The following information describes how to use a Bright-Digit Edit Entry to change an instrument parameter. The output frequency, amplitude and the modulation indices can be modified with this entry method.

The RF OUTPUT [ON/OFF] must be enabled for the Generator to produce an output. (See the reference material on RF OUTPUT [ON/OFF] Entry.)

### Command Syntax

Select Display Field -- Position Bright Digit -- Change Bright-Digit Value

## INSTALLATION AND OPERATION

### Summary

	COMMAND	NOTES
Edit Frequency		
Local:	[FREQ] -- EDIT [←]/[→] -- EDIT [↑]/[↓]	1,2
Remote: "FB"	-- float "GZ" -- "KF" float "MZ" "KZ" "HZ"	3,4,5
Edit Amplitude		
Local:	[AMPL] -- EDIT [←]/[→] -- EDIT [↑]/[↓]	1,2
Remote: "AB"	-- float "DB" -- "KA" float "V" "MV" "UV" "NV"	3,4,5
Edit FM Deviation		
Local:	[FM] -- EDIT [←]/[→] -- EDIT [↑]/[↓]	1,2
Remote: "DB"	-- float "GZ" -- "KD" float "MZ" "KZ" "HZ"	3,4,5
Edit AM Depth		
Local:	[AM] -- EDIT [←]/[→] -- EDIT [↑]/[↓]	1,2
Remote: "PB"	-- float "PC" -- "KP" float	3,4,5

### Example 1

Edit the displayed amplitude of 9.7 dBm to 10.0 dBm.

Local: Put the bright digit in the amplitude display by pressing [AMPL]. Select the least significant digit in that display by pressing EDIT [→] until the bright digit is on that digit. Increase the value of that digit by pressing EDIT [↑] three times.

Remote: "AB.1DB,KA3"

### Example 2

Edit the displayed FM Deviation from 5.0 kHz to 3.0 kHz.

Local: Put the bright digit in the FM display by pressing [FM]. Select the 1-kHz digit by pressing the EDIT [→] or EDIT [←] until the bright digit is on that digit. Decrease the value of that digit by pressing EDIT [↓] twice.

Remote: "DB1KZ,KD-2"

## Notes

1. The bright-digit field remains selected until another display field is selected.
2. The bright-digit position is maintained for each of the four functions so that the bright digit can be moved from one display to another and back without losing its position in that previous display field.
3. float equals floating-point number.
4. In remote, the bright digit is positioned within a display field using a decade value and associated unit. Minus signs are ignored.
5. In remote, the bright digit is moved to the corresponding field and is increased or decreased by the signed integer following the "KF,KA,KD,KP" messages. The generic edit command "KB" may also be used to edit up or down the current bright-digit position. Positive integers do not require a sign.

## Related Operations

Relative Function  
Amplitude Fixed Range

### 2-26. Memory Entry

The following information describes how to use the memory function to store and recall front panel settings. The standard Generator has seven memory locations for storing settings that are lost if the power is turned off. With the Non-Volatile Memory option, the Generator has 50 memory locations that are retained for 2 years with the power off.

The sequence feature allows the operator to recall successive memory locations.

## Command Syntax

Select Memory Function -- Enter Memory Location

## Summary

	COMMAND	NOTES
Store		
Local:	[ST0] -- [n] [n]	1,2,3
Remote:	"ST" -- int	1,4
Recall		
Local:	[RCL] -- [n] [n]	1,2,3
Remote:	"RC" -- int	1,4
Sequence		
Local:	[SEQ]	5,6
Remote:	"SQ"	5

## INTRODUCTION AND SPECIFICATIONS

### Example

Recall the Instrument Preset State (located in memory location 98). Change the frequency parameter to 302 MHz, then store the new front panel setting in memory location 06.

Local: [RCL] [9][8] EDIT [↑] [↑] [STO] [0][6]

Remote: "RC98,KF2,ST6"

### Notes

1. The memory locations available for operator use are 01 through 07. With the Non-Volatile Memory option, the available locations are 01 through 50. Additionally, the following special memory locations are available:

Memory location 00 contains a backup-memory location. After a recall (or sequence) operation it contains the last front panel setting. After a store operation, it contains the data in the stored memory location before the store operation. Thus, a recall operation can be reversed by recalling location 00.

Memory location 98 contains the Instrument Preset State.

Memory location 99 contains the ~~the~~ present instrument state.

2. In local control, two data digits must be entered to specify the memory location. The recall or store is performed when the second digit is released.
3. The last memory location specified (used for sequence operations) is displayed while the [STO] or [RCL] button is pressed.
4. int equals unsigned integer.
5. The sequence operation recalls the next higher memory location, starting from the last memory location stored or recalled. No memory location need to be specified. When the highest location is reached, the sequence starts over again at location 01.
6. While [SEQ] is pressed, the next memory location number is displayed and the memory location is recalled. This key is repeating.

### 2-27. Modulation Entry

The following information describes how to preset the modulation index (AM depth or FM deviation), internal modulation rate (400 or 1000 Hz), and how to select the modulation source (internal and/or external).

The FUNCTION-DATA-UNIT method of selecting the modulation index is summarized in the following command syntax. The indices may also be modified using Bright-Digit Edit or Step Entry. Since there is only one modulation display, the modulation index displayed is determined by the last modulation FUNCTION key pressed.

### Command Syntax

Select Function -- Enter Data -- Select Unit

## Summary

	COMMAND	RANGE	RESOLUTION	NOTES
Set AM Depth				
Local:	[AM] -- DATA -- [%]	0 to 99%	1%	1,2
Remote:	"AM" -- float -- "PC"	0 to 99%	1%	1,3
Set FM Deviation				
Local:	[FM] -- DATA -- [MHz V] [kHz mV] [Hz uV]	0.1 to 99.9 kHz	3 digits	1,4
Remote:	"FM" -- float -- "GZ" "MZ" "KZ" "HZ"	0.1 to 99.9 kHz	3 digits	1,3,4

## Summary

	COMMAND	NOTES
Select Modulation Rate		
Local:	[400/1000]	5
Remote:	"MR" "0" or "1"	6

## Summary

	COMMAND	NOTES
Enable or Disable Modulation		
Local:	[INT AM] [INT FM] [EXT AM] [EXT FM]	7,8
Remote:	"AI" "0" or "1" "FI" "0" or "1" "AE" "0" or "1" "FE" "0" or "1"	9

## Example

Set the FM deviation to 5 kHz, the modulation rate to 400 Hz, and internally modulate the carrier.

Local: [FM] [5] [kHz] [INT FM] [400/1000]

Remote: "FM5KZ,MRO,FI1"

### Notes

1. This operation does not change the Generator output unless the corresponding modulation is enabled.
2. Uncalibrated if peak amplitude exceeds +13 dBm or if AM depth exceeds 90% and AM is enabled.
3. float equals floating-point number.
4. Uncalibrated if FM is enabled and FM deviation is below 100 Hz or above (frequency - 100 kHz)/3. ~~If the Low-Rate FM option is installed, the range of FM deviation is 0.01 to 9.99 kHz. With this option, the uncalibrated deviation range is below 10 Hz or above (frequency - 100 kHz)/30.~~
5. Toggles between 400 or 1000 Hz only. An indicator shows selected rate only if internal modulation is on.
6. "0" selects a modulation rate of 400 Hz; "1" selects 1000 Hz.
7. These are ON/OFF operations; any combination is allowed.
8. Two indicators 'EXT HI' and 'EXT LO' are lit when external modulation is on to indicate that the external modulation signal is 2% above or 2% below the nominal 1V peak input requirement.
9. "0" turns the modulation source off; "1" turns it on.

### Related Operations

Bright-Digit Edit Entry  
Step Entry

#### **2-28. Relative Function**

The following paragraphs describe how to change frequency and amplitude using the Relative mode. There are two steps:

1. Setting the reference
2. Changing the parameter relative to that reference

Setting the reference is done by setting the parameter to the desired value and then enabling the relative mode for that parameter. This causes the 'REL' indicator to light and the displayed value to be zero in the corresponding display. The Generator output does not change during these operations. In the relative mode, the usual means of changing the parameter may be used; i.e., FUNCTION-DATA-UNIT, Step, or Bright-Digit Edit Entry.

In the relative frequency mode, the actual frequency is the sum of the reference and the displayed frequency. The actual frequency may be displayed by pressing the [FREQ] key.

In the relative amplitude mode, the actual amplitude is the sum of the reference and the displayed amplitude when the reference and the displayed quantities have the same units. However, with mixed units (volts and dB), the actual amplitude is the voltage value scaled by the dB value. The actual amplitude may be displayed by pressing the [AMPL] key.



## Command Syntax

Select Relative Function -- Enable or Disable

### Summary

	COMMAND	NOTE
Frequency		
Local:	[SPCL] [2] -- [0] or [1]	1
Remote:	"SP" "2" -- "0" or "1"	1
Amplitude		
Local:	[SPCL] [3] -- [0] or [1]	1
Remote:	"SP" "3" -- "0" or "1"	1

### Example

Set the amplitude to -15 dB $\mu$ V; i.e., 15 dB below 1 microvolt.

Local: [AMPL] [1] [Hz| $\mu$ V] [SPCL] [3] [1] [AMPL] [-] [1] [5] [dB(m)]

Remote: "AP1UV,SP31,AP-15DB"

### Note

1. 1 enables the relative function; 0 disables the relative function.

### Related Operations

Amplitude and Frequency Entry  
Bright-Digit Edit Entry  
Step Entry

## 2-29. RF OUTPUT ON/OFF Entry

The following information describes how to enable the output of the Generator using the RF OUTPUT [ON/OFF] key and the corresponding remote code.

### Command Syntax

RF Output On/Off

### Summary

	COMMAND	NOTE
RF Output On		
Local:	<i>as on</i> RF [ON/OFF] when 'RF OFF' is on	1
Remote:	"R01"	1
RF Output Off		
Local:	<i>output</i> RF [ON/OFF] when 'RF OFF' is off	
Remote:	"R00"	

Notes

- 1. Turning the RF Output on resets the optional RPP circuitry if it has tripped.

2-30. Special Function Entry

The following information describes how to use the Special Function Entry to use the special operating functions of the Signal Generator. Table 2-4 lists the special functions available.

7. { In addition to the Special Functions, there are three permanent use memory locations. Locations 00, 98, and 99 contain the backup, preset, and present instrument states, respectively. See paragraph 2-26 for more details. } *this doesn't belong here*

The special function code is a two-digit number. The first digit indicates the classification of the special function, and the second digit specifies the particular special function.

The special function is executed when the second special function code digit is entered. There are ten classes of special functions. The special functions in the 0(n) and 1(n) class cause an action to be performed. Classes 2(n) through 9(n) cause an instrument state to change. The status of classes 2(n) through 9(n) appears (left to right) in the frequency display field when the [SPCL] key is pressed.

Command Syntax

Select Special Function -- Enter Special Function Code

	COMMAND	NOTE
Local:	[SPCL] -- [n] [n]	
Remote:	"SP" -- int	1

Example

Change the repeat rate of the EDIT and STEP keys to slow.

Local: [SPCL] [7] [2]  
Remote: "SP72"

Note

- 1. int equals unsigned integer.

Related Operations

Fixed Range  
Relative Function

2-31. Status and Clear Entry

The Status entry allows you to interrogate the Generator for an explanation of either uncalibrated operation ('UNCAL' indicator is lit) or rejected entry operation (the 'REJ ENTRY' indicator in lit).

When either the 'UNCAL' or 'REJ ENTRY' indicator is lit, press and hold the [STATUS] key to display the Uncalibrated or Rejected Entry Error Code Message. These messages provide detailed information on the nature of the uncalibrated or rejected entry condition. Table 2-5 contains a list and explanation of all the Uncalibrated Error Code Messages. Table 2-6 contains a list and explanation of all the Rejected Entry Error Code messages.

**Table 2-5. UNCAL Error Codes**

CODE	DESCRIPTION
000 000 000	= Indicates no UNCAL conditions
001 000 000	= FM deviation < 100 Hz (< 10 Hz with Option -651)
002 000 000	= FM deviation > (freq -100 kHz)/3
*004 000 000	= Excess FM deviation, main or reference PLL unlocked
020 000 000	= AM depth > 90%
*000 010 000	= Main or reference PLL unlocked
000 000 001	= Level vernier below calibrated range or level < -137 dBm
000 000 002	= Peak (AM) amplitude > +13 dBm
*000 000 004	= Amplitude unlevelled
*000 000 010	= Fixed-range level vernier at 0
*000 000 020	= Fixed-range level vernier at full scale
*000 000 040	= RPP tripped
000 000 100	= Level below -137 dBm
000 000 200	= Level correction disabled
*000 000 400	= RF output off

**Table 2-6. REJect ENTRY Codes**

CODE	DESCRIPTION
001 000 000	= FM deviation not between 0 and 99.9 kHz (9.99 kHz with Option -651)
002 000 000	= FM deviation Step not between 0 and 99.9 kHz (9.99 kHz with Option -651)
004 000 000	= AM depth not between 0 and 99%
010 000 000	= AM depth step not between 0 and 99%
020 000 000	= IEEE-488 command syntax error
040 000 000	= IEEE-488 input value out of range
100 000 000	= Special function requires IEEE option
200 000 000	= IEEE edit or step operation beyond allowed range
000 001 000	= Frequency not between 0.1 and 1050 MHz
000 004 000	= Frequency step not between 0 and 1050 MHz
000 040 000	= Invalid memory location
000 100 000	= Invalid data in memory
000 200 000	= Special function not allowed
000 000 001	= Output amplitude not between 10 nV and 2V
000 000 002	= Insufficient resolution for units conversion
000 000 004	= Units conversion to volts not allowed with reference in volts
000 000 010	= Units conversion to dB not allowed with reference in volts
000 000 020	= Amplitude step not between 0 and 166 dB or 0 and 1999V
000 000 040	= Units conversion on amplitude step not allowed
000 000 100	= Amplitude step and current amplitude display not in same units

The [CLR LCL] key may be used to clear a partial DATA entry or clear the flashing 'REJ ENTRY' indicator. Press the [STATUS] key while an 'UNCAL' indication exists to display the Uncal Error Codes in three fields:

Flashing codes (denoted by \*) indicate abnormal operation or aberrated output. Non-flashing codes indicate operation outside specified range.

Press the [STATUS] key while the 'REJ ENTRY' indication exists to display the Reject Entry error codes:

## 2-32. Step Entry

The following information describes how to use the Step Entry function to change an instrument parameter. The RF OUTPUT [ON/OFF] must be enabled for the Generator to produce an output. (See the reference material on RF OUTPUT [ON/OFF] Entry.)

### Command Syntax

Select Step Function -- Enter Data -- Select Units -- Change Parameter

### Summary

	COMMAND	RANGE	RESOLUTION	NOTES
Frequency				
Local:	[FREQ][STEP]—DATA --[MHz V] [kHz mV] [Hz uV]	0 to 1050 MHz	10 Hz	
Remote: "FS"	--float--"GZ" "MZ" "KZ" "HZ"	0 to 1050 MHz	10 Hz	1,2
Amplitude				
Local:	[AMPL][STEP]—DATA --[dB(m)] [MHz V] [kHz mV] [Hz uv]	0 to 166 dB 0 nV to 999 V	0.1 dB 3 digits	
Remote: "LS"	--float--"dB" "V" "MV" "UV" "NV"	0 to 166 dB 0 nV to 999V	0.1 dB 3 digits	1,2
FM deviation				
Local:	[FM][STEP] —DATA --[MHz V] [kHz mV] [Hz uV]	0 to 99.9kHz	3 digits	3

Remote: "DS"	--float--	"GZ"	--"DU"/"DD"	
		"MZ"		
		"KZ"		
		"HZ"		
		0 to 99.9kHz	3 digits	1,2,3
AM depth				
Local: [AM][STEP]	--DATA --[%]		-- STEP [↑]/[↓]	
	0 to 99%		1%	
Remote: "PS"	--float--	"PC"	--"PU"/"PD"	
	0 to 99%		1%	1,2

### Example

Recall the Instrument Preset State: [RCL] [9] [8]. Step the displayed frequency of 300 MHz, in 10-MHz steps, to 270 MHz.

Local: [FREQ] [STEP] [1] [0] [MHz|V] [↓] [↓] [↓]STEP  
 Remote: "FS10MZ,FD,FD,FD"

### Notes

1. float equals floating-point number.
2. Entering the step size from IEEE-488 does not select the step function. For example, "FS10MZ" does not select the step function; "FD" or "FU". The generic step up/down commands "SU" and "SD" may be used to step the current step function.
3. If the Low-Rate FM option is installed, the range of FM deviation steps is 0 to 9.99 kHz.

*must be used to select the frequency step function.*

### Related Operations

#### Relative Function

## 2-33. REMOTE OPERATION (IEEE-488 INTERFACE)

The following paragraphs describe how to operate the Generator using the IEEE-488 Interface option. This option allows you to program the Generator and operate instrument functions via the IEEE-488 bus (with the exception of the front panel POWER switch and the rear panel REF INT/EXT switch). The IEEE-488 Interface option also provides additional programming features not accessible from the front panel.

The rest of this section is divided into two parts: the first part describes how to set up the Generator for operation on the IEEE-488 bus and gives some typical programming examples. The first part also includes a complete list of the programming commands recognized by the Generator software.

The second part describes the implementation of the IEEE-488 interface and programming features that are accessible only from the IEEE-488 Interface. The second

part includes typical timing data, provided as an aid to system programmers. This information can assist in writing programs that have greater speed and efficiency.

The Generator can be used with any IEEE-488 controller in the normal addressed mode. The following two additional modes are available for operation without a controller:

Listen-only mode  
Talk-only mode

In the listen-only mode, the Generator responds to all data messages on the IEEE-488 bus. In the talk-only mode, the Generator sends commands on the IEEE-488 bus to program another 6060A Generator (or a 607xA with some restrictions).

### 2-34. Setting Up the IEEE-488 Interface

Figure 2-5 shows a 6060A Signal Generator connected to a 1722A via the IEEE-488 bus.




Figure 2-5. 6060A Signal Generator Connected to a 1722A

Use the following procedure to set up the Generator with the IEEE-488 Interface option:

1. Connect a standard IEEE-488 cable between the Generator and the IEEE-488 device.

#### NOTE

*The IEEE-488 Interface signal SHIELD (pin 12) can be disconnected (when using an IEEE-488 cable with a metallic hood) from instrument ground. To do this, use the left most address switch (as viewed from the rear panel).*

2. Select the IEEE-488 address and mode as follows:
  - a. For control of the Generator with a controller, set both the LISTEN ONLY and TALK ONLY switches to 0 (down). Set switches a1 through a5 to the desired address. For example, for an address of 1, set switches a2, a3, a4, and a5 to 0 (down), and set switch a1 to 1 (up).
  - b. For talk-only operation, set the TALK ONLY switch to 1 (up).
  - c. For listen-only operation, set the LISTEN ONLY switch to 1 (up) and the TALK ONLY switch to 0 (down).
3. Verify the address and mode:

- a. Press the [SPCL] and the [1][0] keys. Verify that the selected address appears in decimal in the Frequency display field.
- b. If the talk-only mode or listen-only mode has been selected, "to" or "lo" appears to the left of the address in the Frequency display field.

**NOTE**

*The address switches are continuously monitored except when in remote. The TALK ONLY and LISTEN ONLY switches are only read when the Generator is powered on.*

**2-35. Programming Commands**

After the address and mode have been set, the Generator can be programmed by an IEEE-488 controller or from another Generator. Tables 2-7 and 2-8 and the programming examples following them provide the basic information on how to program the Generator.

More details about the commands can be found in two places. Commands that are available from the front panel are described in the first part of this section. Those commands that are only available from the IEEE-488 Interface are described in the Commands Descriptions paragraphs later in this section of the manual.

Table 2-7 is an index for the IEEE-488 Commands used in Table 2-8. This index is a list of the command headers according to function. Table 2-8 lists all the remote commands that are recognized by the Generator. The commands are listed alphabetically by function.

**2-36. Programming Examples**

The following three examples show how to use the IEEE-488 bus and use a variety of controllers to program the Generator. In the first example, a Fluke 1722A Controller is used to program the Generator. In the second example, two Generators are configured to track each other in frequency. In the third example, a 1722A is used to program the Generator with the frequency step up controlled by the trigger command.

**Table 2-7. Index of IEEE-488 Commands**

FUNCTION	COMMAND HEADERS
Amplitude Entry	AP, SP3x, RA, SP8x, SP9x
Binary Learn Commands	LI, LM
Clear Commands	CB, CE, CL
Edit Entry	AB, DB, FB, PB, KB, KA, KD, KF, KP
Frequency Entry	FR, SP2x, RF
Interface Mode Commands	EM, RM, TM, VM, UM, @
Interrogate Commands	ID, IE, II, IO, IR, IT, IU, IV
Memory Entry	RC, ST, SQ
Modulation Entry	AM, AE, AI, FM, FE, FI, MR, MF
Monitor Commands	IB, OB, OD, RB, RW, DW, WB, WW, XA, XB, XD, XR
RF ON/OFF Entry	RO
Special Function Entry	SP
SRQ Commands	IM, SM, XF
Step Entry	FS, LS, PS, DS, SU, SD, FU, FD, LU, LD, PU, PD, DU, DD
Trigger Commands	CT, TR

Table 2-8. IEEE-488 Commands

COMMAND  USE	COMMAND			COMMENTS
	HEADER	NUMERIC	SUFFIX	
AMPLITUDE ENTRY				
Program Amplitude	AP	float	V MV UV NV DB	Program displayed amplitude in units of: volts millivolts microvolts nanovolts dB or dBm
Convert Amplitude Units	AP	none	V MV UV NV DB	Change amplitude units to: volts volts volts volts dB or <del>dBm</del> 6V
Relative Amplitude	SP	30/31	none	Disable/enable relative amplitude operation
Relative Amplitude	RA	0/1		disable/enable relative amplitude operation.
Level Correction	SP	80 81 82	none	Enable all level correction. Disable all level correction. Disable attenuator correction.
Amplitude Fixed Range	SP	90/91	none	Disable/enable amplitude fixed-range operation.
BINARY LEARN COMMANDS				
Store a Front Panel Setup	LI	int	string	The Generator stores the string into the memory location specified by int. See the Command Description paragraph for decoding the learn string.
Send a Front Panel Setup	LM	int	none	The Generator responds with the contents of the memory location specified by int. See the Command Descriptions paragraph for decoding the learn string.
CLEAR COMMANDS				
Clear IEEE-488 Output Buffer	CB	none	none	Clears IEEE-488 output buffer.
Clear error	CE	none	none	Clears the IEEE-488 rejected entry status.
Device Clear	CL	none	none	Clears the instrument state.
EDIT ENTRY				
Position Amplitude	AB	float	V MV	Position the bright digit in the AMPLITUDE display with the stated resolution. For



Table 2-8. IEEE-488 Commands (cont)

Bright Digit			UV NV DB	example, enter "AB10MV" for 10 mV resolution.
Position FM Bright Digit	DB	float	GZ MZ KZ HZ	Position the bright digit in the FM Display with the stated resolution. For example, enter "DB1KZ" for 1-kHz resolution.
Position Frequency Bright Digit	FB	float	GZ MZ KZ HZ	Position the bright digit in the FREQUENCY display with the stated resolution. For example, enter "FB1MZ" for 1-MHz resolution.
Position AM Bright Digit	PB	float	PC	Position the bright digit in the AM display with the stated resolution. For example, enter "PB1PC" for a 1% resolution.
Edit	KB	float	none	Edit the current bright digit by float counts.
Edit Amplitude	KA	float	none	Move the bright digit to the AMPLITUDE display and edit amplitude by float counts.
Edit FM	KD	float	none	Move the bright digit to the FM display and edit FM by float counts.
Edit Frequency	KF	float	none	Move the bright digit to the FREQUENCY display and edit frequency by float counts.
Edit AM	KP	float	none	Move the bright digit to the AM display and edit AM by float counts.
FREQUENCY ENTRY				
Frequency Programming	FR	float	GZ MZ KZ HZ	Program displayed frequency in units of:  gigahertz megahertz kilohertz hertz
Relative Frequency	SP	20/21	none	Disable/enable relative frequency operation.
Relative Frequency	RF	0/1	none	Alternate programming command for disable/enable relative frequency operation.
INTERFACE MODE COMMANDS				
Error Mode	EM	0/1	none	Disable/enable the clear error mode. If disabled, the IEEE-488 error status is cleared only when interrogated. If enabled, the error status is cleared when a new message is processed.

Table 2-8. IEEE-488 Commands (cont)

Record Mode	RM	0/1	none	Disable/enable the record mode. If disabled, the message unit is a command. If enabled, a message unit is a record. The message unit is the smallest group of characters that the Generator processes.
Record Terminator Mode	TM	0/1	none	Selects the LF/CR character as the record terminator. The record terminator is used on input in the record mode and is sent following all output.
Output Valid Mode	VM	0/1	none	Disable/enable the output valid mode. In the output valid mode, the Generator waits to process commands until the RF output has become valid.
Unbuffered Mode	UM	0/1	none	Disable/enable the unbuffered mode. If disabled, all input is buffered. If enabled, only one message unit is buffered.
"a" Modes	a	int	none	The "a" command may be used as an alternate method of programming interface modes.
INTERROGATE COMMANDS				
Instrument Identification	ID	none	none	The Generator responds with its model number, for example, "6060A".
Elapsed Time Indicator	IE	none	none	If the Non-Volatile Memory option is installed, the Generator responds with the total operating time since the Generator was manufactured.
Interface Modes	II	none	none	Interrogate the interface modes selected. The Generator responds with an unsigned integer.
Option Loading	IO	none	none	Interrogate the option loading. The Generator responds with the message: d1, d2, d3  d1 is the instrument code. d2 is the digital and synthesizer options. d3 is the output options. See the Interrogate Commands paragraphs for details.
Rejected Entry	IR	none	none	Interrogates the rejected entry error codes. The Generator responds with three octal fields: "AAAAA,BBBBB,CCCCC". See Table 2-6 for a list of rejected entry error codes.
Self Test	IT	none	none	Interrogates the results of the self tests. The Generator responds with the self-test results. See Section 4D for self-test codes.

Table 2-8. IEEE-488 Commands (cont)

UNCAL	IU	none	none	Interrogates the uncalibrated output error codes. The Generator responds with three octal fields: "AAAAA,BBBBB,CCCCC". See Table 2-5 for a list of uncal error codes.
Software Version	IV	none	none	Interrogate the software version. The Generator responds with the status message: "Vxx.x" where x's are decimal digits representing the current software revision level.
MEMORY ENTRY				
Recall	RC	int	none	Recall the front panel setup stored at the memory location specified by int.
Store	ST	int	none	Store the current front panel setup at the memory location specified by int.
Sequence	SQ	none	none	Sequence (recall) to the next higher memory location.
MODULATION ENTRY				
Program AM	AM	float	PC	Program AM depth in percent.
External AM	AE	0/1	none	Disable/enable external AM modulation.
Internal AM	AI	0/1	none	Disable/enable internal AM modulation.
Program FM	FM	float	GZ MZ KZ HZ	Program FM deviation in units of:  gigahertz megahertz kilohertz hertz
External FM	FE	0/1	none	Disable/enable external FM modulation.
Internal FM	FI	0/1	none	Disable/enable internal FM modulation.
Program Mod Freq	MR	0/1	none	Program modulation frequency to 400 Hz/1000 Hz.
Program	MF	float	GZ MZ KZ HZ	Program modulation frequency in units of:  gigahertz megahertz kilohertz hertz
MONITOR COMMANDS				
Input Bit	IB	none	BIT Designator	Respond with the value of the designated hardware bit.
Output Bit	OB	0/1	BIT Designator	Set the designated hardware bit to 0 or 1.

# INSTALLATION AND OPERATION

Table 2-8. IEEE-488 Commands (cont)

Output Dac	OD	int	DAC Designator	Set the value of the designated hardware DAC to the value specified by int.
Read Byte	RB	int	none	Read the value of the addressed byte. The Generator responds with an unsigned integer.
Read Word	RW	int	none	Read the value of the addressed word. The Generator responds with an unsigned integer.
Define Write Address	DW	int	none	Defines the address to be used by the write byte/word commands.
Write Byte	WB	int	none	Write int into the address specified with the define write address command.
Write Word	WW	int	none	Write int into the address specified with the define write address command.
Read Attenuation	XA	none	none	Read the current attenuation. The Generator responds with an unsigned integer.
Write Attenuation	XB	none	none	Change attenuation to 6dB times the unsigned integer. The integer can be 0 to 23.
Set Frequency Direct	XD	float	GZ MZ KZ HZ	Set the frequency hardware directly to the specified synthesizer frequency.
RF Output	XR	0/1	none	"XR0" programs all attenuation. "XR1" restores attenuation to its previous state.
RF ON/OFF ENTRY				
RF Output	R0	0/1	none	Turn RF output off/on.
SPECIAL FUNCTION ENTRY				
Special Functions	SP	00 02 03 04 07/08 09 10 11 12/13 14 15 20/21 30/31 70 71 72 80 81 82 83-86 90/91		Clears all special functions Initiates self test Display check Key check Set/reset SRQ Display S/W rev and instr ID Display IEEE-488 address Display self-test results Turn on/off display Initialize memory Latch test Disable/enable relative freq Disable/enable relative ampl Medium key repeat rate Fast key repeat rate Slow key repeat rate Enable all level correction Disable all level correction Disable attenuator correction Program alternate 24dB attens Disable/enable ampl fixed ring

Table 2-8. IEEE-488 Commands (cont)

SRQ COMMANDS				
Interrogate SRQ Mask	IM	none	none	Interrogate the SRQ mask. The Generator responds with the decimal value of the SRQ mask.
Set SRQ	SM	int	none	The SRQ mask is set to int.
Local Operation Alert Mode	XF	0/1	none	Disable/enable a mode to set SRQ each time a local entry is made. This SRQ is enabled by setting the front panel bit in the SRQ mask.
STEP ENTRY				
Program FREQ STEP Size	FS	float	GZ MZ KZ HZ	Program frequency step size in units of:  gigahertz megahertz kilohertz hertz
Program AMPL STEP Size	LS	float	V MV UV NV DB	Program amplitude step size in units of:  volts millivolts microvolts nanovolts dB or dBm
Program AM STEP Size	PS	float	PC	Program AM step size in percent.
Program FM STEP Size	DS	float	GZ MZ KZ HZ	Program FM step size in units of:  gigahertz megahertz kilohertz hertz
Step Up/Down	SU/SD	none	none	Step the currently selected step function up/down one step.
Step Up/Down Frequency	FU/FD	none	none	Change the current step function to frequency and step frequency up/down one step.
Step Up/Down Amplitude	LU/LD	none	none	Change the current step function to amplitude and step amplitude up/down one step.
Step Up/Down AM	PU/PD	none	none	Change the current step function to AM and step AM up/down one step.
Step Up/Down FM	DU/DD	none	none	Change the current step function to FM and step FM up/down one step.
TRIGGER COMMANDS				
Configure Trigger	CT	string	none	Configures the trigger. Each time a trigger command or a group execute trigger interface message is received, the Generator executes the string of commands. The string record must end with a record terminator.

Table 2-8. IEEE-488 Commands (cont)

Trigger	TR	none	none	Trigger command. Equivalent to the group execute interface message. Upon processing the trigger command, the Generator executes the string, which has been preprogrammed with the configure trigger command.
---------	----	------	------	--

## 2-37. PROGRAMMING EXAMPLE 1

Use the following procedure to program the Generator with a Fluke 1722A Instrument Controller to this state:

Frequency 210 MHz  
 Amplitude 6 dBm  
 Modulation Freq. 1000 Hz  
 FM 5 kHz  
 Internal FM ON  
 AM 15%  
 External AM ON

1. Connect the Generator to the Controller with an IEEE-488 cable.
2. Set the address switch of the Generator as follows (as viewed from the rear of the instrument):

00000010

3. Enter the following program into the Controller:

```

1  ! Fluke 1722A BASIC program to control a 6060A.
2  ! The Address of the 6060A is 2.
3  AZ = 2%
10 ! Clear the 6060A so that it is in a known state.
15 INIT PORT 0
20 REMOTE @AZ \ CLEAR @AZ
100 ! SET THE 6060A.
110 PRINT @AZ, "FR210MZ, AP6DB, MR1, FM5KZ, FI1, AM15PC, AE1"
999 END
  
```

4. Run the program by typing on the Controller "RUN <RETURN>".

## 2-38. PROGRAMMING EXAMPLE 2

The 6060A Signal Generator can be connected to an other 6060A Signal Generator in a master-slave configuration. In the following example, two Generators are configured to track each other in frequency. This configuration may be used to track frequency, amplitude, AM, or FM.

1. Connect two 6060A Signal Generators together with an IEEE-488 cable.
2. Set the rear panel address switch of the first Generator (talker) as follows:

00100000

3. Set the rear panel address switch of the second Generator (listener) as follows:

01000000

4. Manually program the talker Generator as follows:

FUNCTION	VALUE	KEY SEQUENCE
Frequency	210 MHz	[FREQ] [2] [1] [0] [MHz V]
Step Function	Frequency	[FREQ] [STEP]
Frequency Step	1.25 kHz	[1] [.] [2] [5] [kHz mV]

5. Manually program the listener Generator as follows:

FUNCTION	VALUE	KEY SEQUENCE
Frequency	195 MHz	[FREQ] [1] [9] [5] [MHz V]
Step Function	Frequency	[FREQ] [STEP]
Frequency Step	1.2 <del>4</del> kHz	[1] [.] [2] [ <del>4</del> ] [kHz mV]

6. On the talker Generator, press the [  $\uparrow$  ] STEP or [  $\downarrow$  ] STEP keys. Each time the key is pressed, the frequency of both Generators increases or decreases by 1.2~~4~~ kHz (the Frequency Step) at frequencies 15 MHz apart.

Different functions on each Generator can be programmed to track in the master-slave configuration. In other words, while the master Generator can be programmed to step increase 25 kHz FM, the Slave Generator can be programmed to step 25% AM.

#### NOTE

*To use the step function feature for other functions, change the step function on the Generators to the desired functions.*

### 2-39. PROGRAMMING EXAMPLE 3

In the following example, the Generator is programmed by a Fluke 1722A Controller (via the IEEE-488 bus) to the same state as in Programming Example 1. Additionally, the frequency step size is set to 1.2~~4~~ kHz, and the trigger buffer is programmed to execute the step up command when the trigger command is received. The SRQ mask of the Generator is set to generate an SRQ when the RF output has settled and the Generator is ready for more input from the bus.

The program then enters a loop where it waits for the ready SRQ, sends the GET (group execute trigger) interface message to step up the frequency, and waits again. At this time you should do the following:

1. Connect the Generator to the Controller with an IEEE-488 cable.
2. Set the rear panel address switch of the Generator as follows:

00000111

3. Enter the following program into the Controller:

```

1  ! Fluke 1722A BASIC program to control a 6060A.
2  ! The address of the 6060A is 7.
3  AZ = 7%
10 ! Clear the 6060A so that it is in a known state.
15 INIT PORT 0
20 REMOTE @AZ \ CLEAR @AZ
100 ! Set the 6060A.
110 PRINT @AZ, "FR210MZ,AP6DB,MR1,FM5KZ,FI1,AM15PC,AE1"
120 ! Set the frequency step, output valid mode,
121 ! and configure the trigger buffer.
130 PRINT @AZ, "FS1.24KZ,VM1,CTSU"
140 ! Set the SRQ mask to enable "output valid" SRQ
150 PRINT @AZ, "SM16"
160 ! Wait for above commands to finish processing
170 WAIT 1000 \ S% = SPL (AZ)
180 ! Trigger the first step up
190 TRIG @AZ
300 ! Wait for SRQ
310 ON SRQ GOTO 800
320 WAIT FOR SRQ
800 OFF SRQ
810 ! Check the serial poll response
820 S% = SPL(AZ)
830 IF (S% AND 64%+16%) (>) 80% THEN PRINT S%: " Bad Serial Poll Response"
840 ! Trigger the next step up
850 TRIG @AZ
860 ! Resume operation-- waiting for next SRQ
870 RESUME 300
999 END

```

4. Run the program by typing on the Controller "RUN (RETURN)".

## 2-40. Interface Functions

The Generator implements a subset of interface functions defined by the IEEE Standard 488-1978. Table 2-9 summarizes the interface functions implemented. This section describes the operation of the Generator in response to interface messages associated with each interface function.

**Table 2-9. IEEE-488 Interface Functions List**

FUNCTION	DESCRIPTION
SH1	Complete source handshake capability
AH1	Complete acceptor handshake capability
T5	Basic talker, Talk only, Serial poll, Unaddressed if MLA
TE0	No extended talker capability
L3	Basic listener, Listen only, Unaddressed if MTA
LE0	No extended listener capability
SR1	Complete service request capability
RL1	Complete remote/local capability
PPO	No parallel poll capability
DC1	Complete device clear capability
DT1	Complete device trigger capability
CO	No controller capability
E2	Tri-state drivers

## 2-41. Address Mode

In the address mode, the Generator may be operated from local (using the Front Panel keys) or from remote (using the IEEE-488 Interface). The following paragraphs describe the operation of the Generator in both states and transitions between the states.

The available IEEE-488 messages and their descriptions for the address mode of operation are presented in Table 2-10.

## 2-42. LOCAL OPERATION

The Generator powers up in the local mode. When in local mode, the following conditions are present:

The front panel indicator 'REM', is not lit.

Device trigger (GET), device clear (DCL), and selected device clear (SDC) interface messages are ignored.

All device dependent messages are ignored.

If the data output was requested while the Generator was in the remote mode, the data output of a talker may be sent.

## 2-43. GOING FROM LOCAL TO REMOTE

The Generator switches from local to remote when the "my listen address message" (MLA) is received, and the Remote Enable (REN) signal is true.



Table 2-10. IEEE-488 Address Mode Message Descriptions

MESSAGE	DESCRIPTION
<p>pon Power-On</p> <p>Talker Operation</p> <p>Listener Operation</p> <p>Service Request Operation</p> <p>MTA My Talk Address</p> <p>Talker Operation</p> <p>Listener Operation</p> <p>MLA My Listen Address</p> <p>Talker Operation</p> <p>Listener Operation</p> <p>Data</p> <p>Talker Operation</p> <p>Listener Operation</p>	<p>When powered up, the Generator generates a Power-On message (pon) and clears its output buffer. The Generator is not addressed to talk when powered up.</p> <p>The Generator is not addressed to listen when the power is turned on.</p> <p>The state of the Service Request (SRQ) signal on pon is determined by the SRQ mask. If the Non-volatile Memory option is installed, the SRQ mask is the same as when the power was removed. Therefore, if the SRQ mask enables the power on, output valid, or ready SRQs, the SRQ signal will be true during pon. If the Non-Volatile Memory option is not installed, the SRQ signal will not be true.</p> <p>The Generator is addressed to talk upon receipt of the MTA message. The front panel 'ADDR' indicator is lit while the Generator is addressed to talk.</p> <p>The Generator unlistens when the MTA message is received.</p> <p>The Generator untalks when the MLA message is received.</p> <p>The Generator is addressed to listen when the MLA message is received. The front panel 'ADDR' indicator of the Generator is lit while the Generator is addressed to listen.</p> <p>The Generator sends data to the IEEE-488 bus only when requested by a programming data message. Message formats are described in the Command Description paragraphs. An End of Record (EOR) character is sent with EOI asserted following all outputs. The EOR character is either a carriage return or a line feed, depending on the setting of the terminator mode. The parity bit is always zero. Multiple output requests are buffered until the buffer is full. Processing of programming data messages is stopped until the buffer is no longer full. The buffer can be cleared with the Clear Buffer command ("CB"). The buffer is also cleared on power up (pon), with a Clear Command ("CL"), or with a Device Clear interface message (DCL or SDC).</p> <p>Command syntax, error processing, and input buffer overflow are described in the paragraphs on Command Processing. Refer to Table 2-8 for a List of IEEE-488 commands that are recognized by the Generator.</p>

**Table 2-10. IEEE-488 Address Mode Message Descriptions (cont)**

MESSAGE	DESCRIPTION
IFC Interface Clear	
Talker Operation	The Generator untalks and unlistens when the IFC message is received.
Listener Operation	The Generator unlistens and untalks when the IFC message is received.
OTA Other Talk Address	
Talker Operation	The Generator untalks when the OTA message is received.
SPE Serial Poll Enable	
Talker Operation	After receiving the SPE message, the Generator responds with the serial poll status byte, if addressed to talk.
SPD Serial Poll Disable	
Talker Operation	After receiving the SPD message, the Generator resumes normal talk operation.
ULA Unlisten Address	
Listener Operation	The Generator unlistens when the ULA message is received.
RSV Request Service	
Service Operation	The front panel SRQ indicator is lit when the rsv message is sent. The Generator may request service for several reasons. Each reason for service request can be individually masked with the set mask command ("SM"). The service request mask can be interrogated with the interrogate mask command ("IM").
DCL Device Clear	
Clear Operation	The DCL message is ignored when in local. When the DCL message is received (during remote operation) the Generator is cleared. Any characters in the input buffer are cleared followed by the same operation as the clear command ("CL"). The operation of the DCL message is identical to the operation of the selected device clear (SDC) message. The cleared state of the Generator is described in the paragraphs on Power-On Conditions.

Table 2-10. IEEE-488 Address Mode Message Descriptions (cont)

MESSAGE	DESCRIPTION
SDC Selected Device Clear	
Clear Operation	The SDC message is ignored during local operation. When the SDC message is received (during remote operation), the Generator is cleared. Any characters in the input buffer are cleared followed by the same operation as the clear command ("CL"). The operation of the SDC message is identical to the operation of the device clear (DCL) message. The cleared state of the Generator is described in the paragraphs on Power-On Conditions.
GET Group Execute Trigger	
Trigger Operation	The GET message is ignored during local operation. When the GET message is received (during remote operation), the Generator executes a command string that has been preprogrammed with the Configure Trigger command ("CT"). The operation of the GET message is identical to the operation of the Trigger ("TR") command.
Undefined IEEE-488 Commands	All undefined IEEE-488 commands are acknowledged by the Generator handshake sequence, but no action is taken.

## 2-44. REMOTE OPERATION

When in the remote mode, the following conditions are present:

The front panel REM indicator is lit.

Device trigger (GET), device clear (DCL), and selected device clear (SDC) interface messages are processed.

All device-dependent messages are processed during the remote mode.

## 2-45. GOING FROM REMOTE TO LOCAL

The Generator switches from remote to local mode in one of the following ways: The IEEE-488 Go To Local (GTL) message is received, the remote enable signal REN is false, or a Return To Local (RTL) message is generated by pressing the front panel [CLR|LCL] key (if the Generator is not in the local lockout mode).

The Generator enters the local lockout mode when the Local Lockout message (LLO) is received. The Generator exits the local lockout mode to the local mode when REN is false.

When switching from remote to local, unprocessed commands in the input buffer are processed until the input buffer is cleared or a front panel entry is made. Switching to local has no effect on the contents of the output buffer.

## 2-46. Talk-Only Mode

Figure 2-6 shows two 6060A connected together with the IEEE-488 Bus.




Figure 2-6. 6060A IEEE-488 Bus Connected to a 6060A IEEE-488 Bus

To select the talk-only mode, set the TALK ONLY address switch to 1 (up). If the talk-only address switch and the listen-only address switch are set to 1, the talk-only mode is selected.

In the talk-only mode, the listener, remote/local, service request, device clear, and device trigger interface functions do not apply.

If the talk-only mode is selected, the Generator is always addressed to talk and the front panel 'ADDR' indicator is always lit. The Step Up ("SU") or Step Down ("SD") message is sent when the [ + ] STEP or [ - ] STEP front panel keys are pressed. This output is not buffered and if no listener is connected to the IEEE-488 Interface, no output will be sent. A carriage return followed by line feed (with the EOI signal true) are always sent as the end of record.

### 2-47. Listen-Only Mode

To select the listen-only mode, set the LISTEN ONLY address switch to 1 (up). If the talk-only address switch and the listen-only address switch are set to 1, the talk-only mode is selected.

If the listen-only mode is selected, the Generator is always addressed to listen, and the front panel 'ADDR' indicator is always lit. The Generator listens and responds to all data messages on the IEEE-488 Interface. The response to data messages is the same as in the addressed mode of operation except that requests for talker output are ignored.

In the listen-only mode, the talker, remote/local, service request, device clear, and device trigger interface functions do not apply.

### 2-48. Command Syntax

The Generator IEEE-488 bus commands alphabet consists of the letters A through Z (upper and lower case letters are treated equally), digits 0 through 9, and the following special characters:

@ . , ; + - CR LF

Spaces, tabs characters, and the parity bit are ignored.

The IEEE-488 commands for the Generator consist of the following three parts:

Header  
Numeric  
Suffix

The header is always required, but the numeric and suffix may be optional. This rule gives the following four possible combinations:

<HEADER>  
 <HEADER> <NUMERIC>  
 <HEADER> <NUMERIC> SUFFIX  
 <HEADER> <SUFFIX>

Multiple commands may be separated with one of the end of string (EOS) characters “,” or “;”. Use of EOS characters facilitates recovery in the event of a syntax error and will also enhance readability.

## 2-49. COMMAND HEADER SYNTAX


The command header is a two alpha-character string. A list of the IEEE-488 command headers used on the Generator is presented in Table 2-8. The header determines the syntax of the numeric and suffix as listed in the table.

## 2-50. NUMERIC DATA SYNTAX

There are four types of numeric data: Boolean, unsigned integer, floating point, and trigger string. The following paragraphs describes each of the four numeric data formats. A syntax diagram is included for each format.


### 1. Boolean

Boolean numeric data must be either a “0” or a “1”. All other characters will result in a syntax error.




### 2. Unsigned Integer

Unsigned integers may be specified in decimal or in hexadecimal. Any number of decimal digits are accepted. However, values greater than 65,535 are rejected. Hexadecimal numbers are preceded by an “X”. Only 4 hexadecimal digits are accepted. Specifying a number in hexadecimal for the read word and read byte commands causes the response to be sent in hexadecimal. Decimal digits may be the numerals 0 through 9. Hexadecimal digits may be the hexadecimal digits 0 through F.



## 3. Floating Point

The floating-point numeric data format is the most flexible format. Digits may be the numerals 0 through 9. Any number of digits are accepted for both the number and the exponent. However, numbers greater than 2,147,483,629 are truncated, and exponents greater than 32,749 are rejected.




## 4. Trigger String

The trigger string numeric data is a string of Generator commands terminated with an EOR. The string may be up to 71 characters not including the EOR. Commands in the string are not checked for validity until the trigger string is executed with the trigger command.

EOR is the end of record character. This character is selectable with the terminator mode command. TM0 selects the linefeed character. TM1 selects the carriage return character. The IEEE-488 interface signal EOI asserted with any other character is also considered an end of record.

EOS is an end of string character, use either “;” or “,”.



## 2-51. SUFFIX SYNTAX

Suffixes are always one or two alpha-characters. Certain suffixes are used to scale the numeric (the same as the front panel UNITS keys). Other suffixes mnemonically designate hardware components. The five types of suffixes are described in Table 2-11.

## 2-52. Command Descriptions

The following paragraphs describe the remote IEEE-488 Interface operating commands that are not accessible from the front panel of the Generator. IEEE-488 Interface commands that are accessible from the front panel of the Generator are described earlier in this section.

Table 2-11. Suffix Types

SUFFIX TYPE	SUFFIX	MNEMONIC	EQUIVALENT EXPONENT
Frequency and FM	GZ	gigahertz	9
	MZ	megahertz	6
	KZ	kilohertz	3
	HZ	hertz	0
Amplitude	V	volts	0
	MV	millivolts	-3
	UV	microvolts	-6
	NV	nanovolts	-9
	DB	dBm or dB	0
AM	PC	percent	0
DAC/BIT Designators	DAC and BIT designators are two alpha-character mnemonics that refer to hardware dacs and bits. Refer to the paragraphs on Monitor Commands for a complete list of designators.		
Learn Suffix	A learn suffix is a string of ASCII characters that contain coded memory location contents. Refer to the paragraphs on Binary Learn Commands for decoding of the learn string.		

## 2-53. BINARY LEARN COMMANDS

Front panel setups are stored in the memory of the Generator in a packed binary format. The binary learn commands are used to transfer this binary data between an IEEE-488 controller and the Generator. These commands allow you to minimize the amount of programming commands needed to program the entire instrument state. The binary learn commands are:

- “LM” Learn Memory
- “LI” Learn Interface

The syntax for the Learn Memory (“LM”) command is as follows:

“LM” Memory Location Code

The Generator responds to the “LM” command with a string of 64 ASCII characters followed by an  $\langle \text{EOR} \rangle$  (end of record character). This string represents the front panel settings (in a packed binary format) that were stored in the memory location specified.

### NOTE

*The  $\langle \text{EOR} \rangle$ , end of record character, is sent with EOI asserted. “TM0” selects the linefeed character, and “TM1” selects the carriage return character.*

### Example

IEEE-488 Command: "LM98"

Response:

"BOABAAAAPPJMAAAKAAAAAAAAABBOBKKAAPCEAA  
BPEAAABDAEEBBAGBLKKMPAC"<EOR>

Refer to Figure 2-7 for information on how to decode this learn string.

The syntax for the Learn Interface "LI" Command is as follows:

"LI" Memory Location Code: Learn String

The Generator stores the learn string in the memory location designated by the memory location code. If the memory location specified is 99, the instrument is programmed to the data sent in the learn string.

### Example

To program the Generator to the Instrument Preset State:

"LI99BOABAAAAPPJMAAAKAAAAAAAAABBOBKKAAPCEAAABPE  
AAABDAEEBBAGBLKKMPAC"

Note that the binary learn string in this example is the same as the learn string returned from memory location 98 which contains a record of the Instrument Preset State.

Instructions:

1. Convert the hexadecimal number to a signed decimal number as follows:
  - a. Multiply the most significant hexadecimal digit by 16.
  - b. Add the next significant digit to the value obtained in Step a.
  - c. Multiply the sum of Step b by 16, and add in the next hexadecimal digit until the least significant hexadecimal digit has been added.

### NOTE

*If the hexadecimal number started with an 8 through F, the number is negative.  
Perform Step d for negative numbers.*

- d. Subtract, 16 from the number raised to the power of the number of digits.

Example of Instruction 1:

To convert hexadecimal number 1E:

$$(1 * 16) + 14 = 30$$

(Since the most significant digit is 1, the number is not negative.)






Figure 2-7. Learn String Example




Figure 2-7. Learn String Example (cont)




Figure 2-7. Learn String Example (cont)




Figure 2-7. Learn String Example (cont)




Figure 2-7. Learn String Example (cont)

To convert hexadecimal number FF9C:

$$((((15 * 16) + 15) * 16) + 9) * 16 + 12 = 65436$$

(Since the most significant digit is F, the number is negative.)

Using Step d;  $16^4 = 65536$ ,  $65436 - 65536 = -100$ . The signed decimal equivalent to FF9C is -100.

2. Amplitude quantities have a number and a resolution associated with them. This applies to the Displayed Amplitude, Reference Amplitude, and Amplitude Step.

Use the following procedure to identify the resolution of an amplitude quantity:

- a. If the resolution is A or B (hexadecimal), the resolution of the number is 0.1 dBm or 0.1 dB units.

Example:

The Displayed Amplitude (in this figure) is -100 with a resolution of

- a. The actual displayed amplitude is -10.0 dBm.
- b. If the stored resolution is 0 through 9 (hexadecimal), the amplitude quantity is in volts. To convert the number to the actual amplitude in nanovolts, multiply the amplitude number by the power of ten represented by the resolution.

Example: An Amplitude Step of 12, with a resolution of 6 would be an actual amplitude step of 12,000,000 nV or 12 mV.

3. If the Relative Amplitude mode is off, the data stored in the reference amplitude location is not used.
4. If the Relative Frequency mode is off, the data stored in the reference frequency location is not used.
5. FM and FM Step quantities have a number and a resolution associated with them. To convert the number to the FM quantity in Hz, multiply the number by the power of ten represented by the resolution. If the Low-Rate FM option is installed, the FM quantity, adjusted by the resolution, has a resolution of 0.1 Hz.

Example: The FM number (in this figure) is 500, with a resolution of 10 Hz. The actual FM deviation is 5000 Hz.

6. The checksum data is calculated by adding the data in the learn string, two hexadecimal digits at a time. The total, including the checksum, should add up to a number whose least significant two hexadecimal digits are 01.

### NOTE

*The memory location code must be an unsigned integer indicating the memory location to be learned. Memory location 99 refers to the current instrument settings. Memory location 98 refers to the Instrument Preset State as listed in Table 2-3.*

The characters in the learn string correspond to each Generator function. A description of how to interpret the characters in the learn string is given in Figure 2-7. Table 2-12 shows the conversion from the learn string to the hexadecimal character.

**Table 2-12. Learn Character to Hexadecimal Conversion**

LEARN CHARACTER	HEXADECIMAL EQUIVALENT	DECIMAL EQUIVALENT
A	0	0
B	1	1
C	2	2
D	3	3
E	4	4
F	5	5
G	6	6
H	7	7
I	8	8
J	9	9
K	A	10
L	B	11
M	C	12
N	D	13
O	E	14
P	F	15

## 2-54. CLEAR COMMANDS

The following IEEE-488 clear commands are recognized by the Generator:

- “CB” Clear IEEE-488 input buffer
- “CE” Clear IEEE-488 rejected entry error status
- “CL” Clear instrument

The “CB” command can be used to clear the Generator output buffer. The output buffer is also cleared on power up, with the “CL” clear Generator command, or by the SDC and DCL clear interface messages.

The “CE” command can be used to explicitly clear the error status. The error status is also cleared when it is interrogated with the “IR” command, or the “CL” clear Generator command, or the SDC and DCL clear.

The “CL” command is used to clear the instrument state. The same actions are performed with the SDC and DCL clear interface messages. (In addition, the input buffer is cleared with the clear interface messages.) The following IEEE-488 commands are performed with the clear Generator command: “RC98, RO1, CE, CB, RM0, TM0, EM0, VM0, UM0, SM192, SP08, XF0, DW0, CT”<EOR>.

## 2-55. INTERFACE MODE COMMANDS

Interface Mode commands are used to configure the Generator for different modes of IEEE-488 interface operation. Since the Generator knows when its RF output has settled, it can be configured to synchronize itself with the Controller. This eliminates WAIT statements in the program, which are normally used to allow time for the output of the controlled device to settle. Table 2-13 lists the Interface Mode Commands.

**Table 2-13. Interface Mode Commands**

COMMAND	DESCRIPTION	COMMAND STATUS
"EM"	Error Mode	1 = on, 0 = off
"RM"	Record Mode	1 = on, 0 = off
"TM"	Select Terminator	1 = CR, 0 = LF
"UM"	Unbuffered Mode	1 = on, 0 = off
"VM"	Valid Mode	1 = on, 0 = off

The error mode selects when the IEEE-488 rejected entry status is cleared. If turned on, the error status is cleared when a new message is processed. If turned off, the status is cleared only when interrogated with the "IR" (interrogate rejected entry) command or when explicitly cleared with the "CE" (clear error command).

The record mode selects whether the message unit is a record or a command. When turned on, the message unit is a record. When turned off, the message unit is a command.

The terminator mode selects the character used as the record terminator. The terminator character is not used for command processing unless the record mode is enabled. When turned on, the record terminator CR (carriage return) is used. If turned off, the record terminator LF (line feed) is used. The record terminator character is the last character in all IEEE-488 messages sent from the Generator.

The unbuffered mode selects when messages from the IEEE-488 interface are processed. When turned on, messages are read from the IEEE-488 interface only when the microprocessor is ready to process them. In this mode, the input buffer will contain a maximum of one message. (A message may be one command or one record, depending on the setting of the record mode.) When turned off, messages are read from the IEEE-488 interface to the input buffer of the Generator at the fastest rate. In this mode, the input buffer may contain up to 80 characters.

The valid mode selects when messages are processed by the Generator microprocessor. When turned on, processing of a new message is begun only after the RF output has settled and become valid. When turned off, a new message is processed immediately after the completion of the previous message.

The interface modes can also be programmed using the command, "@n" (where n is an integer). The interface modes are set to the value of n where n is the sum of the codes for the desired modes. The integer codes for the interface modes that can be programmed using the "@n" commands are as follows:

Terminator Mode	= 1
Record Mode	= 2
Valid Mode	= 4
Unbuffered Mode	= 8
Error Mode	= 16

For example, to select the record mode and valid mode, the command is "@6".

## Interface Mode Example

In this example, the RF output of Generator is connected to a circuit that is being measured by a voltmeter. The output of the Generator must be settled before the voltmeter is given its command to make a measurement.



A Fluke 1722A program might look something like:

```
PRINT @1, "CL, TM1, RM1, VM1, UM1" : initialize the 6060, select modes
PRINT @1, "FR100MZ, AP-25DB"      : program the 6060
PRINT @2, "?"                      : trigger the voltmeter
INPUT @2, R#4                      : get the reading
```

The entire record is transferred into the Generator before processing begins. In this example, processing begins when the record terminator CR is received. The following character (LF in this case) will not be received into the Generator until the entire record is processed and the output has settled. No wait statement is needed between setting up the Generator and taking the measurement because the Generator will not handshake the LF character until its output has settled.

#### NOTE

*A record is a string of characters separated by <EOR>. A message is the smallest group of characters that the Generator can process when programmed from the IEEE-488 interface.*

#### NOTE

*The output valid state of the Generator occurs 45 ms after any hardware has been changed.*

## 2-56. INTERROGATE COMMANDS

Interrogate commands allow the status of the Generator to be given over the IEEE-488 interface. These commands consist of headers only. The interrogate commands available on the IEEE-488 interface are:

- "ID" Give Instrument ID
- "IE" Elapsed Time Indicator
- "II" Interface Mode Status
- "IO" Option Loading
- "IR" IEEE-488 Rejected Entry Status
- "IT" Self-Test Results
- "IU" UNCAL (uncalibrated) Status
- "IV" Software Revision Level

When the "ID" command is sent, the Generator responds with its instrument model number (and end of record character) as in "6060A"<EOR>.

The "IE" elapsed time indicator command works only on Generators with the Non-Volatile Memory Option. When the "IE" command is sent, the Generator responds with a 10-digit integer followed by the <EOR> character. The 10-digit integer indicates the time the instrument has been in operation since it was manufactured. To convert the time into minutes, multiply the integer by 0.67.

The "II" command interrogates the current selection of interface modes. A 5-digit integer followed by the <EOR> character is the sum of the modes selected as follows:

- Terminator mode= 1
- Record mode = 2
- Valid mode = 4
- Unbuffered mode= 8
- Error Mode = 16

The "IO" command interrogates the Generator for its option complement. The returned record contains three integers, separated by commas, that indicates configuration of options. For the 6060A, the first number is always 3, which indicates that the Generator being interrogated is in fact a 6060A. The two remaining numbers are the sum of the option related numbers as follows:

### 2nd Number

- 1 = -570 Non-Volatile Memory Option
- 2 = -131 Sub-Harmonic Reference Option
- 4 = -130 High-Stability Reference Option
- 8 = -651 Low-Rate FM Option

### 3rd Number

- 1 = -870 RPP Option
- 2 = -830 Rear Output Option

For example, 352 would indicate a 6060A with options -570, -131, and -830.

The "IR" command interrogates the Generator for rejected entry error status. (See Table 2-6 for a list of rejected entry codes.) The returned record is the sum of errors that have been detected while processing IEEE-488 commands. The status is cleared when interrogated with the "IR" command. The status can also be explicitly cleared with the "CE" command and is also cleared on the "CL" command and the clear interface messages DCL and SDC.

The "IT" command interrogates the Generator for the self-test results. Table 2-14. lists the self-test error codes. The self tests are performed on the Generator power-up and can also be initiated with special function 02.

The self-test results are reported in four fields which are explained in the table. Any non-zero code indicates that some tests failed. Further details of the self-test results are listed in the Service Section. Table 2-14. shows the self-test error codes.

The "IU" command interrogates the Generator for the UNCAL entry status. (See Table 2-5 for a list of the UNCAL Error Codes.)

The "IV" command interrogates the Generator for its current software revision level. The returned record is similar to the following:

"V1.0" <EOR>.

This means that the software revision level is Version 1.0.

**Table 2-14. Self-Test Error Codes**

MOD	FREQ	AMPL
aaa	-bbb ccc	ddd
aaa = Modulation (AM and FM) test results		
- = If displayed, indicates the self test did not complete		
bbb = Frequency test results		
ccc = Digital test results		
ddd = Amplitude test results		

## 2-57. MONITOR COMMANDS

The Generator monitor commands are intended for troubleshooting and maintenance procedures. They allow the instrument hardware to be programmed to states not normally possible with the regular programming commands.

### CAUTION

**The output of the Generator is not guaranteed if the Generator hardware has been changed with these monitor commands.**

There are three types of monitor commands: Input/Output, Read/Write, and Hardware Control. Table 2-15 lists the Input/Output types of monitor commands. Table 2-16 lists the Read/Write types of monitor commands. Table 2-17 lists the Hardware Control types of monitor commands.

## 2-58. SRQ COMMANDS

The Generator asserts the SRQ bus management line on the IEEE-488 interface bus whenever the Generator requires service. The Controller can then perform a serial poll to determine the need for service. The set mask command is used to designate those needs that require service. The SRQ commands are as follows:

- “SM” Set SRQ Mask
- “IM” Interrogate SRQ Mask
- “XF” Local Operation Alert Mode

The SRQ mask is set to the sum of the reason values listed in Table 2-18. These reason values correspond to the allowable reasons that will be requiring service. The SRQ Mask is set by the following command sequence:

“SM” Sum of Reasons

The Generator asserts SRQ when one of the allowed reasons becomes true. The serial poll response is the sum of those values for reasons that are currently true, independent of the setting of the SRQ mask. For example, if the rejected entry SRQ is enabled with “SM2” and a rejected entry occurs, the serial poll response will indicate that the Generator generated the SRQ (value of 64) and that a rejected entry occurred (value of 2). In addition, other values may be set. The default SRQ mask is 192.

The “IM” command interrogates the current SRQ mask, and an integer is returned.

The “XF” command enables a mode that causes an SRQ to be generated any time the Generator processes an entry. In this mode, a front panel SRQ is generated (i.e., the serial poll response indicates that a front panel SRQ is the cause of the SRQ). This mode is enabled and disabled with its own command, not through the Set SRQ Mask commands (as are all other SRQs). The Alert Mode is enabled/disabled as follows:

“XF0” = Alert Mode off, “XF1” = Alert Mode on.

## 2-59. TRIGGER COMMANDS

The Generator has the ability to preprogram a command string of arbitrary Generator programming commands. This command string is executed whenever the trigger command “TR” or the IEEE-488 group execute trigger interface message (GET) is received. This method of programming the Generator can be used when a long string of commands is to be sent to the Generator over and over. The programming time is shortened by the time required to transmit the string of characters from the controller to the Generator.

Table 2-15. Input/Output Monitor Commands

COMMAND NAME	COMMAND	VALUE	DESIGNATOR	NAME	LOCATION
Read Input Bit	"IB"		"EX"	exrefl	A2A7, U11-13
			"HS"	hsoptl	A2A7, U11-14
			"IE"	ieinl	A2A7, U11-7
			"LF"	lrfm	A2A7, U40-13
			"MH"	mlevhi	A2A7, U40-8
			"ML"	mlevlo	A2A7, U40-3
			"NV"	nvinl	A2A7, U11-8
			"RO"	roptl	A2A7, U40-17
			"RP"	rppl	A2A7, U11-3
			"RT"	rptrpl	A2A7, U11-4
			"SR"	shrefl	A2A7, U40-18
			"TQ"	trseql	A2A7, U40-4
			"UK"	unlok	A2A7, U11-17
			"UV"	unlvl	A2A7, U11-18
			"XA"	extra-a	A2A7, U40-14
			"XB"	extra-b	A2A7, U40-7
Set Output Bit	"OB"	0 or 1	"CL"	clr	A2A7, U17-16
			"EA"	extam	A2A4, U308-19
			"EF"	extfm	A2A4, U308-16
			"FE"	fmen	A2A1, U19-19
			"FP"	front-panel	A2A7, U17-9
			"HO"	haocth	A2A4, U305-5
			"HT"	het	A2A4, U305-9
			"IA"	intam	A2A4, U308-15
			"IF"	intfm	A2A4, U308-12
			"LP"	mid	A2A4, U305-6
			"MA"	rmux0	A2A1, U32-5
			"MB"	rmux1	A2A1, U32-2
			"MF"	mf400l	A2A4, U308-9
			"MG"	module-gate	A2A7, U17-6
			"MS"	trmodl	A2A1, U32-15
			"NE"	nven	A2A7, U17-5
			"PU"	pulse	A2A4, U308-6
			"RI"	rinl	A2A1, U32-9
			"RR"	rprst	A2A7, U17-2
			"SE"	shen	A2A1, U32-12
			"SH"	shet	A2A1, U32-16
			"TO"	tbout	A2A4, U305-2
			"TS"	tbsyn	A2A1, U32-19
			"XO"	xoenl	A2A1, U32-6
			"YA"	extra-a	A2A7, U17-19
			"YB"	extra-b	A2A7, U17-15
			"YC"	extra-c	A2A7, U17-12
Set Output DAC	"OD" (integer value)	(DAC Location)			
		0-255	"AM"	AM dac	n.a.
		0-127	"AT"	attenuator	A2A7, U27-5, 6, 9, 12, 15, 16, 19
		0-1023	"FM"	FM dac	A2A4, U403-6 through 13
		0-7	"FR"	FM range	A2A1, U19-12, 15, 16
		0-1023	"KN"	kn dac	A2A1, U27-4 through 13
		0-1023	"KV"	kv dac	A2A1, U29-4 through 13
		0-4095	"LE"	level dac	A2A4, U303-4 through 15
		0-255	"TC"	temp.comp.dac	n.a.

Table 2-16. Read/Write Monitor Commands

COMMAND NAME	COMMAND SYNTAX	NOTES
Read byte	"RB" memory location	1
Read word	"RW" memory location	1
Define write address	"DW" memory location	2
Write byte	"WB" value	2
Write word	"WW" value	2
<p>Notes</p> <ol style="list-style-type: none"> <li>1. The Generator responds to these commands with the value of the byte or word in the memory location addressed. The memory location must be an unsigned integer. The value returned is followed by an &lt;EOR&gt;. If the memory location is specified in hexadecimal, then the value is returned in hexadecimal preceded by an "X".</li> <li>2. The Define Write Address command specifies the write address used with the Write Byte and Write Word commands. When the Write Byte and Write Word commands are used, the specified data will be written to that write address.</li> </ol>		

Table 2-17. Hardware Control Monitor Commands

COMMAND NAME	COMMAND SYNTAX	NOTES
Read attenuation	"XA"	1
Set attenuation	"XB" integer	1
Set synthesizer frequency	"XD" floating point decimal "MZ"	2
RF on/off	"XR" "0" or "1"	3
<p>Notes</p> <ol style="list-style-type: none"> <li>1. The current settings of the Attenuator can be read or set. The attenuation is a number from 0 to 23 where the number specifies the multiple of 6-dB attenuation. Zero indicates no attenuation, and 23 is the maximum attenuation. Only the attenuators are changed with the "XB" command. The value of the attenuation will be output on the "XA" command as an unsigned integer followed by &lt;EOR&gt;.</li> <li>2. The "XD" command can be used to program the Generator to the specified frequency. Only the synthesizer circuits on the Synthesizer PCB is programmed. No offset is added, no filters are programmed, no VCO compensation is calculated, and no level correction is calculated.</li> <li>3. "XR0" programs all attenuation, and "XR1" restores the attenuator to its previous state.</li> </ol>		

The trigger commands are as follows:

- "CT" Configure Trigger
- "TR" Execute Trigger Buffer

The configure trigger command is followed by a string of any Generator programming commands up to 71 characters in length. The validity of the programming commands is not checked until the trigger buffer is executed. The power-on value of the trigger string is null (nothing).

**Table 2-18. SRQ Mask and Status Values**

VALUE	REASON	TRUE	FALSE
1	Ready	Input buffer is empty and no commands are being processed.	Input buffer is not empty or commands are being processed.
2	Rejected Entry	IEEE-488 rejected entry; error code is not zero.	IEEE-488 rejected entry error; code is zero.
4	Uncalibrated	RF output is <del>not</del> <sup>not</sup> calibrated. (Front panel 'UNCAL' indicator is <del>not</del> lit.)	RF output is <del>not</del> <sup>not</sup> calibrated. (Front panel 'UNCAL' indicator is <del>not</del> <sup>not</sup> lit.)
8	Power on	Instrument has powered up.	Special function 08.
16	Output valid	RF output is settled.	RF output is not settled.
32	Not Used		
64	RQS	SRQ mask ANDed with currently set values is not zero.	Reason for SRQ goes away or serial poll is performed.
128	Front panel	Special function 07.	Special function 08.

The trigger command causes execution of the trigger buffer, which has been preprogrammed with the configure trigger command "CT". The trigger buffer can also be executed by sending the IEEE-488 group execute trigger interface message (GET).

## 2-60. Command Processing

The following paragraphs describe how IEEE-488 commands are processed by the Generator. Command processing is a term for how commands are executed and how errors are handled.

## 2-61. COMMAND EXECUTION

The execution of the IEEE-488 commands depends on the selection of interface modes with one exception: if an IEEE-488 input is buffered and the buffer becomes full, command execution starts and no further input is accepted until there is room in the input buffer. For more details, refer to the paragraphs on Interface Modes.

## 2-62. ERROR HANDLING

The Generator detects two types of errors while processing IEEE-488 commands: syntax errors and processing errors. All errors are accumulated until the error status is interrogated or is explicitly cleared. The IEEE-488 rejected entry status is interrogated with the "IR" command. The error status is cleared with one of the following commands:

- "CE" Clear Error Command
- "CL" Clear Command
- DCL or SDC Clear Interface Messages

The error status is also cleared on power-up.

The SRQ mask can be set to assert SRQ when an error is detected. The SRQ is unasserted when the error status is cleared.

Syntax errors are commands that do not have the correct syntax for the specified header. For example, "FE5" is a syntax error because the external FM command requires a Boolean numeric field. Unrecognized headers are also syntax errors. An IEEE-488 syntax error causes all commands from the point of the error up to the next string terminator or record terminator to be ignored.

Processing errors are commands that are syntactically valid, but the requested value is outside the range of programmable values. For example, "FR99GZ" is syntactically correct, but the Generator cannot be programmed to a frequency of 99 gigahertz. Command processing continues with the next command.

## 2-63. Timing Data

The programming time can be broken down into four groups: transfer of commands to Generator, command parsing time, software programming time, and instrument settling time.

The total programming time depends on the selection of the interface modes. In some modes, programming steps are performed in parallel and can increase throughput. This section gives some typical timing data for the above four programming steps and describes how the interface modes affect their relative timing.

## 2-64. TRANSFER OF COMMANDS TO GENERATOR

The maximum rate of transfer is 0.4 to 0.5 ms per character. With most IEEE-488 controllers, all characters sent with a single output or print statement is transferred together at the maximum rate. The total time to transfer commands to the Generator is obtained by multiplying the number of characters by the rate of transfer.

## 2-65. COMMAND-PARSING TIME

Command-parsing time is the sum of the time required to process the header, the numeric, and the suffix. Some commands do not have numerics or suffixes. Table 2-19 gives the typical time it takes to process the different components of a command.

## 2-66. SOFTWARE PROGRAMMING TIME

The minimum time required to process a command is 20 ms. Most of the commands that do not program the hardware (such as storing step values) are programmed in 20 ms. Table 2-20 gives the typical time value for programming the different functions in the Generator.

## 2-67. INSTRUMENT-SETTLING TIME

Commands that do not change the state of the hardware (such as programming step values) have no settling time after the software-processing time.

For all other Generator parameters, except frequency and recall, the instrument has settled by the time the software-programming time is up, so no additional instrument-settling time is required.

Worst case frequency changes (including recalls) typically settle within 35 ms after the software-programming time. If level correction is disabled, this settling time is increased to 45 ms. Small frequency changes (not crossing a band) typically settle by the time the software-programming time is up, so no additional instrument-settling time is required.

**Table 2-19. Command-Parsing Time**

COMMAND COMPONENT	TIME
Header	2 ms
Boolean Numeric	1 ms
Unsigned Integer Numeric	2 ms + 1 ms per character
Floating-Point Numeric	2 ms + 1 ms per character
Trigger-String Numeric	10 ms + 0.5 ms per character
Suffix	1 to 1.5 ms
Learn-Interface Suffix	35 ms

**Table 2-20. Typical Programming Time of the Generator Functions**

FUNCTION	TIME (IN ms)	NOTES
Frequency	55	1, 2, 3, 4
Amplitude in Volts	50	1, 2, 4, 5
Amplitude in dBm	90	1, 2, 4, 5
AM Depth	45	2, 4
FM Deviation	30	4
Modulation Frequency	25	
Enable/Disable AM	55	2
Enable/Disable FM	25	
Recall 98	185	6, 5
RF Output On	45	2
RF Output Off	30	
<b>Notes</b> <ol style="list-style-type: none"> <li>1. May take up to 5 ms longer if the relative mode is enabled.</li> <li>2. Can save 10 ms if all level correction is disabled with special function 81.</li> <li>3. Add 20 ms when frequency changes from greater than or equal to 245 MHz to less than 245 MHz. Subtract 20 ms from frequency hardware-settling time in this case.</li> <li>4. Edits and steps may take up to 5 ms longer than the programming function directly.</li> <li>5. Add 45 ms when the Attenuator settings change.</li> <li>6. Recalls vary considerably depending on the stored data. Maximum is approximately 250 ms.</li> </ol>		

## 2-68. TIMING OPTIMIZATION

Timing depends upon the interface modes selected. Read the paragraphs on Interface Mode Commands for a complete description of the interface modes.

The transfer of commands from the IEEE-488 controller to the Generator can never be processed in parallel with anything else. The transfer of commands usually happens simultaneously, regardless of which interface mode is selected.

The parsing of the command and programming the new instrument state is performed one message unit at a time. The record mode selects a command or a record as the



message unit. The record mode off ("RM0") is slower since there is extra processing between message units, and the message unit is smaller.

If the valid mode is enabled, the processing of message units is delayed until the Generator has settled from the previous message. If the output of the Generator does not need to be settled between programming strings, the valid mode should be turned off to speed up processing. If the output does not need to be settled between commands, but needs to be settled between records, enable the valid mode and the record mode. The instrument processes commands within the record as fast as possible and wait for the output to settle only between records.

## 2-69. Power-on Conditions

The power-on conditions of the Generator depend on whether or not the IEEE-488 Interface Option is installed. The power-on state also depends on whether or not the Option-570 Non-Volatile Memory is installed. Table 2-21 lists the instrument parameters at power-on with the IEEE-488 Option installed, and with and without the Non-Volatile Memory Option. The remote clear commands can be used to reset all parameters except the last memory location and the remote/local state.

Table 2-21. IEEE-488 Power-On State

INSTRUMENT PARAMETER	WITHOUT OPTION -570	WITH OPTION -570	NOTES
Memory location parameters	98	same as power off	1
RF on/off	on	same as power off	
Last memory location	0	same as power off	2
Remote/local state	local	local	
IEEE output buffer	cleared	cleared	
IEEE input buffer	cleared	cleared	
Valid mode	off	same as power off	
Record terminator	LF	same as power off	
Unbuffered mode	off	same as power off	
Record mode	off	same as power off	
SRQ mask	192	same as power off	
Trigger configuration	cleared	same as power off	
SRQ interface signal	unasserted	may be asserted	3
<b>Notes</b>  1. The contents of memory location 98 (Instrument Preset State) is listed in Table 2-3.  2. The last memory location is used for sequence operations.  3. If the SRQ mask has the power on, output valid, or ready SRQ enabled, the SRQ interface signal is asserted on power-on.			



## **Section 3**

# **Theory of Operation**

### **3-1. INTRODUCTION**

This section of the manual describes the theory of operation for the Generator. There are four major headings:

- General Description
- Functional Description
- Software Operation
- Detailed Circuit Descriptions

The General Description briefly explains the functions and components of the three major modules of the Generator. The Functional Description covers the main output parameters, amplitude, frequency, and modulation. The Software Operation section describes the software and how it affects the hardware. The Circuit Description is a comprehensive explanation of the operation of each circuit assembly.

### **3-2. GENERAL DESCRIPTION**

The Generator has three major sections. The front section includes the keyboard and display for local control. The module section includes the frequency, level, modulation, and control circuits. The rear section includes the power supply, cooling fan, and assorted external connectors.

### **3-3. Front Section**

The front section of the Generator provides the operator interface. It includes the primary controls, connectors, and indicators of the Generator. All front panel keys and displays (except the power switch that controls the power supply directly) are monitored and handled by the Controller in the module section.

### **3-4. Module Section**

The module section is a multi-compartmented, shielded enclosure that includes the circuits that generate the instrument stimulus functions: frequency, modulation, and amplitude. The Controller (which is not shielded) is also located here. The Controller governs the Generator operation and at power-on determines if any options are installed by checking the option status bits. The optional Sub-Harmonic Reference, Low-Rate FM, and Non-Volatile Memory are also located in this section of the instrument.

### **3-5. Rear Section**

The rear section includes the power supply, the cooling fan, various external connectors, the IEEE-488 Interface and the High-Stability Reference Options.

The power supply is a linear design providing two +15V, -15V, +5V, +37V, +18V, and 6V ac to the Generator. All the power supplies are series-pass regulated except the 6V ac filament supply and the +18V supply, which provides power to the Attenuator relays and optional Reverse Power Protector (RPP) relays. A fuse/filter/line-voltage selector allows the Generator to operate from any common supply voltage.

The ac fan is powered from a 120-volt winding on the power supply transformer regardless of the position of the line voltage selector. The fan operates only when line power is available and the front panel POWER switch is ON.

The Option -130 High-Stability Reference operates whenever the instrument is plugged into an active ac outlet, regardless of the position of the instrument POWER switch.

### **3-6. FUNCTIONAL DESCRIPTION**

The following paragraphs describe the key output parameters of the Generator: level, amplitude modulation, frequency, and frequency modulation.

#### **3-7. Level**

Level control is provided by two separate circuits, a step attenuator and a vernier level DAC. The 6.02 dB per step Attenuator (A2A6 or optional Attenuator/RPP, A2A5) provides coarse control. Fine level control is provided by a vernier level DAC that varies the automatic level control voltage (ALC). The microprocessor automatically controls the step attenuator and the vernier level DAC. The microprocessor also applies level correction to compensate for the Generator frequency response.

Each Generator has level correction data for the Output and Attenuator assemblies, stored in the Output and Attenuator calibration EPROMs. The EPROMs are located on the Controller assembly. The correction data is based on measurements of each assembly during calibration of the Generator at the factory.

This microprocessor level correction data is applied only to the vernier level DAC; it does not affect the coarse level control provided by the Attenuator. In other words, all Generators have the same attenuator pads inserted at a selected level even though the correction data is different for each Generator.

To improve level accuracy in relation to temperature, the Generator uses a software temperature compensation technique. This technique uses data that is the same for all Generators regardless of the options installed.

#### **3-8. Amplitude Modulation**

The output of the level DAC is the ALC loop control voltage. The Generator output signal is amplitude modulated by varying this control voltage with the modulating signal. A 1V peak modulating signal from the internal modulation oscillator or from the external MOD INPUT connector is applied to the AM DAC, a multiplying D-to-A Converter. The multiplying factor of this DAC, corresponding to the programmed percentage of modulation, is factored by the Controller.

The modulation signal from the AM DAC is summed with a fixed dc reference voltage. The composite signal (dc plus modulation) is applied to the LEVEL DAC, a level control-multiplying DAC. The multiplying factor for this DAC is also handled by the Controller and corresponds to the programmed signal level. The multiplying factor also includes the level correction information stored in the calibration EPROMs.

The operation of the ALC loop causes the amplitude of the RF signal to conform to this varying control voltage, thus amplitude modulating the Generator output.

### 3-9. Frequency

The 0.1-MHz to 1050-MHz frequency coverage is divided into the following three bands:

Low-band	0.1 MHz to 245 MHz
Mid-band	245 MHz to 512 MHz
High-band	512 MHz to 1050 MHz

The high and mid bands are derived directly from a voltage-controlled oscillator (VCO) followed by a binary divider that is part of the main phase-locked loop (PLL).

This PLL synthesizes the 245- to 512-MHz band using a modified N-divider loop with a single-sideband mixer (SSB) in the feedback path. The reference frequency for the loop is 1 MHz, which would normally provide 1-MHz steps in a conventional N-divider loop. However, this Generator provides 0.02-MHz steps by using a modified N-divider circuit with pulse deletion controlled by a rate multiplier.

Additional resolution is gained by introducing a signal from the sub-synthesizer circuit into the main PLL through the SSB mixer in the feedback path. This signal provides internal frequency steps of 5 Hz. The sub-synthesizer consists of a 14-bit rate multiplier followed by a divide-by-1000.

Control of the synthesizer frequency ( $F_s$ ) is such that later (effective) doubling or heterodyning produces the high and low frequency bands for the desired Generator output frequency. Also, since the main PLL bandwidth varies with the programmed frequency (due to N changing and variations in the VCO tuning coefficient), the Controller uses compensation to program the phase detector gain via the KN DAC to maintain constant loop bandwidth. By keeping the loop bandwidth constant, loop stability and modulation transfer is controlled, thus ensuring accurate, wideband FM.

### 3-10. Frequency Modulation

Frequency modulation is achieved by applying the modulation signal simultaneously to the PLL VCO and the Phase Detector. Both are necessary because modulating either the VCO or the Phase Detector alone results in FM with a high-pass filter characteristic, or phase modulation with a low-pass filter characteristic. The filter characteristic cutoff frequencies are equal to the PLL bandwidth.

The modulating signal applied to the VCO and the Phase Detector is adjusted in amplitude by the KV DAC to compensate for variations in the VCO tuning coefficient. This compensation is done automatically by the Controller using factory calibration data measured on the VCO in each Generator. This compensation data is stored in the VCO Calibration EPROM.

By integrating the modulation signal applied to the Phase Detector and simultaneously applying the modulation signal to the VCO, the two effects are complementary and result in a flat FM response.

### 3-11. SOFTWARE OPERATION

The Generator software is executed on a Texas Instruments TMS 9995 microprocessor in the A2A7 Controller assembly. The instrument program is stored in 40K-bytes of ROM, two scratch pad RAM, 2K-bytes off-chip and 250- bytes on-chip RAM. Three 2K-byte EPROMs contain the individual Generator calibration data. The software provides the following general functions:

- Interfaces with the front panel keys and the IEEE-488 Interface to provide access to the Generator functions.

- Configures the Generator functional blocks to produce the required output and then applies linearization and compensation data to optimize the instrument performance and resolution.
- Implements a set of self test and diagnostic functions.

### 3-12. User Interface

The Generator software is implemented with a simple operating system that allows several tasks to operate in a round-robin fashion on a equal priority basis. Input and output to the front panel and to the IEEE-488 Interface option, however, execute at a higher priority and are handled as interrupt routines.

At power-on, the software performs an instrument self test and initializes both the RAM and the Generator hardware. Three tasks are continuously in operation:

Service task  
Key task  
IEEE-488 task

The service task checks the status signals. The key task and IEEE-488 task process user input. A fourth task is activated only when needed to process certain UNCAL (uncalibrated) or REJ ENTRY (rejected entry) conditions that cause the instrument STATUS display to flash.

### 3-13. Amplitude Control

Amplitude is programmed using a 23-step (6.02 dB per step) attenuator assembly and a 12-bit vernier level DAC. The level DAC settings depend on a combination of the programmed output level and amplitude correction data.

The amplitude correction data compensates for level inaccuracies and is a function of the Generator frequency. Correction factors are stored in the Output and the Attenuator Calibration EPROMs. Each Output and Attenuator assembly comes with a matched calibration EPROM. The assemblies may be replaced under the Module Exchange Program with only minor adjustments needed after installing the replacements.

### 3-14. Attenuators

One 6-dB, one 12-dB, and five 24-dB sections of the Attenuator are programmed in combination to provide course level control. The indicated voltages at which the Attenuator changes ranges are  $2^{-m}$  volts, where

$m = 1, 2, 3, \dots 23$  for non-AM, or

$m = 2, 3, 4, \dots 24$  for AM operation

Table 4D-15 lists the Attenuator sections programmed for various displayed levels.

### 3-15. Level DAC

The level DAC setting (LEV 0 through 9) is calculated from the Generator output level. If level correction is enabled, the level DAC setting is further modified by the data stored in the Output and Attenuator calibration EPROMs.

To minimize level transients that could damage external circuitry, the following sequence is used in programming the Attenuators and the level DAC when the Attenuator setting is changed:

1. The level DAC is programmed to zero.
2. The new Attenuator setting is programmed.
3. After a 15-ms wait to allow the Attenuators to settle, the LEVEL DAC is programmed to the new setting.

### **3-16. Temperature Compensation**

The temperature compensation DAC (TC DAC) data is stored in the Generator software as a function of the output frequency ( $F_o$ ). This data is the same for each Generator.

### **3-17. Reverse Power Protector Option**

The optional Reverse Power Protector (RPP) A2A5 (if installed) protects the Generator from damaging voltages applied to the RF OUTPUT connector. The status line RPTRPL indicates whether the RPP circuitry has tripped. If the RPP trips, the RF output is programmed off, and the RF OFF indicator flashes. The RPP circuitry is reset by the operator turning the RF OUTPUT on. This causes the Controller to reset the RPP by toggling RPRSTL, and programming the RF on.

### **3-18. Frequency Reference Control**

Programming of the frequency reference control bits depends on the setting of the INT/EXT reference switch as well as whether the High-Stability Reference or the Sub-Harmonic Reference options are installed.

### **3-19. Frequency Control**

The output frequency ( $F_o$ ) is programmable with 10-Hz resolution. The minimum calibrated output frequency is 0.1 MHz, and the maximum calibrated output frequency is 1050 MHz. The filter and band control bits are programmed in five bands and are determined by the output frequency ( $F_o$ ). For each band, a synthesizer frequency ( $F_s$ ) is determined.

The programming data of the KV and KN DACs are calculated from the synthesizer frequency ( $F_s$ ) and the instrument-specific VCO Calibration EPROM data. The KV DAC settings on the high and low bands are one half the settings on the mid-band to compensate for the effective doubling of the FM deviation that occurs on the high and low bands.

### **3-20. Modulation On/Off**

The four modulation modes are:

- Internal AM
- External AM
- Internal FM
- External FM

The modulation modes can be programmed separately or in any combination. The AM depth and FM deviation DACs are always programmed regardless of whether or not modulation is enabled. When enabling or disabling modulation, only the modulation control bits are programmed. Table 4D-17, Modulation ON/OFF Control, lists the control states for each modulation choice.

### **3-21. Modulation Frequency**

The two internal modulation frequencies of 400 Hz and 1000 Hz are programmed with a single control bit MF400L. Table 4D-18 Modulation Frequency Control lists the MF400L control states.

### 3-22. Amplitude Modulation

The Generator allows amplitude modulation depth programming from 0 to 99% with 1% resolution. However, the maximum calibrated AM depth is 90%. Programming an AM depth greater than 90% causes the 'UNCAL' indicator to light. When the combination of signal amplitude and programmed AM depth exceeds +13 dBm peak, the 'UNCAL' indicator lights to warn you the output level is no longer guaranteed. Amplitude modulation depth is programmed using the 8-bit AM DAC, with a setting of 200 on the AM DAC corresponding to 100% AM modulation of the output frequency.

### 3-23. Frequency Modulation

Frequency modulation (FM) is programmable with three digits of resolution in the three decade ranges. Table 4D-12, FM Ranges, lists the three ranges.

### 3-24. FM Deviation

The FM DAC is a 10-bit DAC programmed to the FM deviation in Hz divided by the resolution. Table 4D-13 lists the settings of the FM DAC.

### 3-25. Self Test

At power-on, the Generator automatically self tests its digital and analog circuits. If the Generator fails any self test, the test results are automatically displayed as error codes. Several special functions are available for additional tests. (See section 4D-16.) Also, the Generator microprocessor continuously monitors two status signals, UNLVL (unleveled) and UNLOK (unlocked).

The self tests can also be invoked by using the [SPCL] [0][2] keys. The results of the self test can be displayed in the four display fields with [SPCL] [1][1] keys and can also be transmitted using the optional IEEE-488 Interface.

Self tests 1 through 5 are digital checks that indicate the general functionality of the Controller assembly. Self tests 6 through 10 use the two status signals UNLVL and UNLOK to test the general functionality of the RF circuitry.

During the self-test sequence all attenuators are programmed ON (maximum attenuation) to prevent unwanted signals at the output. In addition, the Generator is programmed to the internal frequency reference because the self tests fail if there is no reference supplied.

The self-test error codes and descriptions are listed in Section 4D. A brief description of the different Generator self tests are described in the following:

- Test 1. The Generator RAM is verified by writing data to each memory location and checking that the same data can be read back. Both the off-chip RAM and the on-chip RAM are tested in this way.
- Test 2. The data in each word of the two instrument software EPROMs is successively summed and rotated by two. The result of this procedure is compared with a checksum for each EPROM.
- Test 3. The data in each of the three calibration EPROMs (VCO, Output, and Attenuator) is summed and compared with a checksum.
- Test 4. The IEEE-488 (if installed) is verified by the microprocessor writing data to the IEEE-488 chip and then by reading it back to see if the response is the one expected. The operator is given a report only if the test fails.



- Test 5. If Non-Volatile Memory is installed, each memory location of the Non-Volatile RAM is checked with a checksum.
- Test 6. The low-pass filters on the Output assembly are tested by setting the frequency at the top of each of the four half-octave non-HET bands and verifying that the output is leveled. Then, the frequency is set above the cutoff frequency, and the output is checked to see if the output is unleveled.
- Test 7. The synthesizer operation is verified by programming the Generator to a normal operating frequency and checking to see that the instrument is locked. The Generator is then programmed to a synthesizer frequency below 225 MHz and then above 550 MHz and is checked to see that the instrument becomes unlocked. Finally, all frequency reference circuitry is turned off and checked to see that the Generator becomes unlocked.
- Test 8. The Generator PLL operation is verified by forcing a large change in frequency. When this is done, the Generator should become unlocked and then lock again.
- Test 9. Frequency modulation is verified by overmodulating the carrier and then checking the unlocked indicator. This is done by programming internal FM on and programming the KV DAC to a higher than normal value.
- Test 10. Amplitude modulation is verified by overmodulating the carrier and then checking the unleveled indicator. This is done by programming a high output level and programming INT AM on with a high AM depth.

### 3-26. Service Special Functions

There are two special function self tests for the front panel indicators and keys. These special function self tests are described in the following:

1. The front panel displays are checked any time by pressing the [SPCL] [0][3] keys. When this is done the microprocessor lights all display segments. This test is terminated by pressing any key on the instrument.
2. Check the normally open front panel keys by pressing the [SPCL] [0][4] keys. Now, each key pressed has its row and column address displayed in the center of the FREQUENCY display field. The special function is exited by pressing the [CLR/LCL] key.

### 3-27. Status Signals

Six status signals indicate the Generator option complement, and these status bits are interrogated at power-on self test as follows:

HSOFTL	= 0 indicates Option -130 High-Stability Reference is installed.
SHREFL	= 0 indicates Option -131 Sub-Harmonic Reference is installed.
IEINL	= 0 indicates Option -488 IEEE-488 Interface is installed.
NVINL	= 0 indicates the Option -570 Non-Volatile Memory is installed.
LRFML	= 0 indicates the Option -651 Low-Rate FM is installed.

## THEORY OF OPERATION

ROPTL = 0 indicates Option -830 rear panel RF OUTPUT and MOD IN connectors is installed.

RPPL = 0 indicates Option -870 Reverse Power Protector is installed.

The status of the rear panel REF EXT/INT reference switch is continuously monitored with the EXREFL bit. The state of this bit is used by the Controller to display the 'EXTREF' indicator on the front panel and to program the reference source.

The RF output of the Generator is considered calibrated whenever the 'UNCAL' indicator is off. The 'UNCAL' indicator is lit, but not flashing, whenever the calibrated limit of the Generator is exceeded. However, the RF output is still considered usable.

The 'UNCAL' indicator flashes when the output of the instrument is considered unusable. This is the result of a severe overrange condition or when one of the following analog status signals becomes active.

RPTRPL = 0 indicates that the optional-870 RPP circuitry has tripped. If this occurs, the RF output is programmed off to provide additional protection to the instrument. The 'RF OFF' and 'UNCAL' indicators flash to indicate that RPP has tripped.

UNLOKL = 0 indicates one of several conditions. The Synthesizer or the reference circuits could be out-of-lock. If FM is on, it could indicate FM over-modulation. The 'UNCAL' indicator flashes for any of these circumstances.

UNLVLL = 0 indicates that the output is unlevelled. This could also be the result of amplitude over-modulation. With this condition, the 'UNCAL' indicator flashes.

### 3-28. DETAILED CIRCUIT DESCRIPTIONS

This section contains the detailed circuit descriptions for the following assemblies:

#### A1 Front Section

A1A1 Display Assembly

A1A2 Switch Assembly

#### A2 Module Section

A2A1 Synthesizer Assembly

A2A2 VCO Assembly

A2A4 Output Assembly

A2A6 Attenuator Assembly

A2A7 Controller Assembly

#### A3 Rear Section

A3A1 Power Supply Assembly

### 3-29. FRONT SECTION, A1

The Generator front section, A1, consists of the Display PCA A1A1, the Switch PCA A1A2, and the Elastomer switches mounted in a sheet metal housing. The front section also includes the display lens, the POWER ON/OFF switch, and the MOD INPUT connector.

**3-30. Display PCA, A1A1**

The Display PCA A1A1 provides a readout of the programmed modulation, frequency, amplitude parameters, and status information. This displayed information and the bright digit are controlled by the Controller, A2A7, under the direction of the instrument software. The display is comprised of two vacuum fluorescent displays and their associated control circuitry. The two displays are refreshed as four groups of eight display fields (usually a digit) each. The four groups share the digit (grid) strobes but have individual segment (anode) strobes.

**3-31. DATA COMMUNICATIONS**

Display data is sent through a byte-wide bidirectional data bus from the Controller A2A7 and is latched by U1 through U5 on the display board. Latch select signals DIGL, SEG1L, SEG2L, SEG3L, and SEG9L determine which latch receives the data. Level shifting buffer drivers U6 through U10 interface the TTL latches directly to the +37V anodes of the vacuum fluorescent displays.

**3-32. DISPLAY FILAMENT VOLTAGE**

The 6.0V ac filament voltage for the display is derived from a center-tapped winding on the power supply transformer, T1. The ac filament voltage is biased at +6.2V above ground by circuitry on the power supply board A3A1, to provide a cutoff potential for the displays.

**3-33. BRIGHT-DIGIT EFFECT**

The bright-digit effect is achieved by providing three extra refresh cycles (strobes) to the specified digit. Grid current-limiting resistor R3 provides uniform digit brightness by controlling electron depletion from the display cathode filaments.

**3-34. SWITCHBOARD INTERFACE**

The digit strobe data latched by U1 is buffered by open collector inverters U13 and U15, and strobes the front panel switch matrix. The switch columns are strobed in unison with the eight display fields. The switch matrix status is read by the tri-state buffer U14.

**3-35. DISPLAY BLANKING**

Monostable U11 and NOR gate U12 clear the display if new field or segment strobes are not received. This protects the display if the microprocessor stops refreshing. The display can be blanked manually by pressing [SPCL] [1][3] which sets the signal CLRL and the output of U11 low, thus clearing latches U2 through U5. To restore the display, press [SPCL] [1][2].

**3-36. MODULATION-LEVEL INDICATOR**

The external modulation-level indicator warns the operator when the modulation signal is not set to 1V peak ( $\pm 2\%$  typically). The external modulation signal is compared in the dual-comparator, U16, with internal references of 0.98 and 1.02V. Two status bits, MLEVLO and MLEVHI, are at the output of the 0.5 second dual one-shot, U17. If either of these reference voltages are exceeded, the two status bits are sensed by the Generator Controller that controls the 'EXT HI' and 'EXT LO' indicators in the MODULATION display field.

**3-37. Switch PCB, A1A2**

All the front panel control keys, except the POWER ON/OFF switch, consist of an Elastomer membrane sandwiched between the Switch PCB A1A2 and the front panel sheet metal housing. The Switch PCB consists of a 6-by-8 matrix of open switch contact pads. When a key is pressed, a conductive pad on the back of the Elastomer membrane connects a set of contact pads. The Controller software senses what row and column of the matrix are connected when a key is pressed.

### 3-38. MODULE SECTION, A2

The module section consists of a cast module frame with gasketed covers and includes the following electrical assemblies:

- A2A1, Synthesizer
- A2A2, VCO
- A2A4, Output
- A2A6, Attenuator (or A2A5, Attenuator/RPP)
- A2A7, Controller

### 3-39. Synthesizer PCA, A2A1

The Synthesizer PCA provides frequency control and modulation of the Signal Generator output. The Synthesizer assembly is located on the top side of the Module Section A2. Together with VCO A2A2 and a 10-MHz reference frequency, the Synthesizer assembly simultaneously generates a high-band signal that spans 490 to 1050 MHz and a mid-band signal that spans 245 to 512 MHz.

The high-band and mid-band signals are coupled to the Output A2A4. Here, heterodyning extends the Generator frequency coverage down to 0.1 MHz.

The Synthesizer assembly consists of the following functional circuits that are described in the following paragraphs:

- 10-MHz Reference
- Main PLL
- FM Processing
- 800/40 MHz PLL
- Sub-Synthesizer

### 3-40. 10-MHZ REFERENCE

The 10-MHz Reference circuitry allows internal or external signals to function as the Generator reference. The Generator reference is normally the internal 10-MHz crystal oscillator. If Option -130 High-Stability Oscillator is installed, that oscillator becomes the Generator reference.

The internal 10-MHz crystal oscillator (XO) is a crystal, Y1, and an FET transistor Q26. The frequency is adjusted by C153. The oscillator signal from Q26 is buffered by Q27, converted to TTL by U54, and sent to multiplexer U55A. When the internal oscillator is disabled, the input (U54 pin 13) is pulled up at the same time the bias current for Q26 is disabled. The A section of this multiplexer decides whether the internal 10-MHz X.O., the external reference, or Option -130 High-Stability Reference is selected for the Generator reference.

The output of multiplexer U55 is sent to the 800/40-MHz loop-phase detector, the main loop-phase detector via divide-by-10 U58, and Option -131 Sub-Harmonic Reference (if installed). Multiplexer U55B sends the signal to the rear panel if the REF INT/EXT switch is set to INT.

The rear panel 10 MHz IN/OUT connector serves two functions.

1. When the rear panel REF INT/EXT switch is set to INT, the 10-MHz reference signal from the X.O. is the Generator's reference.

If Option -130 High-Stability Oscillator is installed, its signal is the Generator's reference, and it is available at the rear panel 10 MHz IN/OUT connector.

2. When the rear panel REF INT/EXT switch is set to EXT, an external 10-MHz TTL signal applied to this connector becomes the Generator reference.

If Option -131 Sub-Harmonic Reference is installed, a separate BNC connector labeled REF IN is installed on the rear panel. The existing 10 MHz IN/OUT connector is relabeled 10 MHz OUT.

### 3-41. MAIN PHASE-LOCK LOOP

The main phase-lock loop (PLL) is a fractional divider PLL with a single-sideband mixer (SSB) in the feedback path. The oscillator for this loop is a separate PCA, the A2A2 VCO. All the remaining PLL circuitry is on the synthesizer PCA A2A1.

The key signals to the main PLL are the 1-MHz reference signal from the 10-MHz Reference circuit, the 245-MHz to 512-MHz signal from the binary divider, and the 20-kHz to 40-kHz signal from the sub-synthesizer circuit. The fractional division technique provides 20-kHz frequency resolution.

The SSB mixer, in conjunction with the sub-synthesizer, provides additional 5-Hz resolution at the Generator frequency ( $F_s$ ). This corresponds to 10-Hz resolution on the high band.

The main PLL consists of the VCO, the binary divider, the SSB mixer, the triple-modulus prescaler, the N-Divider, the phase detector, and the loop amplifier. All but the VCO are described in the following paragraphs. The VCO is discussed in paragraphs 3-48.

### 3-42. Binary Divider And Single-Sideband Mixer

The 490-MHz to 1050-MHz signal from the VCO via J107 is coupled to the binary divider, U1. Regulator Q1 provides +5V for the divider. One output of U1 is coupled to the Output PCA, A2A4 through J104. The other output is amplified by Q2 and Q3. This signal is split into two quadrature (90° phase difference) signals by 3-dB coupler, U6.

This signal, and two other audio quadrature signals from U10, are summed in the double-balanced mixers U7 and U8 to produce two double-sideband suppressed-carrier signals. Because of the phase relationship of the outputs of the mixers, the summing of the two composite signals (in resistor network R21 and R22) results in the upper-sideband component being suppressed. The predominate remaining signal is the lower-sideband signal.

The lower-sideband signal, spanning 245 MHz to 512 MHz in 20-kHz steps, is amplified by U9 and applied to the N-Divider where it is divided down to 1 MHz.

### 3-43. N-Divider

The main components of the N-Divider are:


Triple-Modulus Prescaler (divide by 20/21/22) U18, U19, and U20  
N-Divider Custom Gate Array U17

The triple-modulus prescaler, Figure 3-1, consists of a divide by 10/11 (U20), divide by 2 (U18A), synchronizing flip-flop (U18B), and quad NOR gates (U19). If all the inputs (E1, E2, E3, E4, and E5) to the 10/11 divider are low, the prescaler divides by 11, and the total division to the output (U20 pin 7) is 22. If any of the inputs are high, it divides by 10, and the total division is 20.

If inputs E1 and E3 are low, the modulus of the 10/11 divider is controlled by the output of the following divide by 2 (U18A). Consequently, the prescaler divides by 10 half the

time and by 11 the other half, resulting in a divide by 21. U20 contains the ECL to TTL converter. UI8B synchronizes the changing of the modulus with the clocking of the subsequent stages. The N-divider is clocked by the composite prescaler output UI8A.

The operation of the triple-modulus prescaler is shown in Figure 3-1. The prescaler operates in conjunction with the N-divider gate array shown in Figure 3-2.



### Figure 3-1. Triple-Modulus Prescaler Operation




Figure 3-2. N-Divider Operation

## THEORY OF OPERATION

The N-Divider gate-array contains two 5-bit binary counters (A and N), a BCD two-decade rate multiplier, and latches to interface to the microprocessor. The operation of the N and A counters is as follows:

At the beginning of a count cycle, a number is loaded into the A and N counters. The A counter is not at its terminal count, so the output is high, and the mode line (MODE L) is low. This causes the prescaler to divide by 21 (or 22, TRMODL = low). The mode line stays low for 31-A counts, where A is the programmed number. The mode line goes high, and the prescaler divides by 20 (or 21, TRMODL = low) for 31-N counts.

The total division is:

$$(P+1)*(31-A) + P*((31-N)-(31-A)) \text{ or } P*(31-N) + (31-A)$$

On the 31st count, the counters are reinitialized. Figure 3-3 shows the timing for the A-counter programmed to 26, and the N-counter programmed to 18. Only the CKNL and MODE L signals shown in Figure 3-2 are accessible at U17, pin 6, and 22, respectively. Figure 3-3 show the N-Divider timing diagram.

The N-Divider gate array includes a two-decade rate multiplier that produces the fractional part of the division. It produces a pulse train with a programmed number of pulses for a 100-cycle frame of the 1-MHz N-divider output.

The programmed number ranges between zero and 98 in steps of two, corresponding to 20-kHz steps at the mid-band output frequency. The flip-flops in the rate multiplier get setup on count 29, and on count 30, a pulse may or may not be present depending on the programming of the rate multiplier. This is the shaded pulse in the timing diagram, Figure 3-3.

Irregularly spaced rate-multiplier pulses cause the mode line to go low, and the prescaler divides by P+1 at a rate equal to the rate multiplier programming. At a division of 255, the N and A counters are normally programmed to 15. This means the divider is always dividing by 21; consequently, there is no place to slip in the rate-multiplier pulses.

It might be noted that a 20/21 dual-modulus prescaler will not allow division from 245 to 525 without holes. For example 252 is 12 frames of 20 and 12 frames of 21. Consequently, there is no place to slip in the rate-multiplier pulses. It is not possible to divide by 253.

By using a triple-modulus prescaler, these problems are solved. Continuing with the above example number of 252, 252 is 12 frames of 21 and 0 frames of 22. The deleter functions by allowing the prescaler to divide by 22 at a rate equal to the rate-multiplier frequency. Number 253 is 11 frames of 21 and 1 frame of 22. A software algorithm determines whether to operate in the 20/21 mode (TRMODL =1) or 21/22 mode (TRMODL =0).

The frequency at the output of the divider is  $(F_o/2 - F_s - F_d)/N$ ; where  $F_o$  is the VCO output frequency,  $F_s$  is the sub-synthesizer frequency, and  $F_d$  is the fractional-division frequency.






Figure 3-3. N-Divider Timing Diagram

### 3-44. Phase Detector

The 1-MHz reference signal from divide-by-10 U58, and the 1-MHz signal from the N-divider U17 are connected to a digital phase-frequency detector (U43, U44, U45). If the N-divider output is greater than the reference frequency, the level at TP38 is high. When the output of the level shifter Q16 is above ground, then CR12 is turned off. This allows current from Q19 to flow through CR13 into the integrator, decreasing the voltage at the integrator output, U48 Pin 6, which then lowers the frequency of the VCO until the reference and the N-divider output are the same frequency.

Similarly, if the N-divider output frequency is below the reference, TP39 is low, and the voltage at the output of level shifter Q17 is below ground, turning off CR15 and allowing current from R108 to flow through CR14 out of the integrator. This raises the voltage at the output of the integrator, which raises the VCO frequency. The phase-frequency detector is designed so that if the phase between the reference and N-Divider output slips more than two cycles in either direction, the corresponding phase-detector output is high or low. This provides twice the integrator current during acquisition as a conventional phase-frequency detector.

R107 provides a small bias current to the integrator to bias the phase detector at approximately 2.5 radians; consequently, the down-pump is normally always on. If the up-pump comes on, indicating an over-modulation condition, the pulses are detected by the one-shot, U47 that produces the UNLOCK status that is then sensed by the Controller.

For flat FM response, it is necessary for the PLL bandwidth to be constant at all VCO frequencies. Two factors cause the loop bandwidth to change: the VCO tuning coefficient ( $K_v$ ) and the divider ratio ( $N$ ).

During calibration of the VCO, the  $K_v$  is measured at many frequencies across the band, and compensation data is stored in the VCO Calibration EPROM. The instrument software uses this data along with  $N$  to control the PLL bandwidth in a compensating manner. The PLL bandwidth is controlled by changing the current to the down-pump via the  $K_N$  DAC, U27, and the voltage-to-current converter, U46, Q18, and Q19.

### 3-45. Loop Amplifier

The loop amplifier-integrator consists of operational amplifier U48, C118 and R91. Capacitors C121 and C119 filter the 1-MHz reference. The output of the integrator is connected to a multi-pole LC filter (R92, C123, C99, C124, C126, C125, L49, L50, and R93) that attenuates the delete rate (20 and 40 kHz) and reference 1-MHz spurs.

Diodes CR9 and CR10 stabilize the loop during switching. The filter is buffered by the Darlington emitter-follower Q20, which is biased at 10 mA by Q21. Additional lead/lag compensation is provided by R99, R101, and C131. Proper termination for the filter is provided by R93 and Q22. The voltage for the loop amplifier is regulated to approximately +30V by Q15.

Amplifier U49 is a precision clamp to keep the VCO frequency above a minimum value for oscillation, and below a maximum above which the N-divider would not divide correctly. The photoisolator U50 detects when the clamp is active, indicating an out-of-lock condition. This signal is ORed with the signal from one-shot U47 and sent to the microprocessor as the UNLOCK status.

### 3-46. FM PROCESSING

To provide FM accuracy, the FM signal FMV from the Output board is first processed by the  $K_V$  DAC (U28, and U29) to compensate for the VCO tuning coefficient. The  $K_V$  DAC setting is proportional to  $1/K_v$ , where  $K_v$  is the tuning coefficient. This correction

is stored in the VCO Calibration EPROM on the Controller board. For output frequencies above 512 MHz and below 245 MHz, the KV DAC setting is halved to account for the effective frequency doubling that occurs on these bands.

Range switching is provided by resistors R77, R78, R79, and FETs Q10, Q11, and Q12. Comparator U42 converts TTL levels to 0V (on), and -15V (off) required by the FETs. U41A buffers the range switch, and in conjunction with R82, provides an overall FM adjustment. At this point, the audio signal splits into two paths. The path that connects to the integrator, U41, is for modulation frequencies inside the loop bandwidth.

The path that sums with the VCO control voltage at J103 is for frequencies outside the loop bandwidth. U41D is an active high-pass filter that compensates for the non-ideal integrator and the ac coupling to the VCO tuning port.

The output of U41D is summed with the VCO control voltage via R88 and C117. FET Q13 allows the FM to be turned off. The audio signal is also processed by integrator U41A, R85, R86, and C115. The audio signal is ac coupled into the phase-detector integrator via R89, R90, C116, and FET Q14. (Resistor R90 adjusts the low frequency FM gain). This integrator makes the phase modulation produced at the Phase Detector appear as FM.

### 3-47. 800/40 MHz PLL

When the Signal Generator is operated in the low-band, the 800-MHz oscillator is locked to the 10-MHz Reference and provides a local oscillator for the heterodyne circuit on the Output PCA. It also provides a 40-MHz signal to the sub-synthesizer clock generator.

The 800-MHz VCO is connected to the divide-by-four, U61, followed by a divide-by-five, U62 and U63, providing 40 MHz to the sub-synthesizer clock generator through selector U64. When the Signal Generator is not in the low-band, the 800-MHz oscillator and the first divide-by-four are disabled by turning off Q28 (HET).

The 40-MHz Oscillator consisting of U64, L66, and CR24, is selected by U64. The 40-MHz balanced ECL signal from U64 drives the two-phase clock generator. A self-biased gate, U65, converts ECL to TTL. U66 divides the 40-MHz signal by four to produce a 10-MHz signal that is compared against the 10-MHz reference in the phase detector U59 and U65.

Op-amp U60, resistor network Z9, and C181, C185, C186, and C201 integrate the phase detector pulses to produce a dc control voltage for the 800-MHz VCO and the 40-MHz VCO.

### 3-48. 800-MHz VCO

The 800-MHz VCO is a low noise, limited range, voltage-controlled oscillator for the 800-MHz PLL. The basic oscillator uses two active devices operating as negative resistance elements, coupled symmetrically to a resonator made up of a varactor and an adjustable capacitor. Each device is followed by an amplifier and isolation pad. This provides two coherent outputs of +5 dBm to the PLL and 0 dBm to the output A2A4 assembly.

The oscillator transistors Q32 and Q35 are biased at 13 mA by R182 and R191. The voltage at the collectors of Q32 and Q35 is typically +2.5V. The two 6-dB amplifiers Q33 and Q37 are biased so that the voltage at their emitters is about +0.3V, and the voltage at their bases is about +1V with the collectors at +6.5V.

The PLL control voltage from U60 provides the tuning voltage for the varactor CR27. The adjustable capacitor C206 is set to provide +16V on the varactor to optimize the VCO noise characteristic. The output attenuators consisting of R186, R187, R189, R197,

R198, and R200 provide isolation between the outputs. The VCO signal is coupled to the output assembly A2A4 by a through-the-plate coaxial connector P108 at the 0 dBm level. The other VCO signal is connected to the divider U61 to provide the feedback for the PLL.

### 3-49. SUB-SYNTHESIZER

The sub-synthesizer consists of the clock generator, U34, 35, Q4, Q5, the gate-array, U33, the divide by 500, U15, and U16, and the low-pass filter L11 and L17. Internal to the sub-synthesizer gate-array, U33, are a divide-by-two, a  $3\frac{1}{2}$  decade-rate multiplier, and associated latches.

The balanced 40-MHz ECL clock signal is converted to TTL in Q4 and Q5, and converted to a two-phase 20-MHz clock in U34, U35.

An enable output of each section allows multiple sections to be cascaded. The input frequency to the rate-multiplier is 20-MHz. The output frequency can be programmed from zero to 19.995 MHz in 5-kHz steps. This signal is ORed with the other phase of the 20-MHz clock to produce 20 MHz to 39.995 MHz at U33 pin 1. This is divided by two in the gate-array, by ten in U15, and again by 50 in U16 to produce 20 kHz to 39.995 kHz in 5-Hz steps. This TTL signal at TP11 is filtered by L11, L17, and C41, C42, C48, C50, and C51. Op-amp, U10 forms an active quadrature generator, and the output pins 14 and 8 are offset by 90°. These two signals are the 20-kHz to 40-kHz inputs for the Main PLL single-sideband mixer.

### 3-50. VCO PCA, A2A2

The VCO PCA A2A2 is the heart of the main PLL. It produces the signal that is further processed to become the Signal Generator output. The VCO assembly is located in a bottom side compartment of the Module section A2.

The VCO tunes over a frequency range of 490 MHz to 1050 MHz with a control voltage range of +2V to +18V. The basic oscillator circuit uses two active devices operating as negative resistance elements. Coupled symmetrically to a resonator, each active device is followed by a 6-dB amplifier and a 15-dB isolator pad that provides two coherent but isolated signals at about 0 dBm.

One signal is sent to the Output A2A4 assembly, and the other to the Synthesizer A2A1 assembly. To suppress harmonics, two tuned trap filters are placed between the negative resistance devices and amplifiers Q2 and Q4.

The oscillator transistors Q1 and Q3 are biased at 13 mA by the FET current sources Q5 and Q6. The voltage at the collectors of Q1 and Q3 are typically set at +6V. The two 6-dB amplifiers Q2 and Q4 are biased so that the voltage at their emitters is about +0.3V and at their bases about +1V, with the collectors at about +6.5V.

The PLL control voltage from the Synthesizer assembly A2A1 at P102 provides the tuning voltage for varactors CR1 and CR2. This voltage also controls varactors CR3 and CR4 with resistors R6, R4, R18, R19, and R20. These varactors, in conjunction with their lead inductance and C1 and C32, make up a shunt trap filter at twice the VCO frequency to suppress the in-band second harmonic at both VCO outputs to typically less than -10 dBc.

The output attenuators consisting of R13, R14, R15, R27, R28, and R29 provide the isolation between the two VCO outputs at P103 and P104. C23 and C30, in series with the printed board inductors, form out-of-band trap filters for approximately 1.4 GHz. These filters further suppress the out-of-band harmonics.

C23 couples the VCO signal to the Synthesizer assembly by a through-the-plate coaxial connector P104. The other VCO signal is connected to the Output assembly A2A4 by a plug-in capacitor, A2C1. This plug-in capacitor allows either VCO or the Output PCB to be removed independently from the module A2 assembly without the use of a soldering iron.

### 3-51. Output PCA, A2A4

The Output PCA accepts RF signals from the Synthesizer and the VCO circuits and command signals from the Controller. The output circuit provides a 0.1-MHz to 1050-MHz RF signal to the Attenuator.

The functions of the Output assembly are to reduce harmonic distortion components in the RF signal, control RF signal amplitude, introduce AM, and generate the low (heterodyne) frequency band 0.1 MHz to 245 MHz through mixing. It also generates a modulation signal to provide internal AM and FM, and provides a digital interconnect path between the Controller and Synthesizer.

### 3-52. RF PATH

The RF path begins with the two RF signals from the VCO and the Synthesizer assemblies. The SPDT bandswitch circuit selects between the 512-MHz to 1050-MHz signal at P106 and the 245-MHz to 512-MHz signal at P107. The selected signal is applied to buffer amplifier Q101 and Q102.

The 245-to 512-MHz signal directly generates the 245-to 512-MHz mid-band output signal. The 512-MHz to 1050-MHz signal generates the 512-MHz to 1050-MHz high-band output signal directly and the 0.1-MHz to 245-MHz low-band output signal by mixing with an 800-MHz LO signal.

The buffer amplifier Q101 and Q102 is a common-base, common-emitter cascade circuit with 7-dB gain. The three cascaded filter circuits that follow the buffer amplifier consist of combinations of discrete components and printed filters that suppress harmonics in the Generator RF output signal.

The first section of the circuit is a printed 1100-MHz low-pass filter. The second section is switched into the RF path via PIN diodes CR106 through CR110 by asserting MIDL when the Generator is operated in the mid-band (245 to 512 MHz). PIN diodes CR114 through CR116 select capacitors C119, C121, and C123 whenever HAOCTH is asserted to change the section cutoff frequency from 512 to 350 MHz. The third section provides harmonic filtering for the two higher bands, 512 MHz to 730 MHz, and 730 MHz to 1050 MHz. PIN diodes CR111 through CR113 select capacitors C112 through C114 to change the cutoff frequency from 1050 MHz to 730 MHz whenever HAOCTH is not asserted.

The amplitude modulator consists of PIN diodes CR117 through CR120 and associated components and follows the switchable filters in the signal path. The modulator is a voltage-controlled variable attenuator that provides AM and output level control. Modulator control voltage is determined by the leveling-loop circuitry. The leveling loop is described later in this section.

Q209, Q211, Q213, and associated components follow the modulator in the signal path and form a three-stage, 20-dB gain, 245-MHz to 1050-MHz amplifier. This amplifier drives a 3-dB power splitter that consists of resistors R253 through R255 and associated printed transmission lines.

One power splitter output drives the leveling-loop detector diode CR202. The other output goes to the HET band switch that includes PIN diodes CR203 through CR210 and

biasing components. In the 245-MHz to 1050-MHz position, the signal passes through diodes CR204 through CR209 to the output amplifier Q215. This low-distortion output amplifier has 6-dB gain and output capability of 15 dBm.

For low-band operation (0.1 MHz to 245 MHz), the signal from the power splitter is routed through CR203 to an adjustable attenuator, R224 through R229, and then to the RF port of U201 (a double-balanced mixer). The signal frequency at the mixer RF port varies from 800.1 MHz to 1045 MHz. The 800-MHz local oscillator (LO) signal for the mixer comes from the Synthesizer assembly through P108 and is amplified by Q207. This fixed-tuned amplifier has 13 dB of gain and provides a 10-dBm signal at the mixer LO port.

The mixer 0.1-MHz to 245-MHz output signal is passed through a diplexing low-pass filter (C219 through C230, R230, R231) that suppresses unwanted mixer spurious products while maintaining a 50-ohm load at the mixer IF port. The filtered IF signal is amplified by a three-stage IF amplifier Q202, Q204, Q206 and associated components.

The IF amplifier gain increases with frequency and is nominally 35 dB at 0.1 MHz and 37 dB at 245 MHz. This gain characteristic compensates for the increasing loss with frequency of the mixer and the diplexing low-pass filter. The output of the IF amplifier passes through a 245-MHz low-pass filter (C216, C217, C218 and printed inductors) and PIN diode CR210 to the output amplifier. The +15V power supply for the LO and IF amplifiers is switched off by Q301 when the instrument is operating in the 245-MHz to 1050-MHz band to avoid introducing spurious products in the instrument output.

### 3-53. LEVELING LOOP

The leveling loop accepts the unleveled 245-MHz to 1050-MHz signal from the switchable low-pass filters and generates a leveled signal at the power splitter output that feeds the HET band switch. The leveled signal is proportional to the leveling loop control voltage that is generated by the level-control circuit. The signal amplitude at the other output of the power splitter is detected by a Schottky detector diode, CR202.

This diode generates a temperature-dependent dc voltage, which is a non-linear function of the applied RF voltage, so temperature compensation and linearization are necessary. The detector diode signal is low-pass filtered by L217 and C253, and is offset by the voltage across temperature-compensating diode CR126. Q104, Q105 and associated components form a current source circuit that provides bias current for CR126 and CR202.

The offset detector diode voltage at U101B pin 3 is linearized by amplifier U101B and its associated feedback components. Potentiometer R144 provides detector linearity adjustment. Thus, the voltage at U101B pin 1 is proportional to the RF voltage at detector diode CR202.

This voltage is divided and applied to the loop integrator amplifier at U101A pin 6. This amplifier drives the modulator through emitter follower Q103 and through the action of the ALC loop, maintaining the voltage level at U101A pin 6 equal to that on pin 5. Pin 5 voltage is a function of the leveling loop control voltage applied to R140. R140, R141, CR127, and CR128 form an additional detector linearizing network that is active for low RF levels. Amplitude modulation is achieved by summing an appropriately scaled modulation signal with the dc leveling loop control voltage applied to R140.

The amplitude modulator consists of PIN diodes CR117 through CR120, resistors R121, R122, and capacitors C137 and C138. Attenuation through the modulator is a function of bias current through the PIN diodes. This current is provided by the modulator linearizer circuit (R123 through R129, R148, R149, C139 through C143, and CR121).

Modulator attenuation is thus approximately proportional to the modulator control voltage at the emitter of Q103. Proportionality is required to maintain constant leveling loop bandwidth as modulator attenuation varies. Minimum attenuation is obtained with a modulator control voltage of 10V, while maximum attenuation is obtained with 0V.

Comparator U310A and associated components form an unlevelled indicator circuit. The comparator senses the modulator control voltage at the emitter of Q103. This voltage is normally less than +11V, and the comparator output is high. If the modulator control voltage exceeds +11V, the modulator attenuation is at a minimum, and the leveling loop becomes inoperative (unleveled). This condition could be due to a fault or some abnormal operation such as over-modulation. In this case, the comparator output (UNLVLL) goes low. The Controller senses this low and causes the front panel 'UNCAL' indicator to flash and displays an unlevelled status if interrogated.

### 3-54. LEVEL CONTROL

The instrument output level is set by the level-control circuit. Inputs to this audio signal processing circuit are the internal and external modulation signals, a dc reference voltage, and the digital control commands. The circuit output is the leveling loop control voltage that provides vernier level control of the Generator output. Digitally encoded level, modulation depth, and temperature-compensation information are provided by the Controller.

Selection of the internal or external modulating signal, or no modulation, is made by analog switches U401C, U401D, and Op-amp U402B. The selected, buffered modulation signal at U402B pin 1 is applied to pin 4 of U301, a dual 8-bit DAC. U301, with U302D, acts as a digitally programmed variable attenuator and is labeled AM DAC.

Binary AM depth control information from the Controller is applied to DAC U301. The output at U302D pin 14 is the modulation signal scaled to the programmed AM depth. This ac signal is summed by op-amp U302B with a dc reference voltage provided by CR403. The output at U302B pin 7 is called the 1+AM signal. This signal provides the desired AM depth when scaled by the LVL DAC and applied to the leveling loop. AM depth adjustment is provided by potentiometer R421.

The instrument RF output amplitude is temperature compensated in a frequency-dependent manner as follows. The 1+AM signal is applied to pin 18 of dual 8-bit DAC U301, the DAC B reference input. The DAC output, at U405D pin 14, is the 1+AM signal attenuated by an RF frequency-dependent factor provided by the Controller using constants stored in the Generator firmware. This voltage is applied to a resistor/thermistor network that includes R303, R305, R306, and RT301.

The network output is the 1+AM signal attenuated by an RF frequency and temperature-dependent factor, and is applied to summing op-amp U302C. The 1+AM signal is also applied to this summing amplifier. Thus, the voltage at U302C pin 8 is the temperature-compensated and scaled 1+AM signal.

This signal is applied to the reference input of Level DAC U303. This 12-bit DAC, with op-amp U302A, latches U304, U305, controls the Output assembly RF output amplitude. The DAC output voltage, at U302A pin 1, is the temperature-compensated 1+AM signal multiplied by a factor proportional to the 12-bit level control number provided by the Controller. This voltage is the leveling loop control voltage. The Generator RF output level adjustment is provided by potentiometer R311, and DAC offset voltage adjustment is provided by potentiometer R309.

### 3-55. MODULATION OSCILLATOR

The modulation oscillator generates a leveled sine wave of 400 Hz or 1 kHz and is the modulation source for the internal AM and FM functions. The oscillator is a level-controlled Wien-Bridge type and consists of op-amps U405A, U405B. Frequency is determined by the series RC time constant of the components between pins 5 and 7 of U405B and by the parallel RC time constant of the components from U405 pin 5 to ground. The modulation frequency control line, MF400L, originating at the latch U308, selects either 400-Hz or 1-kHz operation, and is selected by switching resistors with JFETs Q401 and Q403.

The amplitude of oscillation is controlled by an ALC loop that varies the resistance on U405B pin 6 to ground. This resistance comprised of R412 and the drain resistance of Q402, is nominally 2K ohms. The oscillator signal amplitude is sensed by rectifier CR401. The average current through CR401 is made equal to the reference current in R416 by integrator-amplifier U405A. Level adjustment is set by potentiometer R419. Temperature compensation is provided by R417, R418, and CR402.

### 3-56. FM DEVIATION CONTROL

The FM modulation signal source and deviation control circuits are on the Output assembly. Analog switches U401A, U401B, and op-amp U402A select the internal or external modulating signal, or no modulation. The selected and buffered modulating signal at U402A pin 7 is applied to FM DAC U403. This DAC provides fine control of the FM deviation. (The coarse control FM circuitry is part of the Synthesizer assembly). The output of the DAC, at U405C pin 8, is the modulation signal multiplied by a factor proportional to the 8-bit FM deviation control provided by the Controller.

### 3-57. Attenuator PCA, A2A6

The Attenuator PCA A2A6 consists of an Attenuator PCA, A2A6A1, in a metal housing mounted on the top side of the A2 module section to form a shielded enclosure. The Relay Driver PCA, A2A6A5, is included in this assembly.

The Attenuator assembly controlled by the microprocessor provides coarse control of the Signal Generator output level. The high-level signal from the Output PC assembly, A2A4, is applied to the Attenuator which provides 0 dB to 138 dB of attenuation, in 6-dB steps, to this signal before it goes to the Generator RF OUTPUT connector.

If the Generator is equipped with the Reverse Power Protector option, the standard Attenuator A2A6 assembly is replaced with the Attenuator/RPP A2A5 assembly. For a description of this option, refer to Section 6 paragraph 870-1 in this manual.

Compensation data peculiar to the particular attenuator in each Generator is stored in the Attenuator calibration EPROM located on the Controller PCA, A2A8. The instrument program uses this data to correct for the combined deviations of the attenuator sections in use. For more details on level correction, refer to paragraph 3-13, Amplitude Control.

The Attenuator Assembly provides an attenuation range from 0 dB to 138 dB in 6-dB steps and consists of seven independently cascaded 50-ohm attenuation sections, a 6-dB, a 12-dB, and five 24-dB sections. Each section consists of a DPDT relay and a three-resistor attenuator pad.

One relay position (when power is applied to the relay provides a straight path for the RF signal, and the other position (no power applied to the relay) inserts the attenuator pad into the RF signal path. All seven relays are inside individual shielded compartments in the Attenuator housing.



The control of the Attenuator relays is latched via U27, the open-collector drivers U30 and U31 on the Controller PCA A2A8 and transistor drivers on the A2A6A5 Relay Driver PCA (or the A2A5A5 Relay Driver/RPP control PCA). For calibration and troubleshooting purposes, special functions 83 through 86 allow the direct selection of four of the five 24-dB attenuators. The other 24-dB attenuator is selected by programming the appropriate level (-12 dBm).

**3-58. Controller PCA, A2A7**

The Controller, under the direction of the instrument software, handles the data interface between the front panel, remote interface, and Generator functions. The Controller is located in a top side compartment of the module section, A2.

The Controller printed circuit assembly consists of the following functional groups:

- Microprocessor and its interface circuitry
- Attenuator control interface
- Front panel interface
- IEEE-488 Interface
- Memory ICs and addressing circuitry
- Module I/O circuitry
- Reset circuit
- Status and control latches

**3-59. MICROPROCESSOR**

The heart of the Controller assembly is U1, a TMS9995 16/8 bit microprocessor. The digital system clock signal is generated by an oscillator comprised of gates from U5 and crystal U41. When enabled, bidirectional buffer U4 provides additional drive current to the data bus operation; when it is disabled, it isolates the microprocessor from the system data bus. Buffers U33, U34, and U10 provide extra drive current to the microprocessor address and control signals.

**3-60. ATTENUATOR CONTROL INTERFACE**

The attenuator control signals are latched by U27. Darlington drivers U30 and U31 control the Relay Drivers A2A6A5 (or A2A5A5) PCA.

**3-61. FRONT PANEL INTERFACE**

Data is transferred to and from the front panel circuitry through tri-state bidirectional data buffer U18. This buffer is active when a front panel latch is addressed and the buffer control signal from U17 is low; otherwise, it is in the high-impedance state. The front panel latch select lines are decoded by U36. To reduce RF emissions from the Generator, low-pass filters comprised of the following components are used on the following signals:

SIGNALS	COMPONENTS
Signal CLRL	R6 and C51
Latch select SEG1L	R7 and C53
Latch select SEG2L	R8 and C54
Latch select SEG3L	R9 and C55
Latch select SEG9L	R10 and C56
Latch select DIGL	R11 and C57

In addition, capacitors C58 and C59 bypass the display filament supplies. LC filters comprised of L1 and C50, and L2 and C52 are used on the +5 volt and +37 volt supplies to the front panel circuitry.

### 3-62. IEEE-488 INTERFACE

Tri-state bidirectional buffer U2 buffers the data bus to the optional IEEE-488 assembly, A3A3. Address and control lines to the option are buffered by tri-state buffer U3. These buffers are in the high-impedance state when the option is not addressed.

The active low interrupt signal IEINTL from the IEEE-488 option is connected to the level four interrupt on the microprocessor. When the option is not present, IEINTL is pulled up to the inactive state. R1 and C22 form a low-pass filter to suppress digital emissions from the Generator.

### 3-63. MEMORY

The microprocessor uses a 2K-byte RAM (U25) to store program variables. A 32K- and an 8K-byte EPROM (U21 and U22) contain the microprocessor instructions and constant data. Three 2K-byte Calibration EPROMs (U23, U24, U26) contain calibration data for the VCO, Output, and Attenuator or optional Attenuator/RPP assemblies, respectively. Decoders U20 and U14 decode the individual chip selects for the memory ICs.

### 3-64. MODULE I/O

Control data is transferred to the RF circuitry (located in the Module Section, A2) through a byte wide unidirectional data bus. This data is retained on the RF circuit boards in latches. Select lines BSEL0L, BSEL1L, and address lines BAB2 through BAB0 are decoded into individual latch enables on the various RF circuit boards. Tri-state buffers U15 and U16 on the data and address lines provide extra drive current and allow these signals to float when inactive.

Flip-flop U42 gates the module I/O select pulse from U8 with the system clock to delay the leading edges of BSEL0L and BSEL1L to provide adequate latch setup times. D-flip-flop U9 latches address lines BAB2 through BAB0 to provide adequate latch hold times.

### 3-65. RESET

Comparator U7 and its associated circuitry generate the active low reset signal to the TMS9995. The reset signal is generated on power-up or if the +5V supply drops below +5V.

At power-up, R5 and C4 provide a slow-rising reset signal to the microprocessor, and the output of U7 is ignored. When the +5V supply is up, a reference voltage is set at U7 pin 2, the negative terminal. This reference voltage is one diode drop below the voltage at the positive terminal (pin 3). When power is lost, the voltage at the positive terminal falls below the reference voltage held by C3, and the output of U7 is immediately pulled low.

### 3-66. STATUS AND CONTROL

Tri-state buffers U11 and U40 read the three hardware fault detector status signals, UNLVL, UNLOKL and RPTRPL, the seven option status signals HSOPTL, SHREFL, IEINL, RPPL, LRFML, ROPTL, and NVINL, and the status of the REF INT/EXT switch. Control and buffer enable signals are latched by U17.

### 3-67. REAR SECTION, A3

The rear panel section consists of a fuse/filter/line-voltage selector switch A3FL1, a transformer A3T1, a Power Supply PCA A3A1, and a fan, A3B1. The line-selector switch accommodates four line voltages, 100/120/220/240 volts, selected by the orientation of a pullout PCB.

The transformer A3T1, with its two primary windings, accepts these four voltages and produces the necessary five secondary voltages. The power supply PCA A3A1 rectifies, filters, and regulates these secondary voltages to produce the dc voltages required by the

Generator. The 120V ac fan A3B1 is connected to the line selector switch so that it always has the correct voltage, 120V ac (nominal) connection.

#### NOTE

*The power supply for Option -130 High-Stability Reference is separate. It has an automatic change over switch for different input line voltages.*

### 3-68. Power Supply PCA, A3A1

The bridge rectifiers in the power supply are used in either a bridge or full-wave center-tapped configuration with capacitor input filters. Table 3-1 lists the rectifier configurations as well as the component designations for the various supplies.

The two +15V, the -15V, and the +5V supplies use conventional three-terminal IC regulators with internal current-limiting and temperature protection. All three 15V regulators have reverse voltage protection diodes CR3, 4, and 8.

The +37V regulator voltage is adjustable via R3. A 6.2V supply is developed from the +37V supply through resistor R4 and zener diode CR7 and is applied to the center tap of the 6V ac filament supply. This provides grid bias for the front panel displays. All regulators (except +37V) have their common reference terminals brought out to an external ground point on module A2 to reduce power supply ripple (P2).

Triac U6 is a voltage surge protector to protect against line voltage surges as well as overvoltage in case of a wrong setting of the selector switch.

Switch S1 is the REF INT/EXT reference selection switch and is not functionally part of the power supply.

**Table 3-1. Power Supply Rectifier Configurations**

SUPPLY	RECT.	CONFIG.	CAP	REGULATOR	REMARKS
+37	CR6	Bridge	C11	A3A1 U4	Adjustable
+15	CR2	CT/FW	C2	" U5	Fixed
+15	CR2	CT/FW	C2	" U1	Fixed
-15	CR2	CT/FW	C5	" U2	Fixed
+5	CR5	CT/FW	C8	A3 U3	Fixed
+18	CR1	Bridge	C1		Unregulated relay supply
FIL	6V ac with center-tap biased at 6.2V dc.				






# static awareness



A Message From  
**John Fluke Mfg. Co., Inc.**




Some semiconductors and custom IC's can be damaged by electrostatic discharge during handling. This notice explains how you can minimize the chances of destroying such devices by:

1. Knowing that there is a problem.
2. Learning the guidelines for handling them.
3. Using the procedures, and packaging and bench techniques that are recommended.


The Static Sensitive (S.S.) devices are identified in the Fluke technical manual parts list with the symbol




The following practices should be followed to minimize damage to S.S. devices.




1. MINIMIZE HANDLING




3. DISCHARGE PERSONAL STATIC  
BEFORE HANDLING DEVICES




2. KEEP PARTS IN ORIGINAL CONTAINERS  
UNTIL READY FOR USE.




4. HANDLE S.S. DEVICES BY THE BODY



5. USE ANTI-STATIC CONTAINERS FOR HANDLING AND TRANSPORT




6. DO NOT SLIDE S.S. DEVICES OVER ANY SURFACE




7. AVOID PLASTIC, VINYL AND STYROFOAM® IN WORK AREA

PORTIONS REPRINTED  
WITH PERMISSION FROM TEKTRONIX, INC.  
AND GENERAL DYNAMICS, POMONA DIV.



8. WHEN REMOVING PLUG-IN ASSEMBLIES, HANDLE ONLY BY NON-CONDUCTIVE EDGES AND NEVER TOUCH OPEN EDGE CONNECTOR EXCEPT AT STATIC-FREE WORK STATION. PLACING SHORTING STRIPS ON EDGE CONNECTOR USUALLY PROVIDES COMPLETE PROTECTION TO INSTALLED SS DEVICES.



9. HANDLE S.S. DEVICES ONLY AT A STATIC-FREE WORK STATION  
10. ONLY ANTI-STATIC TYPE SOLDER-SUCKERS SHOULD BE USED.  
11. ONLY GROUNDED TIP SOLDERING IRONS SHOULD BE USED.

Anti-static bags, for storing S.S. devices or pcbs with these devices on them, can be ordered from the John Fluke Mfg. Co., Inc.. See section 5 in any Fluke technical manual for ordering instructions. Use the following part numbers when ordering these special bags.

John Fluke Part No.	Description
453522	6" X 8" Bag
453530	8" X 12" Bag
453548	16" X 24" Bag
454025	12" X 15" Bag
Pink Poly Sheet	Wrist Strap
30"x60"x60 Mil	P/N TL6-60
P/N RC-AS-1200	\$7.00
\$20.00	

## **Section 4**

# **Maintenance**

### **4-1. INTRODUCTION**

This section of the manual presents warranty information and service methods. Performance test procedures are presented in Section 4A, access procedures in 4B, calibration adjustment procedures in Section 4C, and troubleshooting and repair information in Section 4D.

Each Signal Generator is warranted for a period of one year following delivery to the original purchaser. The warranty is located in front of Section 1 of this manual.

### **4-2. SERVICE METHODS**

The Signal Generator is designed to be easily and economically serviced. You may return your instrument to Fluke for service, or you may service it yourself, and repair it, if necessary, by module replacement or component replacement.

### **4-3. Fluke Service**

Fluke Service is probably the easiest for you. To ship a Signal Generator to the Fluke Technical Service Center nearest you, see Section 2 for shipping requirements and Section 7 for a list of repair centers. A cost estimate will be provided if you request one and if your instrument purchase date is beyond the warranty period.

### **4-4. Module Replacement**

If your Generator develops a problem, see the Troubleshooting Section 4D for information on identifying the faulty module. With a modest amount of technical knowledge and test equipment, you can identify the faulty module and replace it using the Module Exchange Program. This method takes only a day or two to restore the Generator to proper working order. Very little or no calibration is required depending on the module replaced.

Module exchange is used if it is necessary to completely recalibrate any of the three modules in your Generator that have an associated calibration EPROM.

### **4-5. Parts Replacement**

Parts replacement requires more equipment and service capability but usually offers the best economy and quickest turnaround. It involves part replacement at the customer's facility.

Most faults are detected by the built-in self tests or the UNCAL status circuits. By noting the self-test error code and interrogating the UNCAL status code, the service technician learns where the problem is. By applying normal signal tracing and troubleshooting procedures (see Troubleshooting in Section 4D of the manual), the fault can be quickly identified.

## MAINTENANCE

The faulty component is replaced, and then the instrument is recalibrated using Calibration Adjustments in Section 4C of this manual (if necessary). The Performance Tests explained in Section 4A of this manual are used to verify the Generator performance after repair or recalibration of the Generator.

Some assemblies have some non-field-replaceable parts. These parts, if replaced, would invalidate the calibration EPROM associated with that assembly. They are the Output (A2A4), the VCO (A2A2), and the Attenuator (A2A6) or Attenuator/RPP (A2A5) assemblies. Non-field-replaceable parts are listed in the appropriate parts lists at the bottom of that list.

In the event that a non-field-replaceable part is defective (about 10% of the parts are not field-replaceable), it is necessary for the module to be replaced using the Module Exchange Program in order to realize a complete recalibration of that module and its associated EPROM. Section 7 lists the national and international Sales Representatives and Service Centers.



## Section 4A

# Performance Tests

### 4A-1. INTRODUCTION

The information in the following paragraphs describes the performance tests for the key parameters of the Signal Generator, using the instrument specifications as the performance standard. These covers-on performance tests may be used as an acceptance test upon receipt of the instrument, as an indication that repair and/or calibration is required, or as a performance verification after completing repairs or calibration of the instrument. Individual performance tests can be used as troubleshooting aids.

The Signal Generator being tested (UUT) must be warmed up with all covers in place for at least 20 minutes before starting the performance tests.

### 4A-2. TEST EQUIPMENT

Table 4A-1 gives a list of the recommended test equipment for the performance tests, adjustment procedures, and for troubleshooting the Generator. Figure 4A-1 shows a Two-Turn Loop.




Figure 4A-1. Two-Turn Loop

**MAINTENANCE  
PERFORMANCE TESTS**

**Table 4A-1. Recommended Test Equipment**

INSTRUMENT NAME	MINIMUM REQUIREMENT	MANUFACTURER DESIGNATION	NOTES (1)
DVM	5 1/2-Digit, 0.3% DC-20 kHz	JF 8840A-09	A,P
DMM	3 1/2-Digit, 1% DC and 1 KHz	JF 8020B	A,P,T
Wideband Amplifier	> 25-dB gain, 0.4 to 1050 MHz NF < 9 dB.	HP 8447D-010	P
RF-Spectrum Analyzer	0.1 to 1.5 GHz, 1-kHz BW	HP 8558B/182T	P,T
Oscilloscope	Four-trace 300 MHz, 5-mV/Div	TEK 2465-11	T
FET Probe	DC-900 MHz	TEK 6201	T
RF Voltmeter	0.01 to 700 MHz, 0.01 to 3V $\pm 10\%$	HI RF 801	T, 2
Frequency Counter	0.4-1050 MHz; 10 Hz res; 0.1V	JF 7220A	A,P,T
Modulation Analyzer	Input: 0.4 to 1050 MHz, 0 to AM: 10 to 90%, $\pm 1\%$ , FM: 0.1 to 100 kHz dev $\pm 1\%$	HP 8901A	A,P,T,4
Distortion Analyzer	1 to 10% rng, $\pm 1$ dB, 0.4 and	HP 339B	A,P,T,4
Power Meter Sensor	Instrumentation accuracy < $\pm 1\%$ -30 to 20 dBm; SWR < 1.2 for 0.4 to 1 MHz, < 1.1 for 1 to 1050 MHz	HP 435B HP 8482A	A,P,T,4 4
Low-Level Sensor	-67 to -20 dBm; SWR < 1.4 for 10 to 30 MHz < 1.15 for 30 to 1050 MHz	HP 8484A	4
Attenuator, 60 dB	0.4 to 1050 MHz SWR < 1.1	Narda 777C	P,5
LF Synthesized Sig- Gen	10 Hz to 11 MHz, 10 Hz steps, 1V pk. Spurs and Harm < -50dB	JF 6011A	A,P
Frequency Standard	House Standard, 10 MHz	---	A,P
Test Cable	Dual pin to BNC	JF 732891	A,T
Adapter, Coax	50-ohm, Type-N(m) to BNC(f)	JF Y9308	A,P,T
Adapter, Service	50-ohm, Module output to SMA	JF 744177	T
Two-Turn Loop	For Leakage test (See Figure 4A-1.)	Homebuilt	P,T,3
Type-N Termination	50-ohm	JF Y9317	P
Coaxial Cable, 50 ohm	3 ft, BNC both ends	Y9111	A,P,T
Coaxial Cable, 50 ohm	6 ft, BNC both ends	Y9112	A,P,T
Screwdriver, electric	Set to 7 inch-pounds torque	Jergens- CL6500/CLT50	A,T
Power Supply, Variable	0 to 30V dc		T

**Table 4A-1. Recommended Test Equipment (cont)**

Notes
1. A = Adjustment; P = Performance Test; T = Troubleshooting.
2. Helper Instruments.
3. Two-Turn, 1-inch diameter loop made of #18 enamel wire soldered to a BNC connector. Figure 4A-1 shows a two-turn loop.
4. The HP8902A/11722A Measuring Receiver may be used in place of the wideband amplifier, 60-dB Attenuator, HP8901A, HP339B, and the HP435B/8482A/8484A for the alternate performance test.
5. SWR verified and actual attenuation calibrated to $\pm 0.2$ dB by the operator at application frequencies.

### **4A-3. POWER-ON TEST**

This performance test is the built-in self test that performs a simple functional check of the instrument.

#### **REQUIREMENT**

The Generator successfully passes the self test.

#### **REMARKS**

The test is begun each time the Signal Generator is turned on. Press any of the FUNCTION keys or the [CLR/LCL] key to abort the test.

#### **PROCEDURE**

- a. Start the test with the POWER switch off.
- b. Turn the POWER switch on.
- c. The Signal Generator automatically starts the self tests, which include turning on all indicators, indicators, and every segment of the display. This test takes five seconds.
- d. If the instrument fails any of the self tests, the results are shown in the four display fields. See paragraph 4D-17 for the interpretation of the test failure codes.

If the Generator passes the self test, it programs the Generator to the Instrument Preset state [RCL] [9][8].

If the Signal Generator has the Option -570 Non-Volatile Memory installed, the Generator is returned to the same front panel condition that existed when the Generator was previously turned off. The IEEE-488 Interface (if installed) is programmed to local control.

### **4A-4. SYNTHESIS TEST**

Using a Frequency Counter operating on a common reference with the Generator, the Generator output frequency is measured at several programmed frequencies.

**REQUIREMENT**

The Generator's measured and programmed frequencies agree within  $\pm$  one count.

**TEST EQUIPMENT**

Frequency Counter

**REMARKS**

Failing this test indicates the need to repair and/or recalibrate the Synthesizer A2A1 assembly.

**PROCEDURE**

- a. Connect the UUT 10 MHz IN/OUT to the Frequency Counter 10-MHz reference input, and connect the UUT RF OUTPUT to the Counter input.
- b. Set the UUT REF INT/EXT Switch to INT.
- c. Program the UUT to [RCL] [9][8].
- d. Program the UUT frequency to 111.1111 MHz.
- e. Program the UUT frequency step to 111.1111 MHz.
- f. As the frequency is stepped from 111.1111 MHz, 222.2222 MHz, etc., to 999.9999 MHz, verify that the Counter reading agrees with the UUT frequency  $\pm$  one count.

**4A-5. HIGH-LEVEL ACCURACY TEST**

The output power is measured with a power meter at various frequencies, first with the step attenuator set for zero attenuation, then with each attenuator section individually programmed, the output level accuracy and attenuator section errors are computed.

**REQUIREMENT**

The output level accuracy, the attenuator section errors, and the sum of the attenuator section errors at each test frequency are less than  $\pm$  1.5 dB.

**TEST EQUIPMENT**

Power Meter with a Sensor

**REMARKS**

Failing this performance test indicates the need to replace the Output (A2A4) and/ or the Attenuator (A2A6) (or optional Attenuator/RPP A2A5) assemblies. To determine which assembly is at fault, use Section 4D in this manual for Troubleshooting procedures.

The test frequencies of this procedure provide reasonable confidence of the amplitude accuracy of the UUT. However, additional test frequencies may be included in this test.

This test verifies the high-level accuracy of the Generator and also verifies that the amplitude correction factors for the individual Attenuator sections are correct. This test, in conjunction with the mid-level accuracy and low-level accuracy tests, verifies the overall level performance of the UUT.

# **PROCEDURE**

- a. Calibrate and zero the Power Meter.
- b. Program the UUT to [RCL] [9][8].
- c. Connect the Power Sensor to the UUT RF OUTPUT.
- d. Program the UUT frequency to 0.4 MHz.
- e. Select each attenuator section by programming the UUT amplitude to the levels shown in Figure 4A-2 High-Level Accuracy test conditions, and record the measured power at each level.
- f. For each programmed level of Figure 4A-2, compute the output power error (subtract the programmed power in dBm from the measured power in dBm). These errors must not exceed  $\pm 1.5$  dB.
- g. For attenuator sections 1 through 7, subtract the measured power for section zero from the sum of the measured power for that section and the nominal attenuation for that section, e.g.,  $(-M0+M1+6)$  for section 1. The eight section errors and their sum must not exceed  $\pm 1.5$  dB.

Figure 4A-2 shows the parameters of the high-level accuracy test.

		OUTPUT POWER				
ATTENUATION		PROGRAM	MEASURED	ERROR	SECTION	LIMIT
SECTION	NOMINAL	(dBm)	(dBm)	(dB)	ERROR (dB)	(dB)
0	0	+12	M0	M0-12	M0-12	$\pm 1.5$
1	6	+ 6	M1	M1-6	$-M0+M1+6$	"
2	12	0	M2	M2-0	$-M0+M2+12$	"
3	24	-12	M3	M3-12	$-M0+M3+24$	"
4	24	-12 [SPCL] [8][3]	M4	M4-12	$-M0+M4+24$	"
5	24	-12 [SPCL] [8][4]	M5	M5-12	$-M0+M5+24$	"
6	24	-12 [SPCL] [8][5]	M6	M6-12	$-M0+M6+24$	"
7	24	-12 [SPCL] [8][6]	M7	M7-12	$-M0+M7+24$	"
					Sum of Errors	$\pm 1.5$

**Figure 4A-2. High-Level Accuracy Test Conditions**

*NOTE*

*To test Attenuator sections 4 through 7, program the Signal Generator to -12 dBm, and key in [SPCL][8][3] through [8][6], respectively.*

- h. Repeat steps d through g with the UUT programmed to each of the following frequencies:

120 MHz, 244 MHz, 245 MHz, 850, and 1050 MHz.

To illustrate the procedure, Figure 4A-3 is an example in which the measured power and the error calculations are shown. This example is for one frequency, and these measurements and calculations are repeated at other frequencies. In this case, the section errors and the sum of the section errors are within the test limits and, therefore, the unit passed.

**4A-6. MID-LEVEL ACCURACY TEST**

The level accuracy is verified, from -24 to -66 dBm at frequencies of 120, 244, 245, 850, and 1050 MHz, using the Power Meter with a Low-Level Sensor.

**REQUIREMENT**

Amplitude accuracy is  $\pm 1.5$  dB from +13 to -137dBm.

**TEST EQUIPMENT**

Power Meter with a Low-Level Sensor

**REMARKS**

This test, in conjunction with the High-Level Accuracy Test and the Low-Level Accuracy Test, verifies the overall level performance of the UUT.

It is convenient to use the UUT RF ON/OFF control when zeroing the Power Meter.

**PROCEDURE**

- a. Program the UUT to the Instrument Preset State [RCL][9][8], and then program 30 MHz and -24 dBm.
- b. Calibrate the Power Meter.
- c. Connect the Power Meter with a Low-Level Sensor to the UUT RF OUTPUT.
- d. Zero the Power Meter.
- e. With the Power Meter, measure the UUT output power (in dBm). It should agree with the programmed level within  $\pm 1.5$  dB.
- f. Repeat steps e and f for levels of -30, -36, -42, -48, -54, -60, and -66 dBm.
- g. Repeat steps d to g for frequencies of 244, 245, 850, and 1050 MHz.

		OUTPUT POWER				
SECTION	ATTENUATION	PROGRAM (dBm)	MEASURED (dBm)	ERROR (dB)	SECTION ERROR (dB)	LIMIT (dB)
	NOMINAL					
0	0	+12	+12.2	+0.2	+12.2-12.0	= +0.2
1	6	+ 6	+05.9	-0.1	-12.2+5.9+6	= +0.3
2	12	0	-00.2	-0.2	-12.2-0.2+12	= -0.4
3	24	-12	-12.1	-0.1	-12.2-12.1+24	= -0.3
4	24	-12 [SPCL][8][3]	-11.8	+0.2	-12.2-11.8+24	= +0.0
5	24	-12 [SPCL][8][4]	-12.0	+0.0	-12.2-12.0+24	= -0.2
6	24	-12 [SPCL][8][5]	-12.3	-0.3	-12.2-12.3+24	= -0.5
7	24	-12 [SPCL][8][6]	-11.9	+0.1	-12.2-11.9+24	= -0.1
					Sum of Errors	= -1.0

**Figure 4A-3. High-Level Accuracy Test Conditions**

#### **4A-7. LOW-LEVEL ACCURACY TEST**

The Power Meter with a Low-Level Sensor and the calibrated 60-dB Attenuator are used to verify the UUT level accuracy at -127 dBm and at frequencies of 120, 244, 245, 850, and 1050 MHz, by using the Spectrum Analyzer as an indicator.

#### **REQUIREMENT**

Amplitude accuracy is  $\pm 1.5$  dB from +13 to -137 dBm.

#### **TEST EQUIPMENT**

Wideband Amplifier  
60-dB Attenuator  
RF Spectrum Analyzer  
Power Meter with a Low-Level Sensor

#### **REMARKS**

This test, in conjunction with the Mid-Level Accuracy and High-Level Accuracy Test, verifies the overall level performance of the UUT.

Failing this test, but passing the High-Level Accuracy Test, probably indicates a leak-around problem in the UUT attenuator. Service tip:

Check for a broken feed-through filter or improper mechanical assembly, i.e., loose screws and/or damaged or misplaced gaskets.

It is convenient to use the UUT RF ON/OFF control when zeroing the Power Meter.

## PROCEDURE

- a. Program the UUT to the Instrument Preset State [RCL][9][8], then program 30 MHz and -67 dBm.
- b. Calibrate and then connect the Power Meter with a Low-Level Sensor to the UUT RF OUTPUT.
- c. Program the UUT to -67 dBm.
- d. Zero the Power Meter.
- e. With the Power Meter, measure the UUT output power (in dBm) and record the measurement as the variable P.
- f. Connect UUT RF OUTPUT through the 60-dB Attenuator and the Wideband Amplifier to the input of the RF Spectrum Analyzer. Use well shielded cables to avoid leakage that could affect the measurement.
- g. Adjust the Analyzer to display the signal, using a resolution bandwidth of 1 kHz and a vertical display of 1 dB/Div. Adjust the reference level so that the response is at a convenient reference point on the display, e.g., 2 dB below top scale. This signal response corresponds to a level of (P-A) dBm, where A is the value of the 60 dB Attenuator.
- h. Program the UUT to a level of -127 dBm, remove the 60-dB Attenuator, and note the difference in the resulting response on the Spectrum Analyzer from the previous response (P-A). The actual UUT output level is (P-A) plus this difference and should agree with the programmed level to within  $\pm 1.5$  dB.
- i. Repeat steps c through h for frequencies of 244, 245, 850, and 1050 MHz.

### 4A-8. ALTERNATE-LEVEL ACCURACY TEST

The Measuring Receiver is used to verify the UUT level accuracy from +11 dBm to -127 dBm, and at various amplitude and frequency settings that test all level ranges of the UUT on all RF bands.

## REQUIREMENTS

Amplitude accuracy is  $\pm 1.5$  dB from +13 dBm to -137 dBm.

## TEST EQUIPMENT

Measuring Receiver

## REMARKS

This one test is a more comprehensive test than the High-Level, Mid-Level, and Low-Level Accuracy tests.

Failing this test at levels above approximately -50 dBm indicates the need to replace the A2A4 Output and/or A2A6 Attenuator Assembly (or optional A2A5 Attenuator/RPP).

Failing this test at lower levels probably indicates a leak-around problem with the Attenuator. Check for loose connectors, loose screws, improper gasketing, or a broken feed-through filter.



It is convenient to use the UUT RF ON/OFF control when zeroing the power meter function of the Measuring Receiver.

#### PROCEDURE

- a. Connect the UUT 10 MHz OUT to the 10 MHz timebase input of the Measuring Receiver.
- b. Set the UUT REF INT/EXT switch to INT.
- c. Program the UUT to [RCL][9][8], and then program the UUT to 0.4 MHz, +11 dBm and program the Amplitude Step to 6 dB.
- d. Calibrate the Measuring Receiver and connect it to the UUT RF OUTPUT.
- e. Verify that the level measured with the Measuring Receiver agrees with the UUT programmed level to within  $\pm 1.5$  dB, as the UUT level is stepped down from +11 dbm to -127 dBm in six dB steps at each of the following frequencies:

0.4 MHz, 120 MHz, 244 MHz, 245 MHz, 850 MHz, and 1050 MHz.

#### 4A-9. OUTPUT LEAKAGE TEST

The output signal leakage is verified with a two-turn loop by measuring the induced signal with a spectrum analyzer and comparing it to a 1  $\mu$ V reference established at each frequency from the UUT.

#### REQUIREMENT

The radiated emissions induce less than 1  $\mu$ V of the Generator's output signal into a 1-inch diameter, two-turn loop, 1 inch away from any surface of the Generator as measured into a 50-ohm receiver.

#### TEST EQUIPMENT

Wideband Amplifier  
RF Spectrum Analyzer  
Two-Turn Loop  
Type-N Termination

A screen room may be required depending on the RF environment.

#### REMARKS

Failing this test probably indicates a broken feed-through filter or improper mechanical assembly, i.e.; loose screws and/or damaged or misplaced gaskets.

#### PROCEDURE

- a. Connect the UUT RF OUTPUT to the Wideband Amplifier input, and connect the Amplifier output to the Spectrum Analyzer input. Use well shielded cables to avoid leakage which could affect the measurement.
- b. Program the UUT to the Instrument Preset State, [RCL] [9][8].
- c. Program the UUT to -107 dBm.

- d. Adjust the Spectrum Analyzer to display the UUT signal for a convenient reference, using a vertical scale of 10 dB/division, a resolution bandwidth of 3 kHz, and a span/division of 5 kHz/division.
- e. Disconnect the Amplifier from UUT and terminate UUT OUTPUT with type-N Termination.
- f. Connect the two-turn loop to the Amplifier input.
- g. Program the UUT to +13 dBm.
- h. Verify that the leakage is less than -107dBm (1  $\mu$ V), as indicated by the Spectrum Analyzer by moving the two-turn loop over the UUT surface at a distance of 1 inch.
- i. Repeat steps c through h at 550, 850, and 1050 MHz.

#### **4A-10. ALTERNATE OUTPUT LEAKAGE TEST**

RF leakage is verified by measuring the induced signal in a two-turn loop with the Measuring Receiver.

#### **REQUIREMENTS**

The output signal leakage must induce less than 1  $\mu$ V into a 1-inch diameter two-turn loop, 1 inch away from any surface of the generator as measured into a 50-ohm receiver.

#### **TEST EQUIPMENT**

Measuring Receiver

Two-Turn Loop

Type-N Termination

A screen room may be required depending on the RF environment.

#### **REMARKS**

This test is an alternative to the Output Leakage test.

Failing this test indicates a problem feed-through filter or improper mechanical assembly, i.e., loose screws, and/or damaged or misplaced gaskets.

The Measuring Receiver is used to measure the UUT leakage relative to a 1  $\mu$ V reference established at each frequency.

#### **PROCEDURE**

- a. Connect the UUT 10 MHz OUT to the 10-MHz timebase input of the Measuring Receiver.
- b. Set the UUT REF INT/EXT switch to INT.
- c. Program the UUT to the Instrument Preset State, [RCL] [98].
- d. Program the UUT to -107 dBm.
- e. Connect the Measuring Receiver sensor to the UUT RF OUTPUT.

- f. Set the Measuring Receiver to make relative level measurements to the -107 dBm signal applied.
- g. Disconnect the sensor from the UUT, and terminate the UUT RF OUTPUT with the Type-N Termination.
- h. Connect the two-turn loop to the Measuring Receiver sensor.
- i. Program the UUT to +13 dBm.
- j. Verify the instrument leakage is less than -107 dBm (1  $\mu$ V) as indicated by the Measuring Receiver by moving the Two-Turn Loop over the UUT surface at a distance of one inch from the UUT.
- k. Repeat steps d through j at 550 MHz, 850 MHz, and 1050 MHz.

#### **4A-11. HARMONIC AND SPURIOUS TEST**

Using a spectrum Analyzer, the level of the harmonic and spurious signals are compared to the desired signal at various programmed frequencies.

#### **REQUIREMENTS**

RF harmonics  $\leq -30$  dBc; spurious (non-harmonic)  $\leq -60$  dBc for offsets  $>10$  kHz.

#### **TEST EQUIPMENT**

RF Spectrum Analyzer

#### **PROCEDURE**

- a. Connect the UUT RF OUTPUT to the Spectrum Analyzer input.
- b. Program the UUT to [RCL] [9][8]. Then program the Generator to +13 dBm.
- c. Program the UUT to 0.4 MHz.
- d. Set the Spectrum Analyzer controls to display the UUT output signal and its harmonics (at least three harmonics wherever possible). Be careful not to overload the Analyzer input. Overloading the Analyzer causes it to generate harmonics, thus invalidating the test.
- e. Verify that all the harmonics are more than 30 dB below the fundamental signal.
- f. Repeat steps c through e for UUT frequencies of 50 MHz, 240 MHz, 300 MHz, 500 MHz, and 750 MHz.
- g. Program the UUT to 185 MHz.
- h. Verify the spur at 245 MHz is  $< -60$  dBc.
- i. Program the UUT to 244 MHz.
- j. Verify the spur at 312 MHz is  $< -60$  dBc.
- k. Program the UUT to 244.99 MHz, 0 dBm.

1. Set the Spectrum Analyzer controls for the appropriate reference level, center frequency, span, and resolution to display the UUT signals and spurs frequencies with appropriate noise floor and signal resolution for the following steps.
  1. Verify the spurs at the offsets of 20 kHz, 30 kHz, 35 kHz, and 40 kHz are  $< -60$  dBc.
  2. Verify the spurs at the offsets of 1 MHz and 10 MHz are  $< -60$  dBc.
  3. Program the UUT level to 1 dBm with the EXT AM on at 30% modulation (no external modulation input is applied).
  4. Verify the spurs at 10 MHz, 20 MHz, and 30 MHz are  $< -60$  dBc.
  5. Verify the spurs at 800 MHz, and 1044.99 MHz are  $< -60$  dBc.
  6. Program the UUT to 600 MHz, 0 dBm, EXT AM modulation off.
  7. Verify the spur at 300 MHz is  $< -60$  dBc.

#### **4A-12. MODULATION TESTS**

These tests use the Modulation Analyzer to verify modulation accuracy and residual and incidental modulation of the UUT. The modulation distortion is verified by measuring the demodulated output of the Modulation Analyzer with a Distortion Analyzer. The internal modulation oscillator frequency is measured using the Frequency Counter on the demodulated output of the Modulation Analyzer. Table 4A-2 lists the requirements for the modulation tests.

#### **REMARKS**

Failing this performance test indicates the need for repair and/or recalibration of the associated circuitry.

Where residual noise affects the Modulation Analyzer measurements accuracy, apply correction methods provided by the Modulation Analyzer manufacturer.

**Table 4A-2. Modulation Tests Requirements**

REQUIREMENTS PARAMETER	SPECIFICATION
MOD FREQ	$< \pm 3\%$ at 0.4 or 1 kHz for 20 to 30°C; add $\pm 0.1\%/^{\circ}\text{C}$ outside this range.
AM ACCURACY	$< \pm(2\% + 4\%$ of setting) for internal rates and depths of 90% or less, and peak amplitudes of +13 dbm or less.
AM DISTORTION	$< 1.5\%$ THD up to 30% AM, $< 3\%$ to 70%, $< 5\%$ to 90%, at internal rates.
RESIDUAL AM	$< 0.1\%$ rms ( $-60$ dBc) in a 0.05-kHz to 15-kHz bandwidth.
INCIDENTAL FM	$< 0.3$ fm for internal rates and $< 30\%$ AM.
FM ACCURACY	$< \pm 7\%$ for rates of 0.3 kHz to 20 kHz, and $> 100$ Hz deviation.
FM DISTORTION	$< 1\%$ THD for rates of 0.3 kHz to 20 kHz, and $> 100$ Hz deviation.
RESIDUAL FM	rms in a 0.3-kHz to 3-kHz band: $< 13$ Hz for 245 MHz to 512 MHz and $< 27$ Hz elsewhere. rms in a 0.05-kHz to 15-kHz band: $< 30$ Hz for 245 kHz to 512 MHz and $< 60$ Hz elsewhere.
INCIDENTAL AM	$< 1\%$ AM at 1-kHz rate and for deviation $< 50$ kHz.

The UUT settings in this procedure are chosen to provide a strong confidence of the modulation performance of the UUT throughout its range. However, performance also may be checked at other instrument settings if desired.

The FM deviation accuracy depends upon software correction data stored in the VCO Calibration EPROM that is derived from the measured data of the particular VCO assembly installed in the Generator.

## TEST EQUIPMENT

Modulation Analyzer  
Distortion Analyzer  
Frequency Counter  
Low-Frequency Synthesized Signal Generator (LFSSG)  
DVM

## PROCEDURE

1. Internal Modulation Oscillator Frequency Test
  - a. Connect the UUT RF OUTPUT to the Modulation Analyzer input.
  - b. Connect the Modulation Analyzer modulation output to the Frequency Counter input.
  - c. Program the Modulation Analyzer to measure AM depth in a 0.05-kHz to 15-kHz bandwidth.
  - d. Program the UUT to [RCL][9][8]. Program the UUT for 90% INT AM at a 1-kHz rate and a level of +1 dBm.
  - e. Verify that the Counter reads between 970 and 1030 kHz.
  - f. Program that the UUT to a modulation frequency of 400 Hz.
  - g. Verify the Counter reads between 388 Hz and 412 Hz.
2. Internal AM Accuracy Test
  - a. Measure the mean AM depth,  $(+PEAK \text{ plus } -PEAK)/2$ , with the Modulation Analyzer.
  - b. Verify that the mean AM depth is between 84.4% and 95.6%.
  - c. Program the UUT to a modulation frequency of 1 kHz.
  - d. Verify that the mean AM depth is between 84.4% and 95.6%.
3. AM Accuracy and Distortion Test
  - a. Connect the output of the LFSSG to the UUT MOD INPUT and the DVM (use a BNC T connector).
  - b. Program the UUT for a frequency of 0.4 MHz, 1 dBm level, and EXT AM at 30% AM depth.

- c. Program the LFSSG for 1 kHz at 0.7071V rms as measured by the DVM.
  - d. Connect the modulation output of the Modulation Analyzer to the input of the Distortion Analyzer.
  - e. Set the Distortion Analyzer to measure the THD of the 1-kHz modulation signal.
  - f. Verify that the mean AM depth  $(+PEAK \text{ plus } -PEAK)/2$ , is between 26.8% and 33.2%.
  - g. Verify that the THD is less than 1.5%.
  - h. Program the remaining combinations of RF frequency, level, and AM depth listed in Table 4A-3. For each combination, verify that the mean AM depth is between the allowed limits and that the THD is less than the allowed limit, which depends on programmed depth, as shown in Table 4A-4:
  - i. Disconnect the LFSSG from the UUT.
4. Incidental FM Test
- a. Program the UUT for 30% INT AM at 1 kHz, at 1050 MHz, and 10 dBm.
  - b. Program the Modulation Analyzer to measure peak FM deviation in a 0.3- to 3-kHz bandwidth.
  - c. Verify the incidental FM is less than 300 Hz.

**NOTE**

*It may be necessary to compensate for residual noise effects using the procedure presented in the Modulation Analyzer manual.*

5. Residual AM Test
- a. Program the UUT to 100 MHz, +7 dBm, and no modulation.
  - b. Program the Modulation Analyzer to measure rms (or average) AM in a 0.05-kHz to 15-kHz bandwidth.
  - c. Verify the residual AM is less than 0.1% rms (or 0.09% average).
6. FM Accuracy and Distortion Test
- a. Connect the output of the LFSSG to the UUT MOD INPUT connector and the DVM (use a BNC T connector).
  - b. Program the Modulation Analyzer to measure peak FM in a 0.05-kHz to 20-kHz bandwidth.
  - c. Program the UUT frequency to 245 MHz, 7 dBm, 99.9 kHz (9.99 kHz if the Generator has Option -651) deviation, and EXT FM.
  - d. Set the LFSSG to 10 kHz and adjust its level so the DVM reads 707.1 mV rms.

**Table 4A-3. AM Test Conditions**

FREQUENCY (MHz)	LEVEL (dBm)	AM (%)
0.4	1	30
		70
		90
	7	30
		70
		90
244.9	1	70
		90
		70
	7	70
		90
		70
245	1	70
		90
		70
	7	70
		90
		70
512	1	70
		90
		70
	7	70
		90
		70
1050	1	70
		90
		70
	7	70
		90
		90

**Table 4A-4. AM Depth Range**

PROGRAMMED DEPTH (%)	MEAN AM DEPTH(%)		MAXIMUM THD(%)
	MIN.	MAX.	
30	26.8	33.2	1.5
70	65.2	74.8	3
90	84.4	95.6	5

- e. Set the Distortion Analyzer to measure distortion at 10 kHz.
- f. Verify that the Modulation Analyzer reading is between 93 kHz to 107 kHz, (9.99 kHz if the Generator has Option -651 installed) and the THD is less than 1% as the UUT frequency is stepped up to 1045 MHz in 50-MHz steps. (Tip: use the instrument FREQ STEP feature.)
- g. Set the LFSSG to 0.4 kHz and adjust its level so the DVM reads 707.1 mV rms.
- h. Program the Modulation Analyzer to measure FM in a 0.05-kHz to 3-kHz bandwidth.
- i. Set the Distortion Analyzer to measure distortion at 0.4 kHz.
- j. Verify that the Modulation Analyzer reading is between 93 kHz to 107 kHz (9.99 kHz if the Generator has Option -651 installed), and the THD is less than 1% as the UUT frequency is stepped down to 245 MHz in 50-MHz steps.

- k. Program the UUT to 9.99 kHz deviation. (Skip to step m if the UUT has Option -651 installed.)
- l. Verify that the Modulation Analyzer reading is between 9.3 kHz and 10.7 kHz.
- m. Program the UUT to 0.999 kHz deviation.
- n. Verify that the Modulation Analyzer reading is between 0.93 kHz and 1.07 kHz.

*NOTE*

*It may be necessary to compensate for residual noise effects using the procedure presented in the Modulation Analyzer manual.*

- o. Disconnect the LFSSG from the UUT.

7. Incidental AM Test

- a. Program the UUT for 50-kHz deviation, INT FM only, at 1 kHz, a level of 7 dBm and a frequency of 11 MHz.
- b. Program the Modulation Analyzer to measure peak AM in a 0.3-kHz to 3-kHz bandwidth.
- c. Verify that the incidental AM is less than 1%.

8. Residual FM Test

- a. Program the UUT for a frequency of 4 MHz and no modulation.
- b. Program the Modulation Analyzer to measure rms (or average) FM in 0.3-kHz to 3-kHz bandwidth.
- c. Verify that the Modulation Analyzer reading is less than 27-Hz rms (or 24-Hz average) at the following UUT frequencies:  
  
10, 50, 100, 200, and 244 MHz
- d. Verify that the Modulation Analyzer reading is less than 13-Hz rms (or 12-Hz average) at the following UUT frequencies:  
  
250, 385, 450, and 510 MHz
- e. Verify that the Modulation Analyzer reading is less than 27-Hz rms (or 24-Hz average) at the following UUT frequencies:  
  
512.03999, 750.03999, 850.03999, 900.03999, 950.03999,  
1000.03999, 1025.03999, and 1049.03999 MHz
- f. Change the Modulation Analyzer bandwidth from 0.05 kHz to 15 kHz.



- g. Verify that the Modulation Analyzer reading is less than 60-Hz rms (or 54-Hz average) at the UUT frequencies listed in step e.
- h. Verify that the Modulation Analyzer reading is less than 30-Hz rms (or 27-Hz average) at the UUT frequencies listed in step d.
- i. Verify that the Modulation Analyzer reading is less than 60-Hz rms (or 54-Hz average) at the UUT frequencies listed in step c.



## Section 4B

# Access Procedures

### 4B-1. INTRODUCTION

The information in this section describes the general access procedures for the following major module assemblies.

Front Section Assembly, A1  
Rear Section Assembly, A3  
Synthesizer Board, A2A1  
Output Board, A2A4  
Attenuator Assembly A2A6, or the Attenuator/RPP Assembly, A2A5  
VCO Board, A2A2

Access to other assemblies is straightforward; and therefore, other assemblies are not detailed in this manual.

### 4B-2. LOCATION OF MAJOR ASSEMBLIES

The location of the major assemblies of the Signal Generator is illustrated in Section 8.

Information on exchanging modules is presented in Section 4D.

### 4B-3. ACCESS INSTRUCTIONS

Access instructions for each module of the Signal Generator are provided in the following paragraphs. Before performing any disassembly of the Signal Generator, remove the power cord from the rear panel power receptacle and remove the exterior top and bottom instrument covers.

To install the assemblies, reverse the disassembly steps. Be certain the pin connectors and filter sockets are straight when replacing the boards.

### 4B-4. Removing the Front Section Assembly, A1

1. Disconnect the MOD INPUT wire W1 at the module connector located at the front of the Attenuator module.
2. Disconnect the front panel display ribbon cable at the controller.
3. Remove the decals from both front panel handles. Removing the decals ruins them; new decals should be installed to maintain a proper instrument appearance.

The part number for the decal is listed in Section 5.

4. Remove the five flathead screws from each front panel handle.

#### **4B-5. Removing the Rear Section Assembly, A3**

1. Disconnect the Synthesizer, Controller, and Attenuator power cable at the power supply.
2. If the High-Stability Reference option is installed, disconnect the oscillator power cable from the Auxiliary power supply
3. Remove the IEEE-488 Interface assembly (if present) from the back of the instrument rear panel.
4. Remove the inside part of the 10 MHz IN/OUT (and the REF IN, if present) BNC connector.
5. Remove the decals for both rear panel handles. Removing the decals ruins them; replace with new decals to maintain a proper instrument appearance. The part number for the decal is listed in Section 5.
6. Remove the five flathead screws from each handle and swing the rear panel assembly out from the Signal Generator.
7. If you need to completely detach the rear panel assembly from the Generator, unfasten the front panel power switch.

#### **4B-6. Removing the Synthesizer Board, A2A1**

1. Remove the number 6 screws holding the top module (A2) cover. (The number 10 screws are adjustment access screws and need not be removed.) Remove the module cover.
2. If the Sub-Harmonic Reference option is installed, remove the RG188 pigtail connector, and remove the Sub-Harmonic Reference option board.
3. Remove the heat sink from both gate arrays U17 and U33.
4. Remove the 4/40 panhead screw, shoulder washer, and insulator from the regulator U25.
5. Remove the number 6 screws holding the board, and then carefully remove the board.

#### **4B-7. Removing the Output Board, A2A4**

1. Remove the number 6 screws holding the bottom module (A1) cover. (The number 10 screws are adjustment-access screws and need not be removed.) Remove the module cover.
2. Remove the plug-in coupling capacitor between the Output and the VCO boards.
3. Remove the number 6 screws holding the board, and then carefully remove the board.

#### **4B-8. Removing the Attenuator A2A6, or Attenuator/RPP A2A5 Assembly**

1. Disconnect the SMA connector at the Attenuator that leads to the RF output.

2. Disconnect the control harness from the Relay Driver PCA.

**4B-9. Removing the VCO Board, A2A1**

1. Remove the number 6 screws holding the bottom module (A) cover. (The number 10 screws are adjustment-access screws and need not be removed.) Remove the cover.
2. Remove the plug-in capacitor that couples the Output board to the VCO.
3. Remove the number 6 screws holding the assembly, and remove the board.



## **Section 4C**

# **Calibration Adjustments**

### **4C-1. INTRODUCTION**

The adjustment procedures for the Generator are described in the following paragraphs. The recommended test equipment for calibration is denoted by an A in Table 4A-1.

Adjustment procedures for the Power Supply, Display, Output, Synthesizer, and Attenuator (or optional Attenuator/RPP) assemblies are covered in this section. Adjustment procedures for the High-Stability Reference, Sub-Harmonic Reference, and Low-Rate FM options are given in Section 6.

### **4C-2. SAFETY**

This is a Safety Class I instrument. It is provided with a protective earth terminal. Warnings and cautions are for your protection and to avoid damage to the equipment. Please take them seriously.

#### **WARNING**

**BECAUSE SOME SERVICE PROCEDURES DESCRIBED HERE ARE DONE WITH POWER APPLIED TO THE SIGNAL GENERATOR AND WITH PROTECTIVE COVERS REMOVED, SERVICE SHOULD BE DONE ONLY BY TRAINED SERVICE PERSONNEL WHO UNDERSTAND THE HAZARDS INVOLVED. WHERE SERVICE CAN BE PERFORMED WITHOUT POWER APPLIED, THE SIGNAL GENERATOR SHOULD BE UNPLUGGED FROM THE LINE POWER.**

**DO NOT INTERRUPT THE PROTECTIVE GROUNDING CONNECTION. TO DO SO WOULD CREATE A POTENTIAL SHOCK HAZARD THAT COULD RESULT IN PERSONAL INJURY. SECURE THE INSTRUMENT AGAINST UNINTENDED OPERATION IF IT IS LIKELY THAT THIS PROTECTION HAS BEEN IMPAIRED. USE ONLY 250V FUSES OF THE PROPER CURRENT RATING.**

#### **CAUTION**

**To avoid damage to the Generator, unplug the instrument before removing any Printed Circuit Assembly.**

### **4C-3. POWER SUPPLY, A3A1, ADJUSTMENT**

This procedure covers the +37V adjustment, R3, on the Power Supply assembly, A3A1. This is the only adjustment on the Power Supply PCB.

## TEST EQUIPMENT

DMM

## REMARKS

This adjustment is accessible through a hole in the bottom lip of the rear panel.

See Figure 4C-1 for the location of the power supply test points.

## PROCEDURE

R3 is adjusted for +37V as measured at TP5.

1. Remove the UUT top and bottom instrument covers. Connect the DMM to TP5 with the ground lead (black wire) connected to the power distribution connection point on the module plate.
2. Program the UUT to [RCL] [9][8].
3. Adjust R3 for a DMM reading of  $+37.00 \pm 0.05V$ .
4. Verify the other supply voltages at the test points listed in the following:

TP	Voltage Limits
11	14.5 to 15.7
3	14.5 to 15.7
2	-14.5 to -15.7
4	4.85 to 5.20
1	17.4 to 22.6

## NOTE

*The voltage at TP1 depends on the line voltage. The limits shown are for a line voltage exactly equal to the line voltage selector setting, i.e., 100, 120, 220, or 240V ac.*

5. Remove the test leads, and reinstall the top and bottom instrument covers.

## **4C-4. DISPLAY ASSEMBLY, A1A1, ADJUSTMENT PROCEDURE**

This procedure covers the adjustment of R16, the external modulation level indicator adjustment.

## TEST EQUIPMENT


DVM

## REMARKS

This adjustment is independent of other adjustments and assumes proper circuit operation.

Adjustment R16 is located below TP1 on the rear of the Display PCA, just above the POWER switch.





**Figure 4C-1. Power Supply Test Points**

## PROCEDURE

Adjust R16 for 0.98V at TP1.

1. Gain access to the rear of the Display PCA by removing the top instrument cover.
2. Connect the DVM to measure the dc voltage at TP1 relative to the chassis.
3. Adjust R16 for  $+0.9800 \pm .0005$  V dc.

## 4C-5. OUTPUT ASSEMBLY, A2A4, ADJUSTMENT

This procedure covers all of the adjustments on the A2A4 Output PCA, as follows:

1. R309, LEVEL DAC offset
2. R419, modulation oscillator level
3. R144, linearizer detector offset
4. R421, AM depth
5. R311, RF level
6. R227, Het level

These adjustments, as well as TP7, are accessible by removing the seven number 10 access screws in the module cover. Refer to Figure 4C-2 to identify the access screw corresponding to a particular adjustment.

Any adjustment can be made independently unless it is noted that it interacts with another adjustment. Interdependent adjustments must be done in the sequence presented. If more than one adjustment is necessary, do them in the sequence presented.

1. Level DAC Offset Adjustment

## TEST EQUIPMENT

DVM

## REMARKS

This adjustment is normally required only when U302 or any associated components are replaced or when the adjustment has been changed or has shifted.


## CAUTION

**This adjustment directly affects the output level and should not be adjusted indiscriminately.**

## PROCEDURE

The LEVEL DAC Offset, R309, is adjusted for  $0 \pm 0.5$  mV at TP7 with the RF OUTPUT turned OFF.

- a. Gain access by removing the bottom instrument cover and removing the access screws for TP7 and R309.
- b. Program the UUT to [RCL][9][8], and program the RF OUTPUT to OFF.
- c. Connect the DVM to measure the voltage between TP7 and the power distribution connection point on the module plate.



**Figure 4C-2. Module Plate, Bottom View**

- d. Adjust R309 for an indication of  $+0 \text{ mV} \pm 0.5 \text{ mV}$ .
- e. Program the UUT RF OUTPUT to ON.
- f. Replace the access screws.

## 2. Modulation Oscillator Level Adjustment

This adjustment sets the modulation oscillator level.

### TEST EQUIPMENT

Modulation Analyzer

DVM

Low Frequency Synthesized Signal Generator (LFSSG)

### REMARKS

The modulation oscillator adjustment is normally required only when components in the modulation oscillator or modulation switching circuits have been replaced or the adjustment has been changed or has shifted.

### PROCEDURE

The AM depth, with internal modulation, is adjusted via R419 to equal the AM depth with a 1-volt peak external modulation signal as measured with the Modulation Analyzer.

- a. Gain access to the access screws for R419 by removing the bottom instrument cover and the access screws for R419.
- b. Connect the output of the LFSSG to the UUT MOD IN connector and the DVM using a BNC tee.
- c. Program the UUT to RCL 98, then program the UUT to 350 MHz, 7 dBm, and EXT AM at 90% AM depth.
- d. Program the LFSSG for 1 kHz and a voltage of 0.7071V rms, as measured by the DVM.
- e. Connect the UUT RF OUTPUT connector to the Modulation Analyzer RF input.
- f. Program the Modulation Analyzer to measure + Peak AM in a 0.3-kHz to 15-kHz bandwidth.
- g. Note the measured AM depth reading with the Modulation Analyzer.
- h. Turn off the UUT EXT AM control and turn on the INT AM control.
- i. Program the UUT for 1000-Hz modulation frequency.
- j. Adjust R419 for an AM depth equal to that noted in step g.
- k. Turn off the UUT INT AM control.

1. Replace the access screw.

### 3. Detector Offset Adjustment

This adjustment sets the detector offset voltage.

#### TEST EQUIPMENT

Power Meter and Sensor

#### REMARKS

The UUT must be operated at room temperature for at least one hour with the module plate cover in place before continuing with this adjustment procedure.

This adjustment is normally required only when components in the detector or detector linearizer circuits have been replaced or when the adjustment has been changed or has shifted. If the Detector Offset is adjusted, perform the AM Depth adjustment.

#### CAUTION

**This adjustment directly affects the output level and should not be adjusted indiscriminately.**

#### PROCEDURE

The Detector Offset adjustment, R144, is adjusted to provide a 20-dB change in output power for a 20-dB change in the LEVEL DAC with level correction disabled, and while operating in fixed range.

- a. Gain access for this adjustment by removing the instrument bottom cover.
- b. Program the UUT to [RCL] [9][8], then program the UUT to 350 MHz and 12 dBm.
- c. Program the UUT to [SPCL] [8][1] and [SPCL] [9][1]. These special functions disable all level correction and enable amplitude fixed-range.
- d. Remove the Detector Offset adjustment access screw from the bottom module plate cover.
- e. Zero the Power Meter.
- f. Connect the Power Sensor to the UUT RF OUTPUT connector.
- g. Program the UUT to +12 dBm.
- h. Note the Power Meter reading.
- i. Program the UUT for -8 dBm, using the EDIT keys.
- j. Adjust the Detector Offset adjustment, R144, for a Power Meter reading 20 dB  $\pm$ 0.1 dB below the reading obtained in step h.

- k. Repeat the previous four steps until the difference between the power measurements is  $20 \pm 0.1$  dBm. This adjustment should require three or fewer iterations.

Program the UUT to +12 dBm, using the EDIT keys. Note the Power Meter reading.

- l. Program the UUT for +2 dBm using the EDIT keys. Verify that the Power Meter reading is  $10 \text{ dB} \pm 2 \text{ dB}$  below the previous reading.
- m. Program the UUT for [SPCL] [0][0]. This enables amplitude level correction and disables amplitude fixed range.
- n. Disconnect the Power Sensor from the UUT, and replace the Detector Offset adjustment access screw.

#### 4. AM Depth Adjustment

#### TEST EQUIPMENT

DVM

Modulation Analyzer LFSSG

#### REMARKS

The UUT must be operated at room temperature for at least one hour with the module plate covers in place before continuing with this adjustment procedure.

#### CAUTION

**This adjustment directly affects the output level and should not be adjusted indiscriminately.**

This adjustment is normally required only when components in the AM signal processing circuits have been replaced, or the adjustment has been changed or shifted. If this adjustment is made, it is necessary to perform the RF level adjustment after the AM depth adjustment has been made.

#### PROCEDURE

Adjust the AM depth potentiometer R421 for 90% AM depth as measured with the Modulation Analyzer when the UUT is programmed to 90% AM.

- a. Remove the AM depth adjustment access screw from the bottom module plate cover.
- b. Connect the output of the LFSSG to the UUT MOD IN connector and to the DVM using a BNC Tee.
- c. Program the UUT to [RCL] [9][8], then program the UUT for 350 MHz, +1 dBm, and EXT AM at 90% AM depth.
- d. Program the LFSSG for 1 kHz and a voltage of 0.7071 rms, as measured by the DVM.

- e. Connect the UUT RF OUTPUT connector to the Modulation Analyzer input.
- f. Program the Modulation Analyzer to measure AM + Peak, in a 0.05-kHz to 15-kHz bandwidth.
- g. Alternately measure + PEAK and – PEAK and adjust the AM Depth Adjustment, R421, until the readings are symmetrical, about 90%.
- h. Replace the AM Depth adjustment access screw.

## 5. RF Level Adjustment

### TEST EQUIPMENT

Power Meter and Sensor

### REMARKS

The UUT must be operated at room temperature for at least one hour with the module plate covers in place before continuing with this adjustment procedure.

This adjustment is required if any of the following events occur:

The Output Assembly, A2A4, or the Attenuator, A2A5 or A2A6, has been replaced.

The AM Depth adjustment is made.

The LEVEL DAC or any associated components are replaced.

The RF level adjustment has been inadvertently changed or shifted.

### CAUTION

**This adjustment directly affects the output level and should not be adjusted indiscriminately.**

### PROCEDURE

With the UUT programmed to +9 dBm, adjust the RF Level Adjustment, R311, for +9-dBm output as measured with the Power Meter.

- a. Program the UUT to [RCL][9][8], then program the UUT to 350 MHz, +9 dBm, and turn all modulation OFF.
- b. Zero the Power Meter.
- c. Remove the RF Level Adjustment access screw from the bottom module plate cover.
- d. Connect the Power Sensor to the UUT RF connector.
- e. Adjust RF Level Adjustment, R311, for a reading of exactly +9 dBm on the Power Meter.

- f. Replace the RF Level Adjustment access screw.

#### 6. HET Level Adjustment

##### TEST EQUIPMENT

Power Meter and Sensor

##### REMARKS

The UUT must be operated at room temperature for at least one hour with the module plate covers in place before continuing with this adjustment procedure.

This adjustment is normally required only when components in the het band circuits have been replaced or when the adjustment has been changed or has shifted.

#### **CAUTION**

**This adjustment directly affects the output level and should not be adjusted indiscriminately.**

##### PROCEDURE

With the UUT programmed to +9 dBm, adjust the Het Level Adjustment, R227, for equal output power at 100 MHz and 350 MHz.

- a. Program the UUT to [RCL][9][8], then program the UUT to 350 MHz and +9 dBm.
- b. Zero the Power Meter.
- c. Remove the het level adjustment access screw from the bottom module plate cover.
- d. Connect the Power Sensor to the UUT RF OUTPUT connector. Note the Power Meter reading.
- e. Program the UUT to 100 MHz.
- f. Adjust Het Level Adjustment, R227, for a reading equal to that previously noted.
- g. Replace the HET level adjustment access screw.

#### **4C-6. SYNTHESIZER ASSEMBLY, A2A1 ADJUSTMENT**

The following are the routine adjustments for the Synthesizer assembly, A2A1.

1. C153 10-MHz Adjustment
2. R82 FM Cal Adjustment  
R90 Low-Rate Deviation Adjustment  
R87 FM Flatness Adjustment



The following only need adjustment if the associated circuits are repaired.

3. L49 20-kHz Notch Filter Adjustment  
L50 40-kHz Notch Filter Adjustment
4. R104 VCO Upper Clamp Adjustment
5. C206 800-MHz Oscillator Adjustment

Each of the following adjustment procedures is independent; that is, they can be done individually or in any sequence. Figure 4C-3 shows the top view of the module plate.

#### 1. Reference Frequency Adjustment, C153

### TEST EQUIPMENT

Frequency Standard  
Oscilloscope

### REMARKS

The accuracy of this adjustment depends on that of the frequency standard.

The Signal Generator may be equipped with either Option -130 High-Stability Reference, Option -131 Sub-Harmonic Reference, or both. The frequency reference operation and adjustment procedure depend on this configuration. That is, the instrument reference may be the 10-MHz crystal oscillator, the High-Stability Reference, or an external signal. If the Sub-Harmonic Reference option is present, and external reference operation is selected, the 10-MHz crystal oscillator is locked to the external reference signal.


This procedure applies to standard instruments or instruments with only the Sub-Harmonic Reference. If the UUT is equipped with the High-Stability Reference, use the adjustment procedure for the High-Stability Reference in Section 6 of this manual. If the Sub-Harmonic Reference Option is also installed, also perform the Sub-Harmonic Reference Option Adjustment described in Section 6 of this manual.

### PROCEDURE

The UUT reference waveform is viewed on the Oscilloscope while triggering on the Frequency Standard. The 10-MHz adjustment, C153, is adjusted for a stationary display.

- a. Remove the instrument top cover and the 10-MHz adjustment access screw from the module plate cover.
- b. Connect the UUT rear panel 10 MHz IN/OUT to the Oscilloscope vertical input.
- c. Connect the Frequency Standard output to the Oscilloscope external trigger input.
- d. Set the UUT rear panel REF INT/EXT switch to INT, and set the vertical controls of the Oscilloscope to display the UUT 10-MHz signal.
- e. Set the Oscilloscope for external triggering, and adjust the timebase for 0.1 us/div.

**MAINTENANCE**  
**CALIBRATION ADJUSTMENTS**



**Figure 4C-3. Module Plate, Top View**

- f. Adjust C153 for a drift of less than one cycle per second.

## 2. FM Adjustments, R82, R90, AND R87

### TEST EQUIPMENT

Modulation Analyzer  
LFSSG  
DVM

### REMARKS

The FM Cal adjustment, R82, sets the overall deviation accuracy, whereas the Low-Rate Deviation Adjustment, R90, equalizes the low and high rate deviation. The FM Flatness Adjustment, R87, equalizes the deviation across the band from 0.4 to 10 kHz.

### PROCEDURE

The FM deviation of the UUT, as measured with the Modulation Analyzer, is adjusted to agree with the programmed deviation at 10-kHz and 0.4-kHz rates by adjusting R82, R90, and R87, respectively.

- a. Remove the instrument cover and the FM CAL, FM flatness, and Low-Rate Deviation adjustment access screws from the cover of the module plate.
- b. Connect the output of the LFSSG to the UUT MOD IN connector and to the DVM using a BNC tee.
- c. Connect the UUT RF OUTPUT to the Modulation Analyzer input.
- d. Program the Modulation Analyzer to measure FM + peak in a 0.05-kHz to > 200-kHz bandwidth.
- e. Program the UUT to the [RCL] [9][8]. Then program the UUT to 385.5-MHz, 7 dBm, EXT FM, 99.9-kHz deviation.
- f. Program the LFSSG to 10 kHz and 0.7071V rms as measured by the DVM.
- g. Adjust R82 for 100.0 kHz, as measured by the Modulation Analyzer.
- h. Program the LFSSG to 0.4 kHz and 0.7071V rms, as measured by the DVM.
- i. Adjust R90, the low-rate deviation for 100.0 kHz, as measured on the Modulation Analyzer.
- j. Program the LFSSG to 1 kHz, and adjust R87 for 100.0 kHz as measured on the Modulation Analyzer.
- k. Repeat steps f through j until the deviation flatness is 100.0 kHz  $\pm$  0.3 kHz.
- l. Turn the UUT EXT FM off, and note the Modulation Analyzer peak deviation (noise) reading.

**MAINTENANCE**  
**CALIBRATION ADJUSTMENTS**

- m. Turn the UUT EXT FM on.
- n. Program the LFSSG to 10 kHz and 0.7071V rms as measured by the DVM.
- o. With the Modulation Analyzer, alternately measure +peak and -peak FM, and adjust R82 so the readings are symmetrical, about 99.9 kHz plus the noise noted in step l.

3. L49 20-kHz and L50 40-kHz Notch Filter Adjustments

TEST EQUIPMENT

RF Spectrum Analyzer  
LFSSG

REMARKS

These adjustments are normally not required unless L49, L50, C123, C99, C124, C126 or C125 are replaced, or unless the Generator has been subjected to severe usage.

PROCEDURE

The 20-kHz and 40-kHz notch adjustments, L49 and L50, are adjusted for sideband level nulls using the RF Spectrum Analyzer.

- a. Remove the instrument and the module plate top covers.
- b. Connect the LFSSG to TP56 (high) and TP36 (low) using clip leads.
- c. Program LFSSG to 20 kHz and 0.2V rms, terminated.
- d. Connect the UUT RF OUTPUT to the RF Spectrum Analyzer input.
- e. Program the UUT to 300 MHz and +13 dBm.
- f. Adjust the RF Spectrum Analyzer to display the signal centered on the display.
- g. Set the span to 10 kHz/division and 1-kHz bandwidth. The 20-kHz sidebands should be visible.
- h. Adjust L49 to minimize the 20-kHz sidebands.
- i. Program the LFSSG to 40 kHz.
- j. Adjust L50 to minimize the 40-kHz sidebands.

4. VCO Upper Clamp Adjustment, R104

TEST EQUIPMENT

Frequency Counter

REMARKS

This adjustment is normally required when the VCO is replaced or when the Generator has been subjected to severe usage.

## PROCEDURE

The UUT PLL loop is disabled to cause the VCO frequency to be at the upper limit of its range, then R104 is adjusted for 530 MHz.

- a. Remove the instrument and module plate top covers.
- b. Connect UUT RF OUTPUT to the Frequency Counter input.
- c. Program the UUT to [RCL] [9][8]; then, program the UUT for 500 MHz and +13 dBm.
- d. Using a clip lead, short TP14 to ground to cause the VCO to go to the upper frequency limit.
- e. Adjust R104 for 530 MHz  $\pm$  1 MHz.

### 5. 800-MHz Oscillator Adjustment, C206

## TEST EQUIPMENT

Frequency Counter  
DMM

## REMARKS

This adjustment is normally not required unless components in the 800-MHz oscillator are replaced or the Generator has been subjected to severe usage.

## PROCEDURE

The PLL control voltage operating point is adjusted to 16V while the loop is phase-locked.

- a. Remove the instrument and the module plate top covers.
- b. Program the UUT to [RCL] [9][8]; then, program 200 MHz.
- c. Connect the DMM to measure voltage between TP53 and the chassis.
- d. Adjust C206 for 16.0V  $\pm$  0.5V.



## **Section 4D**

# **Troubleshooting and Repair**

### **4D-1. INTRODUCTION**

Usually, the Generator is most easily repaired by identifying the defective module and replacing it through the Module Exchange Program. Alternately, you may wish to troubleshoot down to the component level and replace the defective part. This section of the manual provides the necessary information for both repair methods.

After any module repair or replacement, the Performance Tests should be done to verify the performance of the Generator. Signal Generator problems are generally caused by operator error, out-of-spec performance, or by catastrophic failure. The correction strategy is different in each case.

Although most operator errors are detected and indicated, some are not, and therefore, may be mistaken for an out-of-spec condition. Those operator errors that are detected are indicated with either a steady or flashing 'UNCAL' indicator. Consult the Generator Specifications in Table 1-1 and Section 2 in this manual for more information on Generator operation.

Out-of-spec performance is usually corrected by performing the appropriate adjustment procedure(s). Use the Performance Tests to determine which parameters need adjustment. Refer to adjustment paragraphs in this section for more information.

If the problem is not an operator error and is not corrected by adjustment, the Generator has a catastrophic failure. Then the task is to isolate the fault and make appropriate repairs. The UNCAL and self-test failure codes usually provide a good indication of the cause of the problem. Using the Performance Tests in this situation may help to determine which parameters are not affected.

### **4D-2. MODULE REPLACEMENT**

This repair method involves identifying and replacing the problem module. The replacement module may be obtained using the Module Exchange Program or from your spare module stock, which may then be restored using the Module Exchange Program.

Use the information in the Troubleshooting section to diagnose the problem. To help you identify the problem module, you may call your local Fluke Technical Center for troubleshooting assistance. Once the Fluke service technician believes the problem module is identified, a replacement module can be shipped prepaid by an overnight air carrier.

After the operator verifies that the replacement module corrects the problem, return the defective module using the shipping container and including the prepaid return shipping papers and label.

**NOTE**

*The Attenuator, Output, and VCO assemblies are individually calibrated, and the correction data are stored in the associated calibration EPROMS.*

**CAUTION**

**If any of these assemblies needs calibration or if any non-field replaceable part needs repair, order a replacement using the Module Exchange Program.**

To order a replacement module, use the part number for the assembly shown in the List of Parts and specify a Module Exchange part. Table 4D-1 shows a list of replaceable assemblies. To order any new assembly, refer to Section 5 for the part number. (New assemblies are ordered by referring to the same part number). Note that two versions of the Synthesizer assembly are available, one with the Low-Rate FM option and one without the option. The following paragraphs describe the available exchange modules, how to install them, and how to adjust the Generator, if necessary, after installation.

**Table 4D-1. Module Exchange Assemblies**

A1A1 Display PCA
A2A1 Synthesizer PCA
A2A2 VCO PCA
A2A4 Output PCA
A2A6 Attenuator Assembly
A2A6A4 Attenuator PCA
A2A6A5 Relay Driver PCA
A2A7 Controller PCA
A3A1 Power Supply PCA

**4D-3. Power Supply PCA, A3A1**

The Power Supply PCA comes complete with the 5V regulator, A1U3, its socket, and a set of insulated washers for all of the chassis-mounted regulators.

No adjustment is required after installation of the new PCA, but the power supply voltages should be verified, using the last step of the Power Supply Adjustment procedure in this section.

**4D-4. Sub-Harmonic Reference PCA, A2A3**

This module comes ready to install. After installation, perform the Reference Frequency Adjustment procedure for the Sub-Harmonic Reference option.

**4D-5. Synthesizer PCA, A2A1**

Under the Module Exchange Program there are two versions of the A2A1 Synthesizer assembly available. One has the Low-Rate FM option installed on the Synthesizer PCA and the other does not. Therefore, when ordering a replacement Synthesizer module be sure to specify whether or not the Generator being repaired has the Low-Rate FM option.

Also, before replacing the Synthesizer PCA it is important to note what other options are in the Generator and carry out the following instructions pertaining to the option complement of the Generator. If the Low-Rate FM option is present, verify that S1 on the PCB option is set for Low-Rate operation. (See Section 6.)

After the new Synthesizer PCA has been installed, perform the FM CAL, VCO CLAMP, and 10-MHZ adjustments as described in the Synthesizer Adjustment Procedure in Section 4C of this manual. Perform any other adjustments related to the options.



If the Generator has the Sub-Harmonic Reference option installed (which mounts atop the Synthesizer PCA), this option must be removed before removing the Synthesizer PCA. Then L54, C171, and CR20 must be moved from the old Synthesizer PCA to the new PCA. Also C154 on the new PCA must be removed (by clipping it out with a wire cutter). After the Synthesizer and the Sub-Harmonic Reference option PCBs have been installed, the Reference Frequency Adjustment procedure for the Sub-Harmonic Reference option should be done, instead of the 10-MHZ adjustment mentioned above. Refer to Section 6 for this adjustment.

#### **4D-6. VCO PCA, A2A2**

The VCO assembly comes with its associated VCO Calibration EPROM. This EPROM replaces the old one installed on the Controller PCB, A2A7. After installing the new VCO assembly, the FM CAL and VCO CLAMP adjustments should be done. These adjustments are presented under the Synthesizer Adjustment Procedure.

A plug-in coupling capacitor is used to interconnect the VCO and Output PCBs, thus eliminating the need for a soldering iron when replacing this assembly.

#### **4D-7. Output PCA, A2A4**

The Output assembly comes with its associated Output Calibration EPROM. This EPROM replaces the old one installed on the Controller PCB. After installing the new Output assembly, perform the level DAC offset, the RF Level, the HET level, and the FM CAL adjustment procedures given in the Calibration Adjustment Section of this manual.

A plug-in coupling capacitor is used to interconnect the VCO and Output PCBs, eliminating the need for a soldering iron when replacing this assembly.

If the Generator is equipped with the Low-Rate FM option, then it is necessary to add a jumper around C401 and C402 on the new Output assembly before installing it.

#### **4D-8. Controller PCA, A2A7**

The Controller assembly comes without the three calibration EPROMs. Therefore, it is necessary to move these EPROMs from the old to the new Controller. Remember to set the option status switch. No adjustments are required.

#### **4D-9. Display PCA, A1A1**

After installing a new Display PCA, the Modulation Indicator adjustment should be done. The procedure is presented under the Display Adjustment Procedure.

#### **4D-10. Attenuator (Attenuator/RPP) PCA, A2A6 (A2A5)**

The Attenuator or the optional Attenuator/RPP PCA comes complete with the housing, Relay Driver PCA and matching Attenuator Calibration EPROM, and comes ready to install. The matching EPROM replaces the Attenuator calibration EPROM on the Controller PCA. After the new Attenuator assembly is installed, perform the RF Level Adjustment procedure on the A2A4 Output PCA in the Calibration Adjustments section of this manual.

#### **4D-11. IEEE-488 PCA, A3A3**

The IEEE-488 assembly comes complete with panel, frame, and connector and is ready to plug in. No adjustments are required after installation.

#### **4D-12. Non-Volatile Memory PCA, A2A8**

The Non-Volatile Memory assembly comes ready to plug in, and requires no adjustment after installation.

#### **4D-13. PARTS REPLACEMENT**

An experienced technician should be able to isolate the defective component and replace it after reading the information presented in Section 3, the Theory of Operation and the troubleshooting information contained in this section. The Schematics are presented in Section 8 (Section 6 for the options) of this manual.

Most parts are replaced using ordinary methods. The parts requiring special attention are the chip components located on the A2A2 VCO PCA. The chip components should be replaced using a 600°F soldering iron, such as an Ungar 50T7 with a number 76 heater and a number 88 tip, and 2% silver solder paste, such as Electro Science Fabrication SP-37D1 or similar wire solder.

#### **4D-14. TROUBLESHOOTING**

To isolate a fault, it is important to note the conditions under which the symptoms are observed and if the symptoms change with different states of the instrument, such as different RF bands or levels, only when FM is on, only under remote control, etc.

If the symptom is a blank front panel or no response to keystrokes, the fault is most likely a digital problem or a power supply problem. If the power supply and cables are good, go to the digital troubleshooting paragraphs in this section.

If the front panel appears to function properly, but the RF output is abnormal or there is a flashing 'UNCAL' indication, the cause is likely an analog circuit problem (although it could be a control problem).

A properly operating front panel indicates that the majority of the Controller circuitry is functional. It is possible, however, that a digital control problem could exist and cause the RF output to be incorrect. If a digital problem is suspected, go to the Digital and Control troubleshooting paragraphs after checking the power supply.

#### **4D-15. Service Special Functions**

- Special Function 03, Display check

All display segments are lit until a key is pressed.

- Special Function 04, Key check

For each key pressed, the code is displayed in the FREQUENCY display field. Pressing [CLR][LCL] key exits this check. The test also times out after approximately 8 seconds if no keys are pressed.

- Special Function 15, Latch Test

Special function 15 invokes a built-in latch control test that is useful in verifying that the Controller is sending valid data to the latches of the Output and Synthesizer assemblies. This special function sends an alternating bit pattern (10101010 binary) to each 8-bit latch, and displays "Latch AA". Pressing the [EDIT] key changes the bit pattern to (01010101 binary), and "Latch 55" is displayed. Pressing the [EDIT] key changes the pattern back to 10101010. Pressing any other key causes the instrument to exit the test.

### **CAUTION**

**This special function is intended as a troubleshooting tool to check the operation of the digital circuitry and the latches on the analog assemblies. Since the Generator is programmed to an abnormal state, its output is turned off by programming full attenuation.**

- **Special Functions 83 Through 86 Alternate Attenuators**

Special functions 83 through 86 program alternate 24-dB Attenuators. The alternate 24-dB attenuators are normally used only when low levels are programmed too low to be verified with a power meter during service. These special functions allow the alternate attenuators, A242L through A245L, to be programmed one at a time, thus keeping the level high. The first 24-dB attenuator, denoted A241L, is automatically programmed for levels between -17.0 dBm and -11.1 dBm with AM off. These special functions allow the other attenuators, A242L through A245L, to be programmed in the same range.

These special functions also turn off relative amplitude, amplitude fixed range, and all modulation; and turn RF and level correction on. If the level is not in the specified range, -12 dBm will be programmed. Any new entry that normally programs the attenuators causes the default (normal) attenuators to be programmed.

#### **4D-16. UNCAL Conditions**

There are two hardware fault detectors, the unlock detector on the Synthesizer PCA, and the unleveled detector on the Output PCA. These two fault detectors are constantly monitored by the Controller, and if asserted, cause a flashing UNCAL indication. The detectors are also used during the self test to check the general operation of the Generator.

It is very important to interrogate and note the UNCAL code if there is an UNCAL indication.

If the unit has a UNCAL condition, interrogate the UNCAL code by pressing the [STATUS] key and interpret the code (see Table 2-5 in this manual). Take note if the code indicates that either UNLOK or UNLVL conditions have been asserted. Other codes denote overrange or underrange conditions (operator errors) that should be cleared but are not pertinent to troubleshooting.

Usually the unleveled UNCAL code indicates a problem on the Output PCA, whereas a unlocked UNCAL code indicates a problem on the Synthesizer PCA. Be aware that it is possible to have an Unleveled UNCAL condition due to a problem with the Synthesizer PCA that is not detected by the UNLOK detector.

It is a good idea to check for a different UNCAL code when other RF bands, levels or functions (FM or AM) are selected for a more complete analysis of the symptoms. For example, if the code indicates that UNLOK is asserted only with FM on, and not with FM off, it may be indicating an overmodulation condition. See Table 1-1. Signal Generator Specifications, for the FM limitations.

#### **4D-17. Self Test Description**

The self test is started whenever the Generator is turned on. It may also be started by [SPCL] [0][2]. If the Generator fails any of the self tests, the self-test failure report is displayed until any key is pressed. The self-test report can also be displayed by [SPCL] [1][1]. The report is presented in four fields as shown in Table 4D-2.

A minus sign in the Frequency Display indicates that the self test was aborted by a front panel entry.

**Table 4D-2. Self Test Display Field**

MODULATION			FREQUENCY						AMPLITUDE			
A	A	A	-	B	B	B	C	C	C	D	D	D

The four groups (denoted by the A's, B's, C's and D's) in the self-test report correspond to different test categories. These tests are described below, including a tabulation of the Generator instrument state and the test codes that result if any test fails to achieve the expected result. Understanding how these tests are done can provide more meaning to the results and can assist in understanding how they relate to other symptoms. A successful self test is reported with all zeros.

During the self test, the step attenuator is programmed to maximum attenuation and the internal frequency reference is selected. The analog circuit tests make use of the unleveled (UNLVL) and unlocked (UNLCK) status detectors, whereas the digital circuit tests make use of write/read techniques.

#### 4D-18. AAA FIELD

AAA is the result of the AM and FM tests. During these tests, level correction is applied. During the four AM tests, a normal AM depth, which should produce a leveled condition, and an abnormally high AM depth, which should provide an unleveled condition, is set for each modulation frequency. During the two FM tests, a normal FM deviation is set, which should produce a locked condition, and then an abnormally high deviation is set, which should produce an unlocked condition. The two FM tests are not performed if the Option -651 Low-Rate FM is installed. Table 4D-3 shows the AAA Field AM and FM tests.

#### 4D-19. BBB FIELD

BBB is the result of the synthesizer tests. In the first three test steps, the Synthesizer assembly's main PLL operation is verified by programming a large change in frequency. This should cause a momentary unlocked condition that should clear as the frequency settles to the new frequency.

**Table 4D-3. AAA Field AM and FM Tests**

AAA (CODE)	FREQ (MHZ)	LEVEL (DBM)	AM (%)	MOD FREQ (HZ)	KV DAC	FM DAC	FM RANGE	EXPECTED RESULT
001	1050	10.7	30	400	n/a	n/a	n/a	Leveled
002	1050	14	127	400	n/a	n/a	n/a	Unleveled
004	1050	10.7	30	1000	n/a	n/a	n/a	Leveled
010	1050	14	127	1000	n/a	n/a	n/a	Unleveled
020	280	-10	n/a	400	Normal	1023	4	Locked
040	280	-10	n/a	400	1023	1023	4	Unlocked

In the next three steps, the synthesizer is checked by programming 225 MHz, which is outside the normal operating frequency range, and should result in an unlocked condition. Then 385 MHz is programmed, which should result in a locked condition. Next 550 MHz is programmed, which is again outside the normal range, and should result in unlocked condition.

Finally, all frequency reference circuitry is turned off, which should produce an unlocked condition, and then turned on, which should produce a locked condition. Table 4D-4 shows the BBB Field test results.

#### 4D-20. CCC FIELD

CCC is the result of the digital tests. The IEEE-488 option (if installed) is verified by writing data to the IEEE-488 chip, A3A3U1, then by reading it back and checking for the expected response. If Non-Volatile Memory is installed, each memory location of the Non-Volatile RAM is checked with a checksum.

**Table 4D-4. BBB Field Test Results**

BBB (CODE)	SYNTH. FREQ. (MHZ)	MAX. WAIT (MS)	XOENL BIT	EXPECTED RESULT
001	245	120	0	Locked
002	525	5	0	Unlocked
004	525	95	0	Locked
010	225	120	0	Unlocked
020	385	120	0	Locked
040	550	120	0	Unlocked
100	385	120	1	Unlocked
200	385	200	0	Locked

The Generator RAM is verified by writing data to each memory location and checking that the same data can be read back. Both the off-chip RAM (U25) and the on-chip RAM (U1) are tested in this manner. The RAM test is only done during the power-on self test. The data in each of the three calibration EPROMs; VCO (U23), Output (U24), and Attenuator (U26), are summed and compared with a checksum.

The data in each word of the two program EPROMs (U21, 22) are successively summed and rotated by two. The result of this procedure is compared with a checksum for each EPROM. Table 4D-5 shows the CCC field results.

#### 4D-21. DDD FIELD

DDD is the result of the Output filter tests. During these tests, the level is programmed to +13.0 dBm with level correction applied. The low-pass filters on the A2A4 Output assembly are tested by setting the frequency near the high end of each of the four half-octave non-het bands and checking for a leveled condition. Then, the frequency is set above the cutoff frequencies of two of the filters, and the output is checked for an unlevelled condition. Table 4D-6 shows the DDD field Results.

**Table 4D-5. CCC Field Test Results**

CCC (CODE)	DIGITAL TEST
001	IEEE-488 option test
002	Non-Volatile Memory option test
004	RAM test
010	Attenuator calibration EPROM checksum
020	Output calibration EPROM checksum
040	Synthesizer calibration EPROM checksum
100	Lower program EPROM checksum
200	Upper program EPROM checksum

**Table 4D-6. DDD Field Test Results**

DDD (CODE)	FREQ (MHZ)	MIDL	HAOCTH	EXPECTED RESULT
001	349.99999	0	1	leveled
002	511.99999	0	0	leveled
004	729.99999	1	0	leveled
010	1050.00000	1	1	leveled
020	490.00000	0	1	unleveled
040	1024.00000	1	0	unleveled

**Table 4D-7. Band, Filter, and Frequency Programming Data**

OUTPUT FREQUENCY ( $F_o$ )	MIDL	HAOCTH	HETL	SHETH	SYNTH. FREQ ( $F_s$ )
0.2 - 244.99999 MHz	1	1	0	1	$(800 + F_o) / 2$
245 - 349.99999 MHz	0	1	1	0	$F_o$
350 - 511.99999 MHz	0	0	1	0	$F_o$
512 - 729.99999 MHz	1	0	1	0	$F_o / 2$
730 - 1050.00000 MHz	1	1	1	0	$F_o / 2$
1 = TTL High 0 = TTL Low					

#### 4D-22. Check Output Signal

At this point, check the Generator output signal with a Spectrum Analyzer or a Counter at various frequencies on each of the three RF bands and at the state where an UNCAL condition exists. If the frequency is incorrect or erratic, check the power supply first. Go to the Synthesizer troubleshooting paragraphs if the power supply functions properly. Table 4D-7 shows the band, filter, and frequency programming data for the output frequency (at the source).

#### 4D-23. Auxiliary Power Supply PCA, A3A2

The Auxiliary Power Supply consists of the A3A2A1 PCB and the A3A2T1 transformer mounted together with a bracket. The power supply is electrically preadjusted and needs no adjustment after installation.

The Spectrum Analyzer can also be used to check to see if the modulation functions are generally working. If a modulation problem exists, go to the appropriate AM or FM troubleshooting paragraphs after checking the power supply.

If the frequency is stable and correct, but the output level is abnormal, the problem is most likely in the Output PCB. Check the power supply; then go to the Level Troubleshooting paragraphs in this section of the manual.

Armed with a clear knowledge of the symptoms and the conditions under which the UUT fails, the next task is to isolate the problem. Remove the top and bottom instrument covers and visually inspect the interior for loose cables, connectors, etc. Also be alert for the characteristic odor of burned resistors, etc.

**WARNING**

**DO NOT INTERRUPT THE PROTECTIVE GROUNDING CONNECTION. TO DO SO WOULD CREATE A POTENTIAL SHOCK HAZARD THAT COULD RESULT IN PERSONAL INJURY. SECURE THE INSTRUMENT AGAINST UNINTENDED OPERATION IF IT IS LIKELY THAT THIS PROTECTION HAS BEEN IMPAIRED. USE ONLY 250V FUSES OF THE PROPER CURRENT RATING.**

**WARNING**

**BECAUSE THE PROCEDURES DESCRIBED HERE ARE DONE WITH POWER APPLIED TO THE SIGNAL GENERATOR AND WITH PROTECTIVE COVERS REMOVED, TESTING SHOULD BE DONE ONLY BY TRAINED SERVICE PERSONNEL WHO UNDERSTAND THE HAZARDS INVOLVED.**

**CAUTION**

**To prevent damage to the Generator, turn off the instrument before removing any PCAs.**

**4D-24. Check Power Supply Voltages**

**CAUTION**

**To prevent damage to the Generator, turn off the instrument before disconnecting any power distribution cables.**

Check all power supply voltages. Table 4D-8 gives the expected dc and ripple voltages at key test points. If one supply voltage is unusually low, this could indicate an abnormal load on that supply due to a fault. To isolate the fault, check the abnormal voltage before and after disconnecting (one at a time) the power cable to the Controller, Synthesizer, Attenuator, and the cable from the Controller to the front panel.

Table 4D-8 lists the typically dc and ripple voltages (relative to ground connection on the module plate) at the key test points of the Power Supply, A3A1, PCB. These characteristics apply for [RCL] [9][8].

The unregulated dc and ripple voltages are those expected with a line voltage of 120V ac at 60 Hz. The dc voltages are expected values as measured with a digital voltmeter with respect to the power supply ground connection on the module plate.

The ripple voltages are expected values as measured with an oscilloscope with respect to the power supply ground connection on the module plate, and are the peak-to-peak values of the 120-Hz waveform.

The characteristics of the unregulated +18V relay supply depend directly on the line voltage and the load (the state of the instrument). For example; at 120V ac:

- At 50 MHz and 13 dBm, Vdc is typically 20V with 0.25V (peak-to-peak) ripple.
- At 50 MHz and RF off, Vdc is typically 20.9V with 0V ripple.

**Table 4D-8. Power Supply Characteristics**

SUPPLY	UNREGULATED VOLTAGES			REGULATED VOLTAGES		
	@TP	V dc	Ripple(Vpp)	@TP	V dc	Ripple(mVpp)
+37	9	47	0.5	5	36.9 to 37.1	2
+15 Syn	7	22	0.5	11	14.5 to 15.7	0.5
+15 Out				3	" "	"
-15	8	-23	0.2	2	-14.5 to -15.7	"
+5	10	9	1	4	4.75 to 5.25	1
+18	1	18	2.5	None	None	None

#### **4D-25. DIGITAL AND CONTROL TROUBLESHOOTING**

If the symptoms indicate a digital or control problem, the following suggestions may help you isolate the fault to a particular functional circuit. In this manual, refer to the schematic diagrams in Section 8, and refer to Section 3 for the Theory of Operation.

First, verify that all assemblies are receiving the correct voltages from the power supply.

The most obvious symptom of failure in the Controller assembly is a blank front panel. A properly operating front panel indicates that most of the Controller circuitry is functional. If the front panel is totally blank or unresponsive to any keystrokes, the microprocessor kernel should be checked first. See the paragraphs entitled Microprocessor Kernel in this section.

If the front panel is operating correctly but the RF output is incorrect, determine if the fault is on the Controller side of connector P101. The control to most of the audio and RF analog circuitry passes through P101 via buffers U15 and U16 on the Controller PCB, A2A7.

#### **4D-26. Control Activity**

This can be checked by verifying data activity on the data and address lines of P101. Program the bright digit for 100-Hz resolution in the FREQUENCY display. While pressing the [EDIT-  $\blacktriangle$ ] key, observe with an oscilloscope the activity on P101. Pressing one of the EDIT keys sends bursts of frequency and level control data through the buffers.

Although it is difficult to determine if the data, (BD0-7) and address (BAB0-2) signals on P101 are valid at any given time, the most common failures seen at this point are totally inactive signals. Between bursts, the data and address signals are in the high impedance state (tri-stated). Be careful not to confuse this high impedance state with total inactivity. Observing these signals on a known good unit may be helpful.

If signals are found to be totally inactive, inspect the buffer control signals on U15 (pin 1), and U16 (pins 1 and 19) of the Controller, A2A7. If the buffer control signals are active, check the buffer inputs that correspond to the inactive outputs. If the inputs show activity, replace the buffer and again check the signals. If, however, the inputs to the buffers are also inactive, trace the signals back and determine the fault location.



If all data and address signals show activity and their timing roughly corresponds to the select signals BSEL0L and BSEL1L, assume for now that the Controller is sending the correct data and continue on.

#### **4D-27. Latch Control**

Use the [SPCL][1][5] keys to check each available latch on the RF circuit boards to verify that the correct data is reaching them. Passing this test is a good indication that the fault is not in the Controller.

If the IEEE-488 option is present, and an IEEE-488 Bus Controller is available, additional bit-level control of the hardware is available by using the monitor commands (see Section 2). These commands allow you to directly program the DACs, or read and write data to any desired location.

#### **4D-28. Microprocessor Kernel**

Connect an oscilloscope probe to the external clock input of A2A7 U1 pin 2. There should be a symmetrical 10-MHz square wave with an adequate TTL logic level. If the signal deviates from this description, refer to Section 3, Theory of Operation, in this manual to assist you in troubleshooting the clock oscillator circuit.

#### **4D-29. Power Reset**

Connect an oscilloscope probe to the RESET input (pin 22) of U1. The signal should generate a low to high transition on power-up and remain high during normal operation. Turning the power on and off generates active low reset pulses to U1. If a problem with the reset circuit is suspected, refer to Section 3, Theory of Operation, and troubleshoot the reset circuitry.

#### **4D-30. Microprocessor Inputs**

Input pins to U1, CRUIN (pin 13), INT1 (pin 15), HOLD (pin 18), NMI (pin 21), and READY (pin 23), should all be high. If any of these signals are not high, correct the fault before continuing on.

#### **4D-31. IEEE-488 Interrupt**

Verify that the IEEE-488 Interface interrupt signal, IEINTL, is in the inactive (high) state. If IEINTL is active, either troubleshoot the interface to the IEEE-488 Interface option, or temporarily bend out pin 14 of U1 and tie it to +5V.

After completing the above steps, there should be activity on the address, data, and control lines as the microprocessor executes instructions.

#### **4D-32. Microprocessor Bus**

The dynamic nature of microprocessor bus circuitry makes it very difficult to verify the data transmitted at any given time. However, most common bus faults show recognizable symptoms. Look at each of the data (D0 to D7), address (A0 to A15), and bus control (CLKOUT, DBINL, WEL, MEML) signals with an oscilloscope.

Suspect inactive signals or signals that enter invalid logic states. Also compare the driver inputs and outputs of buffered signals. A combination of observation and experience is helpful here. An ohmmeter or a pulse generator may be useful in further investigating suspected signals.

#### **4D-33. Address Decoder**

Several levels of address decoding are used to select all the memory and I/O devices. The inputs to the address decoders come from the buses and present challenges similar to troubleshooting the buses. A suggested approach is to first choose a decoding path to a

particular device or group of devices. Start at the highest level of decoding, and one at a time verify that each part in the path is good.

#### **4D-34. Display and Controls**

If the display shows signs of activity, but has missing or bright digits or segments, the problem is most likely in U18 on the A2A7 Controller or on one of the data latches or drivers on the A1A1 Display PCB. If the display is blank and the Controller is operational, check the various power supplies and the display blanking circuitry on the Display PCB.

Two special function-service tests are available to test the front panel indicators and keys. [SPCL] [0][3] keys check the front panel displays by lighting all segments. This test is aborted by pressing any key on the Generator.

The [SPCL] [0][4] keys allow all normally open keys to be checked. As each key is pressed, its row and column address is displayed in the center of the FREQUENCY display field. See Table 4D-9 for the address codes for each key. This test is exited by a clear entry.

**Table 4D-9. Address Codes for the Front Panel Keys**

KEY	CODE
[EXTAM]	1
[EXTFM]	2
[INTAM]	4
[INTFM]	5
[400/1000]	6
[FREQ]	9
[AMPL]	10
[AM]	11
[FM]	12
[SPCL]	13
[STEP]	14
[7]	15
[4]	16
[1]	17
[0]	18
[ST0]	19
[8]	20
[5]	21
[2]	22
[.]	23
[RCL]	24
[9]	25
[6]	26
[3]	27
[−]	28
[SEQ]	29
[MHz V]	30
[kHz V]	31
[Hz uV]	32
STEP[v]	33
[dB(m)]	34
[%]	35
[CLR LCL]	(Exit Test)
STEP[↕]	37
EDIT[↕]	38
EDIT[↕]	40
EDIT[↕]	41
EDIT[↕]	43
[STATUS]	45
RF[ON/OFF]	46

## **4D-35. SYNTHESIZER TROUBLESHOOTING**

### *NOTE*

*All frequencies mentioned are synthesized; hence they are exact (coherent with the 10-MHz reference), unless noted as approximate.*

If the Generator has the Low-Rate FM (Option -651), set A2A9S1 for normal operation (See Table 651-1) while troubleshooting. If the Generator level is inaccurate or an unlevelled condition exists, then the A2A4 Output assembly is probably at fault. If an unlock condition exists, the problem is in the synthesizer. If the output frequency is in error or erratic, there is likely a problem with the Synthesizer assembly. However, if the UUT has Option-130 Sub-Harmonic Reference and the unlocked condition only occurs when using an external reference, the problem is probably in the Sub-Harmonic Reference option circuitry.

If the unlocked condition exists with REF INT/EXT set to INT, be sure no signal is applied to the 10 MHz IN/OUT connector. An external signal applied (while operating on internal reference) can cause the main loop to unlock.

Next, check to see if the Generator frequency is stuck high or low. A good way to do this is to check the dc voltage at TP44. If it is around 2V, go to the Reference Circuitry Check in the following paragraphs.

If the voltage is around 25V, the problem is associated with the main PLL, i.e., VCO, UHF binary divider, buffer amplifier, SSB mixer, triple-modulus prescaler, or N-Divider.

Table 4D-10 shows the characteristics of the signals at the various test points on the Synthesizer PCA. The range of the signal and the expected value for a typical instrument state are given. The values in the TYPICAL column are for the UUT programmed to 160.11999 MHz, INT FM on at 1 kHz, and 99.9 kHz deviation.

### **4D-36. Reference Circuitry Check**

There should be a 10-MHz square wave at TP50. If there is no signal here, check U55 pin 10. If there is a signal at this point, the problem is in the multiplexer circuitry U55 or latch U32. If there is no signal at U55 pin 10, the problem is in the internal 10-MHz crystal oscillator. The voltage at the junction of R148 and R149 should be a TTL low (approximately 0.2V). If voltage is a TTL high (approximately 3.8V), there is a problem with the latch, U32, or in the interface to the microprocessor. If the 10-MHz circuitry checks out, there should be a 1-MHz signal (20% duty cycle) at TP35.

Table 4D-11 shows the relationship between various reference frequency configurations and the control of the reference circuitry.

### **4D-37. Main Phase Lock Loop**

If the voltage at TP44 is around 25V, connect a variable power supply to TP41. This allows the frequency of the VCO to be controlled directly. Use a Spectrum Analyzer or Counter to monitor the Generator output.

Program the UUT to 640 MHz. If the power supply can be adjusted to obtain an output frequency of about 640 MHz, the VCO is probably OK; proceed to the next paragraph. If the power supply cannot be adjusted to obtain about 640 MHz output frequency, troubleshoot the VCO or the circuitry between TP41 and TP44.

**MAINTENANCE**  
**TROUBLESHOOTING AND REPAIR**

**Table 4D-10. Synthesizer PCA Test Points**

TEST POINT	SIGNAL TYPE	RANGE	TYPICAL	FUNCTION
TP1	RF	245 to 525 MHz	480.059995 MHz; -7 dBm	All frequency digits
TP2	GROUND			
TP3	RF	245 to 525 MHz	480.059995 MHz; +4 dBm	All frequency digits
TP7	GROUND			
TP11	TTL	20 to 39.995 kHz	39.995 kHz	10-K, 1-K, 100-, and 10-Hz Digits
TP12	TTL	1 to 1.99975 MHz	1.99975 MHz	10-K, 1-K, 100-, and 10-Hz Digits
TP13	GROUND			
TP14	TTL	1 MHz (AL)	1 MHz	1-MHz and lower digits
TP15	TTL	0.02 to 1 MHz	20 kHz	
TP16	TTL	12 to 26 MHz	24 MHz	
TP17	RF	245 to 525 MHz	480.02 MHz; -17 dBm	All frequency digits
TP22	AUDIO	0 to 0.7V rms	0.68V rms	All frequency digits
TP23	GROUND			FM Deviation
TP24	TTL	20 MHz, 12.5 ns (AH)	20 MHz	
TP25	TTL	20 MHz, 12.5 ns (AH)	20 MHz	
TP26	GROUND			
TP27	TTL	10 to 19.9975 MHz	19.9975 MHz	10-K, 1-K, 100- and 10-Hz Digits
TP31	GROUND			
TP32	AUDIO	0 to 0.8V rms	0.18V rms	FM Deviation, and Frequency
TP33	AUDIO	0 to 0.8V rms	0.18V rms	FM Deviation, and Frequency
TP34	DC	30 $\pm$ 0.5V	30V dc	
TP35	TTL	1 MHz	1 MHz	1-MHz Reference
TP36	GROUND			
TP37	DC	-1 to -6V	-2.7V dc	Frequency
TP38	TTL	1 MHz 200 ns (AH)	1 MHz 200 ns	
TP39	TTL	1 MHz 10 ns (AL)	1 MHz 10 ns	
TP40	DC	2 to 22V	17.7V dc	Frequency
TP41	DC	2 to 22V	17.3V dc	Frequency
TP42	GROUND			
TP43	DC	2 to 22V	17.3V dc	Frequency
TP44	DC	2 to 22V	16.2V dc	Frequency
TP45	GROUND			
TP46	TTL	low = unlocked high = locked	TTL high	
TP49	TTL	10 MHz 20 ns (AL)	10 MHz, 20 nS	
TP50	TTL	10 MHz	10 MHz	
TP51	GROUND			
TP52	TTL	10 MHz 10 ns (AL)	10 MHz, 10 nS	
TP53	DC	7.5 $\pm$ 1V 16 $\pm$ 2V	16V dc	Above 245 MHz Below 245 MHz
TP54	TTL	10 MHz	10 MHz	
TP55	RF	800 MHz	800 MHz; -10 dBm	Below 245 MHz
TP56	INPUT			To test low- pass filters
<p>NOTE: AH = active high AL = active low</p>				

**Table 4D-11. Frequency Reference Control**

OPTION INSTALLED			BIT				
HIGH-STABILITY	SUB-HARMONIC	INT/EXT	RMUX1H	RMUX0H	RINH	EOENL	SHENL
NO	NO	INT	0	0	0	0	1
		EXT	1	0	1	1	1
YES	NO	INT	0	1	0	1	1
		EXT	1	0	1	1	1
NO	YES	INT	0	0	0	0	1
		EXT	0	0	0	0	0
YES	YES	INT	0	1	0	1	1
		EXT	0	0	0	0	0
1 = TTL High 0 = TTL Low							

Program the UUT to 320 MHz. If you can adjust the power supply to obtain about 320 MHz output from the VCO, the VCO and binary divider are probably OK; proceed to paragraph 4D-41. If you cannot change the frequency, the problem is either the VCO, or the UHF binary divider, U1.

Check the signal at TP1. It should be the same as the output frequency. The level after the buffer amplifier, Q3, Q4, at TP3 (use RF test cable) should be approximately +3 dBm. The signal at TP17 should be a signal sideband signal with the lower sideband component (the desired signal) at about -20 dBm. If the only signal is the carrier frequency (same frequency as TP3), check the quadrature generator, and the sub-synthesizer circuitry. The signal out of the triple-modulus pre scalar should be approximately 16 MHz (with the output frequency set to approximately 320 MHz). The output of the N-Divider, TP14, should be approximately 1 MHz.

As the UUT frequency is programmed, the frequency at TP14 should change, since the divide ratio is being changed. If the frequency is not 1 MHz and/or it doesn't change, the problem is probably with the N-Divider gate array, U17, or the interface to the microprocessor.

If both the reference (at TP35) and the N-Divider signals at the phase detector are 1 MHz, the loop should lock when the operator removes the variable power supply. If the loop does not lock, check the KNV voltage at TP37. With the Signal Generator programmed to 320 MHz, TP37 should be approximately 1.0 to 2.0V. If this voltage is not correct, check the DAC U27, latches U26 and U30, and op-amp U28. This voltage should also change as the operator changes the Generator frequency.

If the KN DAC appears to function, the problem is with the phase detector. Reconnect the variable power supply as before, and adjust the voltage for a approximately 1-MHz signal at U44 pin 3. With this frequency slightly above 1 MHz, TP38 should be high and TP39 should be low.

With this frequency slightly below 1 MHz, TP38 should be low and TP39 should be high. The only remaining circuitry is the loop amp U48 and the current source, U46, Q18, and Q19.

If the loop is locked, but the 1-MHz, 10-MHz, or 100-MHz digits cannot be programmed, the problem is either the N-divider or the interface to the microprocessor. If the 100-kHz

or 10-kHz digit is inoperative or the frequency jumps as the 1-MHz digit is programmed, the problem is likely the triple-modulus prescaler. If the lower order (1-kHz, 100-Hz, 10-Hz) digits cannot be programmed, the problem is the sub-synthesizer or single sideband mixer.

#### **4D-38. Sub-Synthesizer and HET (800 MHz), 40-MHz Loop**

The frequency at TP24 and TP25 should be 20 MHz. The frequency at U64 pins 14 and 15 should be 40 MHz. If the 40-MHz signal is present, but not the 20 MHz, the problem is most likely with Q4, Q5, U35, or U34. If the 40-MHz signal is in error, the problem is in the 40-MHz loop.

Check the frequency at the 40-MHz VCO, U64 pin 3. It should be 40 MHz. If it is not, lift the op-amp end of R169, and connect it to a variable power supply set to approximately 6V. The signal at U64 pin 3 should be approximately a 40-MHz ECL level (approximately 3.2V to 4.2V) signal. By varying the supply voltage, the frequency should change. A similar signal should be present at U64 pin 2. Check to see if U64 pin 11 is ECL low (approximately 3.2V).

The output of TTL buffer U65 pin 8 should be approximately 40 MHz. The output of the divide-by-4, U66, should be approximately 10 MHz. Once again, if the frequency is greater than 10 MHz, pulses should exist at TP52 and the output of op-amp U60 pin 6 should be low. If the frequency is below 10 MHz, pulses should exist at TP49, and the op-amp should be high (approximately 24V). The loop should lock when the operator reconnects R169.

If the TP checks are all right and the 800-MHz oscillator is not locked when in the HET band, the problem is either with the 800-MHz VCO, the divide-by-4 (U61), the divide-by-5 (U62, U63), or the logic that controls the switched +5V.

Program the UUT to 320 MHz. The frequency at TP27 (the output of the sub-synthesizer gate array U33) should be 10 MHz if the input signals are correct. The frequency at TP12 should be 1 MHz, and TP11 should be 20 kHz. There should be a 20-kHz sine wave at the hot end of R33. The signals at the output of the active quadrature generator, U10 pin 8 and U10 pin 14 should be approximately 300 mv p-p sine waves that are 90° apart in phase. Use a dual-trace Oscilloscope for verification.

The frequency at TP27 should change 500 kHz for a 1-kHz change in the programmed frequency, and 50 kHz for a 100-Hz change, etc.

#### **4D-39. FM Circuitry**

Program the UUT to 500 MHz, INT FM, 99.9-kHz deviation, and 1-kHz modulation frequency. There should be a 2V p-p 1-kHz sine wave at TP22. Program 50-kHz deviation, and the level should drop to 1V p-p. Reprogram the deviation to 99.9-kHz. The level of the output of the KV DAC, U28 pin 7 will be approximately 1.5V p-p depending on the FM correction value (KV) in the EPROM.

The signals at TP32 and TP33 should be approximately the same, depending on how R87 is set. The output of the audio integrator should be about 1V p-p. To check the FM range, program the UUT to 9.99-kHz deviation. The ac voltage at TP32 should drop to 10% of the 99.9-kHz value. Program 999-Hz, and the voltage should drop to 1% of the 99.9-kHz value.

The INT/EXT FM selection is done on the A2A4 Output PCA. The controls are listed in Table 4D-17.

Tables 4D-12 and 4D-13 provide FM range and FM DAC (10 bits) control information.

**Table 4D-12. FM Ranges**

FM DEVIATION (Hz)	FM DEVIATION WITH LOW-RATE FM OPTION (Hz)	FMRN
0 - 999	0 - 99.9	1
1000 - 9990	100 - 999	2
10000 - 99900	1000 - 9,990	4

**Table 4D-13. FM DAC Control**

FM DEVIATION (Hz)	FM DEVIATION WITH LOW RATE FM OPTION (Hz)	FM 0 - 9 (Bits)
0 - 999	0 - 99.9	FM Deviation /.1
1000 - 9990	100 - 999	FM Deviation
10000 - 99900	1000 - 9,990	FM Deviation /10
		FM Deviation /100

#### **4D-40. LEVEL TROUBLESHOOTING**

If the Generator level is inaccurate or an unlevelled condition exists, the A2A4 Output assembly or the A2A6 Attenuator assembly is probably at fault. If an unlevelled condition exists, the problem is in the circuitry ahead of the detector. Go to the paragraph in this section entitled Unlevelled Condition.

If there is no unlevelled condition, the problem is likely in the circuitry following the ALC Loop, which includes the Attenuator (or Attenuator/RPP), the heterodyne circuit, and the output amplifier, Q215. If the level problem only exists below 245 MHz, then troubleshoot the heterodyne circuitry. If the problem is not frequency dependent and if the level is accurate above +7 dBm but inaccurate below +7 dBm, then the A2A6 Attenuator (or the A2A5 Attenuator/RPP) is at fault.

#### **4D-41. Output Assembly Test Point Signal Information**

Table 4D-14 presents the nominal characteristics of the signals at the various test points on the Output PCA. Not only the range of the signal, but also the expected value for the Instrument Preset State [RCL] [9][8], are given.

#### **4D-42. ATTENUATOR LEVEL CONTROL**

Table 4D-15 lists the Attenuator assembly (A2A5 or A2A6) sections that are inserted in the RF output path for the various level ranges of the generator. This information is useful in isolating a faulty section. The sections are labeled by the control line mnemonics at latch U27 on the Controller PCB. Note that the section is inserted in the RF output path when there is no power applied to the relay.

If the Level problem exists above +7 dBm, the through path (0 dB attenuation) of the Attenuator may be faulty.

#### **4D-43. Attenuator Check**

Attenuator problems are most likely to be relay contact problems.

To isolate the faulty attenuator section, connect a power meter to the RF OUTPUT connector, and check the nominal levels per Table 4D-16 at both 0.2-MHz and 1050-MHz frequency.

**Table 4D-14. Output PCA Test Points**

TEST POINT	SIGNAL TYPE	RANGE	TYPICAL FOR RCL 98	SIGNAL DESCRIPTION
TP1	RF	245 to 1050 MHz -18 to -32 dBm	300 MHz -27 dBm	Output of mid/high bandswitch.
TP2	RF	245 to 1050 MHz -10 to -25 dBm	300 MHz -20 dBm	Output of buffer amplifier.
TP3	RF	245 to 1050 MHz -13 to -28 dBm	300 MHz -22 dBm	Output of switched low-pass filters.
TP4	RF	245 to 1050 MHz -13 to -33 dBm	300 MHz -22 dBm	Power-splitter output.
TP5	RF	800 MHz -8 dBm	No signal	Het mixer LO signal
TP6	dc+audio	-7 to 14V dc nominal	3.1V dc	Modulator control voltage.
TP7	dc+audio	0.04 to 3.0V dc nominal	1.2V dc	Leveling loop control voltage.
TP8	dc+audio	0 to 2V dc nominal	0.63V dc	Detector diode voltage.
TP9	dc+audio	400 or 1000 Hz, 0.71V rms	400 Hz 0.71V rms	Modulation Oscillator output.
TP10	Ground			
TP11	dc+audio	0 to 0.70V rms	0V	FM modulation signal to Synthesizer.

The through-path operation of the Attenuator (Attenuator/RPP) can be roughly checked by removing the instrument and module bottom covers. Program the frequency to 1 MHz and the level to +13 dBm. Measure (with a high-impedance probe and an RF voltmeter or an oscilloscope) the level at P102 of the A2A4 Output assembly with a power meter connected to the RF OUTPUT connector. If the voltmeter measures a nominal 1V rms, but the power meter does not read +13 dBm, then the signal is not getting through the Attenuator module, and the Attenuator (Attenuator/RPP) is at fault.

If the level problem is subtle rather than catastrophic, a more accurate check is required to determine if the fault is the Attenuator or the Output assembly. Such a check is made by removing the Attenuator assembly, attaching an adapter (6060A-4234; P/N 744177) to the interconnect point, and making power meter measurements of the A2A4 Output assembly output. Use [SPCL] [8][2] to disable the Attenuator correction factors. The level at this point should be flat over 0.4 to 1050 MHz within typically 0.2 dB and should agree with the programmed level within 2 dB.

If the problem has been isolated to the Output assembly and there are no self-test errors or flashing UNCAL condition, the problem is probably in the circuits following the ALC loop. If the problem is only in the Het band (frequency < 245 MHz), check the Het band switch and controls, the Het band circuits (mixer, filter, and amplifier), and the local oscillator signal (800 MHz, nominal -10 dBm at TP5). If the problem is at all frequencies, check the output amp, Q215, and the Het/function switch and controls.



**Table 4D-15. Attenuator Levels Control**

AMPLITUDE RANGE IN DBM				ATTENUATOR SECTIONS INSERTED INDICATED BY X						
AM Off		AM On		A6DBL	A12DBL	A241L	A242L	A243L	A244L	A245L
7.0	19.0	1.0	9.0							
1.0	6.9	-5.0	0.9	X						
-5.0	0.9	-11.0	-5.1		X					
-11.0	-5.1	-17.0	-11.1	X	X					
-17.0	-11.1	-23.1	-17.1			X				
-23.1	-17.1	-29.1	-23.2	X		X				
-29.1	-23.2	-35.1	-29.2		X	X				
-35.1	-29.2	-41.1	-35.2	X	X	X				
-41.1	-35.2	-47.1	-41.2			X	X			
-47.1	-41.2	-53.2	-47.2	X		X	X			
-53.2	-47.2	-59.2	-53.3		X	X	X			
-59.2	-53.3	-65.2	-59.3	X	X	X	X			
-65.2	-59.3	-71.2	-65.3			X	X	X		
-71.2	-65.3	-77.2	-71.3	X		X	X	X		
-77.2	-71.3	-83.3	-77.3		X	X	X	X		
-83.3	-77.3	-89.3	-83.4	X	X	X	X	X		
-89.3	-83.4	-95.3	-89.4			X	X	X	X	
-95.3	-89.4	-101.3	-95.4	X		X	X	X	X	
-101.3	-95.4	-107.4	-101.4		X	X	X	X	X	
-107.4	-101.4	-113.4	-107.5	X	X	X	X	X	X	
-113.4	-107.5	-119.4	-113.5			X	X	X	X	X
-119.4	-113.5	-125.4	-119.5	X		X	X	X	X	X
-125.4	-119.5	-131.4	-125.5		X	X	X	X	X	X
-147.0	-125.5	-147.0	-131.5	X	X	X	X	X	X	X

**Table 4D-16. Attenuator Levels**

ATTENUATOR	PROG LEVEL	SPECIAL FUNCTION	OBSERVED LEVEL (NOMINAL)
6dB	+6dBm	--	+6dBm
12dB	0dBm	--	0dBm
24dB (number 1)	-12dBm	--	-12dBm
24dB ( " 2)	-12dBm	83	-12dBm
24dB ( " 3)	-12dBm	84	-12dBm
24dB ( " 4)	-12dBm	85	-12dBm
24dB ( " 5)	-12dBm	86	-12dBm

#### 4D-44. Unleveled Condition

If there are self-test failures and/or unleveled indications, the problem is probably in, or prior to, the ALC loop. If the problem is isolated to a specific frequency band (or bands) and other bands work properly, check signal inputs and controls to the various filters that precede the modulator. See Table 4D-7 Band, Filter, and Frequency Data for band definition. If all frequency bands are affected, the leveling ALC loop or associated controls and inputs are probably at fault.

TP6 (modulator control voltage) is a good place to monitor. With the instrument programmed to +13 dBm, the voltage on TP6 should be between +2V and +8V dc (+4V to +5V dc typical). Another place to monitor is TP7 (ALC control voltage). With the instrument programmed to +13 dBm, and the level correction disabled [SPCL][8][1], the

voltage here should be approximately 1.6V dc. With the RF off, the voltage at TP7 should be 0V dc.

When the problem is isolated to a specific area, use the schematic, Theory of Operation, Test Point Chart, and normal troubleshooting techniques to isolate the fault.

#### **4D-45. AM TROUBLESHOOTING**

The following paragraphs provide information that help the operator to trace an AM problem to a specific circuit on the Output assembly.

#### **4D-46. Internal/External AM**

If an AM problem exists, determine if the problem occurs with internal AM, external AM or both. This check is done by connecting a 1V peak (2V p-p), 1-kHz signal source to the external MOD INPUT of the UUT and measuring AM depth. Use a Modulation Analyzer. Program the UUT to external AM and then to internal AM at 1-kHz internal modulation rate. The measured AM should agree with the programmed depth within a few percent.

Tables 4D-17 and 4D-18 provide control information for modulation and modulation frequency selection.

If the internal AM does not agree, but external AM is Ok, the Modulation Oscillator is likely at fault. If external AM is bad, but internal AM is Ok, then the problem is somewhere between the external MOD INPUT and the AM DAC.

If both the external and internal AM fail, the problem is likely being caused by either the modulation signal-processing circuit or the leveling loop. To determine which circuit is faulty, perform the following test.

**Table 4D-17. Modulation ON/OFF Control**

INT AM	EXT AM	INTAML	EXTAML	
Off	Off	1	1	
Off	On	1	0	
On	Off	0	1	
On	On	0	0	
INT FM	EXT FM	INTFML	EXTFML	FMENH
Off	Off	1	1	0
Off	On	1	0	1
On	Off	0	1	1
On	On	0	0	1
1 = TTL High 0 = TTL Low				

**Table 4D-18. Modulation Frequency Control**

FREQUENCY	MF400L
400 Hz	0
1 kHz	1
1 = TTL High 0 = TTL Low	

#### **4D-47. ALC Loop Control Voltage**

##### **PROCEDURE**

1. Connect a 1V peak (2V p-p), 1-kHz signal source to the external MOD INPUT.
2. Program the UUT for 350 MHz, 7 dBm, 71% AM depth, and EXT AM ON.
3. Measure the ac and the dc voltage at TP7. The rms voltage should be nominally 50% of the dc voltage.
4. Program the UUT for 35% AM depth. The rms voltage should be nominally 25% of the dc voltage.

If the UUT fails this test, the problem lies somewhere between the EXT MOD input and TP7 (ALC loop-control voltage). To further localize the problem, the same test can be done by measuring the ac voltage at U302 pin 8 (input to level DAC). If the measured ac voltage does not change as programmed AM depth is changed, either the AM DAC or its control is at fault. The AM DAC (A2A4U301) is an 8-bit DAC and is set to twice the programmed AM depth, e.g., 180 for 90% AM.

If the UUT passes this test, then the ALC loop control voltage is correct, and the problem is in the ALC loop. A likely cause of excessive AM depth error and harmonic distortion is detector non-linearity. The following test checks detector linearity.

#### **4D-48. Detector Linearity**

##### **PROCEDURE**

1. Install the plate covers and let the UUT warm up at room temperature for one hour.
2. Program the UUT for 350 MHz, 12 dBm, modulation OFF.
3. Program [SPCL][8][1] and [SPCL][9][1] to disable level correction and enable amplitude fixed range.
4. Measure power with a power meter at the UUT RF OUTPUT. Note the reading.
5. Program the UUT for 2 dBm using the EDIT keys. The measured power should be  $10 \text{ dB} \pm 0.2 \text{ dB}$  below the reading noted in step 4.
6. Program the UUT for -8 dBm using the EDIT keys. The measured power should be  $20 \text{ dB} \pm 0.4 \text{ dB}$  below the noted reading.
7. Program the UUT for [SPCL][0][0].

If the UUT fails this test, the problem is likely to be in the detector or detector-linearizer circuit. If the UUT passes the test, the problem is constrained to the other ALC loop elements, and is likely to be a bandwidth problem associated with the loop amplifier or the modulator or modulator-linearizer circuit.



## Section 5

# List of Replaceable Parts

### TABLE OF CONTENTS

ASSEMBLY NAME	TABLE		FIGURE	
	NO.	PAGE	NO.	PAGE
6060A Final Assembly .....	5-1.	5-4	5-1.	5-4
A1 Front Section .....	5-2.	5-6	5-2.	5-6
A2 Module Section .....	5-3.	5-7	5-3.	5-7
A3 Rear Section .....	5-4.	5-8	5-4.	5-9
A1A1 Display PCA .....	5-5.	5-10	5-5.	5-11
A2A1 Synthesizer PCA .....	5-6.	5-12	5-6.	5-15
A2A2 VCO PCA .....	5-7.	5-16	5-7.	5-17
A2A4 Output PCA .....	5-8.	5-18	5-8.	5-21
A2A6 Attenuator Assembly .....	5-9.	5-22	—	—
A2A6A4 Attenuator PCA .....	5-10.	5-23	5-9.	5-23
A2A6A5 Relay Driver PCA .....	5-11.	5-24	5-10.	5-24
A2A7 Controller PCA .....	5-12.	5-25	5-11.	5-26
A3A1 Power Supply PCA .....	5-13.	5-27	5-12.	5-28

## LIST OF REPLACEABLE PARTS

### 5-1. INTRODUCTION

This section contains an illustrated parts breakdown of the instrument. A similar parts list is included in the Options Section for each of the options. Components are listed alphanumerically by assembly. Both electrical and mechanical components are listed by reference designation. Each listed part is shown in as accompanying illustration.

### 5-2. Parts List Information

Parts lists include the following information:

1. Reference Designation
2. Description of Each Part
3. FLUKE Stock Number
4. Federal Supply Code for Manufacturers
5. Manufacturer's Part Number
6. Total Quantity of Components Per Assembly
7. Recommended quantity: This entry indicates the recommended number of spare parts necessary to support one to five instruments for a period of 2 years. This list presumes an availability of common electronic parts at the maintenance site. For maintenance for 1 year or more at an isolated site, it is recommended that at least one of each assembly in the instrument be stocked. In the case of optional subassemblies, plug-ins, etc., that are not always part of the instrument or are deviations from the basic instrument model, the REC QTY column lists the recommended spares quantity for the items in that particular assembly.

### 5-3. HOW TO OBTAIN PARTS

Components may be ordered directly from the manufacturer's part number, or from the John Fluke Mfg. Co., Inc. or an authorized representative by using the FLUKE STOCK NUMBER. In the event the part ordered has been replaced by a new or improved part, the replacement will be accompanied by an explanatory note and installation instructions if necessary.

To ensure prompt and efficient handling of your order, include the following information:

1. Quantity
2. FLUKE Stock Number
3. Description
4. Reference Designation
5. Printed Circuit Board Part Number and Revision Letter
6. Instrument Model and Serial number

**5-4. Recommended Spare Parts Kit**

A Recommended Spare Parts Kit for your basic instrument is available from the factory. This kit contains those items listed in the REC QTY column for the parts lists in the quantities recommended.

Parts price information is available from the John Fluke Mfg. Co., Inc., or its representative. Prices are also available in a Fluke Replacement Parts Catalog, which is available upon request.

**CAUTION**

**\***

**Indicated devices are subject to damage by static**

# LIST OF REPLACEABLE PARTS

TABLE 5-1. 6060A FINAL ASSEMBLY  
(SEE FIGURE 5-1.)

REFERENCE DESIGNATOR	FLUKE STOCK	MFRS SPLY CODE	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S T -E	N O T
A->NUMERICS-->	S	DESCRIPTION				
A1 FRONT SECTION						
A2 MODULE SECTION						
A3 REAR SECTION						
H 1		SCREW, MACH, FHUP, S. STL, 6-32X1/4	320093 89536 320093	20		
H 2		SCREW, MACH, PHP SEMS, STL, 6-32X1/2	177030 89536 177030	4		
H 3		SCREW, MACH, PHP, STL, 10-32X1/4	218941 89536 218941	11	1	
H 4		SCREW, MACH, PHP, S. STL, 6-32X3/8	334458 89536 334458	67		
H 5		SCREW, MACH, PHP, STL, 6-32X1/4	152140 89536 152140	3		
MP 1		TOP COVER	704866 89536 704866	1		
MP 2		BOTTOM COVER	704874 89536 704874	1		
MP 3		FOOT, SINGLE BAIL TYPE (DARK UMBER)	653923 89536 653923	4		
MP 4		NAMEPLATE, SERIAL -REAR PANEL-	472795 89536 472795	1		
MP 5		DECAL, FRONT CORNER	659227 89536 659227	2		
MP 6		SIDE TRIM 18"	525998 89536 525998	2		
MP 7		DECAL, REAR CORNER	685214 89536 685214	2		
MP 8		COVER PLATE BLANK, IEEE	731265 89536 731265	1		
MP 9		COVER, OUTPUT, PLATED	731430 89536 731430	1		
MP 10		COVER, SYNTHESIZER, PLATED	731398 89536 731398	1		
MP 11		OPERATION DECAL, 100KHZ	755363 89536 755363	1		
TM 1		MANUAL, 6060A 100KHZ	704841 89536 704841	1		
TM 2		MANUAL, GETTING STARTED	744185 89536 744185	1		
U 23, 24		* IC, 2K X 8 EPROM	454603 01295 TMS2516JL	2	1	
W 1		CABLE ASSEMBLY, SEMI-RIGID W 1	731380 89536 731380	1		
W 2		3 WIRE WITH FEMALE PLUG	284174 89536 284174	1		
1		UNPROGRAMMED PART				




Figure 5-1. 6060A Final Assembly







Figure 5-1. 6060A Final Assembly (cont)

**LIST OF REPLACEABLE PARTS**

TABLE 5-2. A1 FRONT SECTION  
 (SEE FIGURE 5-2.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
A 1		DISPLAY PCA	738609	89536	738609	1		
A 2		SWITCH PWB	738591	89536	738591	1		
H 13		SCREW,CAP, SCKT, STL, 8-32X3/8	295105	89536	295105	4		
H 14		SCREW,MACH,PHP SEMS, STL, 4-40X1/2	353060	89536	353060	10		
H 15		SCREW,MACH,PHP SEMS, STL, 4-40X3/16	732750	89536	732750	12		
MP 12		CORNER BRACKET	657601	89536	657601	2		
MP 13		FRONT PANEL SM	657593	89536	657593	1		
MP 14		DECAL, FRONT PANEL	707737	89536	707737	1		
MP 15		DECAL, LENS, 100KHZ	744169	89536	744169	1		
MP 16		LENS DISPLAY	657718	89536	657718	1		
MP 17		CORNER HANDLE, FRONT 5.25 INCH	656173	89536	656173	2		
MP 18		BUSHING INSULATION R.F.OUTPUT	537803	89536	537803	1		
MP 19		RETAINER,RING,STUD-RECEIVER,0.093	740217	89536	740217	11		
MP 37		SHIELD, DISPLAY	731257	89536	731257	1		
S 1		SWITCH, LEFT CONDUCTIVE ELASTOMERIC	698597	89536	698597	1		
S 2		SWITCH,CENTER CONDUCTIVE ELASTOMERIC	731349	89536	731349	1		
S 3		SWITCH,RIGHT CONDUCTIVE ELASTOMERIC	731356	89536	731356	1		
W 7		CABLE ASSY MOD INPUT FRONT	738500	89536	738500	1		
X 1		SOCKET,SIF,0.100 CTR,7 PIN	520809	30035	SS-109-1-07	2		



6060A-5002

Figure 5-2. A1 Front Section

# LIST OF REPLACEABLE PARTS

TABLE 5-3. A2 MODULE SECTION  
(SEE FIGURE 5-3.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS PLY CODE-	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
A 1	*	SYNTHESIZER PCA	748814	89536	748814	1		
A 2	*	VCO PCA	748780	89536	748780	1		1
A 4	*	OUTPUT PCA	744045	89536	744045	1		1
A 6		ATTENUATOR ASSEMBLY	750406	89536	750406	1		1
A 7	*	CONTROLLER PCA	755330	89536	755330	1		
C 1		CAP, CER, 1000PF, +-5%, 50V, COG	528539	51406	RPE113	1		
H 6		SCREW, MACH, PHP SEMS, STL, 6-32X1/4	178533	89536	178533	1		
H 7		WASHER, FLAT, STEEL, #6, 0.031 THK	110270	89536	110270	4		
H 8		SCREW, MACH, PHPD, S, STL, 6-32X9/32	544122	89536	544122	88		
H 9		SCREW, MACH, PHP, STL, 10-32X1/4	218941	89536	218941	3		
H 10		NUT, CAP, EXT, LOCK, STL, 10-32	559237	89536	559237	1		
H 11		WASHER, LOCK, SPLIT, STEEL, #6	110692	89536	110692	2		
H 12		SCREW, MACH, PHP SEMS, STL, 6-32X5/16	530287	89536	530287	4		
MP 7		AIDE, PCB PULL	541730	89536	541730	12		
MP 8		HEATSINK, OUTPUT TRANSISTOR	738492	89536	738492	2		
MP 9		GASKET, SHIELDING, MONEL MESH, CIRCULAR	720664	89536	720664	11		
MP 10		SELF-ADHESIVE, ABMM-1, ABS PLASTIC	407908	89536	407908	1		
MP 11		CABLE, NYLON STRAP, 4 IN L, SST-1	172080	89536	172080	1		
W 6		CABLE ASSY, MOD INPUT, MODULE	738542	89536	738542	1		
W 10		CABLE ASSEMBLY, SYNTHESIZER-POWER	738526	89536	738526	1		

1 ASSEMBLY INCLUDES ASSOCIATED CALIBRATED EPROM




Figure 5-3. A2 Module Section


# LIST OF REPLACEABLE PARTS

TABLE 5-4. A3 REAR SECTION  
(SEE FIGURE 5-4.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	-----DESCRIPTION-----	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
A	1	* POWER SUPPLY PCA	744052	89536	744052	1		
B	1	SH. POLE, SUBMIN, 115VAC11W, ROTRON#5P2A2	335083	89536	335083	1		
E	1 2	LUG, SOLDER #6	132399	78189	2104-06-00	2		
E	3	LUG, CRIMP, SPLICE, BUTT, 18-22AWG	664458	89536	664458	1		
F	1	FUSE, 1/4 X 1-1/4, FAST, 1.5A, 250V	109330	71400	AGC1-1/2	1		
FL	1	FILTER, LINE, 115V/6A, 252V/6A, W/CONN	446328	05245	6J4	1		
H	16	NUT, CAP, EXT. LOCK, STL, 8-32	195263	89536	195263	4		
H	17	SCREW, MACH, FHUP, S. STL, 8-32X1/4	320101	89536	320101	3		
H	18	SCREW, CAP, SCKT, STL, 8-32X3/8	295105	89536	295105	4		
H	19	WASHER, SHLDR, NYLON, #3	485417	89536	485417	4		
H	20	NUT, CAP, EXT. LOCK, STL, 4-40	195255	89536	195255	4		
H	21	SCREW, MACH, PHP SEMS, STL, 6-32X5/8	272591	89536	272591	6		
H	22	SCREW, MACH, RHS, STL, 8-32X2-1/2	114454	89536	114454	4		
H	23	WASHER, FLAT, S STEEL, #8, 0.032 THK	176743	86928	5710-31-32	8		
H	24	WASHER, FLAT, FIBER, #8, 0.063 THK	110353	73734	1472	4		
H	25	SCREW, MACH, FHP, STL, 6-32X1/2	558957	89536	558957	4		
H	26	SCREW, MACH, FHUP, S. STL, 6-32X1/4	320093	89536	320093	2		
H	27	SCREW, MACH, PHP SEMS, STL, 6-32X1/4	178533	89536	178533	5		
H	28	FAN ACCESSORY, GRILLE, WITH FOAM FILTER	740209	89536	740209	1		
H	29	NUT, CAP, EXT. LOCK, STL, 6-32	152819	89536	152819	5		
H	30	WASHER, LOCK, INTRNL, STEEL, #6	110338	89536	110338	1		
H	31	WASHER, SHLDR, FIBER, #6	110387	86928	5604-47	2		
H	32	NUT, HEX, MINI, S. STL, 6-32	110569	89536	110569	3		
H	33	WASHER, LOCK, INTRNL, STEEL, 0.267 ID	110817	89536	110817	3		
MP	20	REAR PANEL SH	657635	89536	657635	1		
MP	21	CORNER BRACKET	657601	89536	657601	2		
MP	22	CORNER HANDLE, FRONT 5.25 INCH	656173	89536	656173	2		
MP	23	SHOCK MOUNT, PS, 7116	732941	89536	732941	3		
MP	24	PLUG BUTTON	398206	89536	398206	2		
MP	25	BUSHING COVER RF OUTPUT	538256	89536	538256	1		
MP	26	INSUL PART, TRANS, SILICONE, POWER	534453	89536	534453	4		
MP	27	POLYOLEFIN #14 .120ID EXPAND BLK	149450	89536	149450			
MP	28	INSUL PART, TRANS, SILICONE, TO-3	473165	55285	7403-08-FR-05	1	1	
MP	29	POLYOLEFIN #12 .153ID EXPAND, BLACK	113852	89536	113852			
MP	30	TRANSFORMER COVER, PAINTED	731307	89536	731307	1		
MP	31	CABLE, NYLON STRAP, 4 IN L, SST-1	172080	89536	172080	2		
MP	32	CABLE, ETHYL CELLULOSE, TYPE 1/2-6R	100974	89536	100974	2		
MP	33	SELF-ADHESIVE, ABHM-1, ABS PLASTIC	407908	89536	407908	2		
MP	34	FAN SKIRT	716944	89536	716944	1		
MP	35	RETAINER, AUX PWR SUPPLY CONN	748640	89536	748640	1		
MP	38	HEAT DIS, TRANSISTOR, SNGL T03, ALUM	740738	89536	740738	1		
T	1	TRANSFORMER, POWER	717959	89536	717959	1		
U	1, 5	* IC, VOLT REG, FIXED, +15 VOLTS, 1.5 AMPS	413187	04713	MC7815CT	2	1	2
U	1	* IC, VOLT REG, FIXED, +5 VOLTS, 3 AMP, TO-3	453944	12040	LM223K	1		1
U	2	* IC, VOLT REG, FIXED, -15 VOLTS, 1.5 AMPS	413179	04713	MC7915CP	1	1	2
U	4	* IC, VOLT REG, ADJ, 1.2 TO 37 V, 1.5 AMPS	460410	12040	LM317T	1		2
W	2	CABLE ASSY, RF, REF IN/OUT	748681	89536	748681	1		
W	15	CABLE ASSY, POWER SWITCH	748673	89536	748673	1	1	
W	18	CABLE ASSY AUX TRANSFORMER	748798	89536	748798	1		

1 REFERED TO THROUGHOUT MANUAL AS A3U1

2 PART OF A3A1




### Figure 5-4. A3 Rear Section

# LIST OF REPLACEABLE PARTS

TABLE 5-5. A1A1 DISPLAY PCA  
(SEE FIGURE 5-5.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE-	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1		CAP,TA,4.7UF,+20%,50V	363721	56289	196D475X9015HA1	1		
C 2, 27, 28,		CAP,TA,10UF,+20%,10V	176214	56289	196D106X0010KA1	4		
C 30			176214					
C 3- 18		CAP,POLYES,0.1UF,+10%,50V	696484	89536	696484	16		
C 23, 24		CAP,TA,10UF,+20%,20V	330662	56289	196D106X0020KA1	2		
C 25, 26		CAP,TA,39UF,+20%,6V	163915	56289	196D394X0020KA1	2		
C 29		CAP,CER,0.001UF,+20%,100V,X7R	402966	72982	8121-A100-W5R-102M	1		
DS 1		DISPLAY VACUUM FLUORESCENT FREQUENCY	698456	89536	698456	1		
DS 2		DISPLAY VACUUM FLUORESCENT AMPLITUDE	698464	89536	698464	1		
J 101		CONN,POST,PWB,.025SQ,NON-INSUL,SELECT	267500	00779	87022-1	14		1
J 103		CONN,PWB,PIN,CRIMP,0.058 DIA	233411	00779	60599-3	2		
R 1, 2		RES,CF,100K,+5%,0.25W	348920	80031	CR251-4-5P100K	2		
R 3		RES,CF,620,+5%,0.25W	442319	80031	CR251-4-5P620E	1		
R 4		RES,MF,9.09K,+1%,0.125W,100PPM	221663	91637	CMF559091F	1		
R 5		RES,MF,31.6K,+1%,0.125W,100PPM	261610	91637	CMF553162F	1		
R 6		RES,MF,8.06K,+1%,0.125W,100PPM	294942	91637	CMF558061F	1		
R 7		RES,MF,2K,+1%,0.125W,100PPM	235226	91637	CMF552001F	1		
R 8		RES,MF,48.7K,+1%,0.125W,100PPM	267385	89536	267385	1		
R 9, 10		RES,CF,30K,+5%,0.25W	368753	80031	CR251-4-5P30K	2		
R 11- 14		RES,CC,10K,+10%,0.125W	246975	01121	BB1031	4		
R 15		RES,CC,560,+10%,0.125W	115303	89536	115303	1		
R 16		RES,VAR,CERM,5K,+10%,0.5W	208282	75378	360T052A2	1		
TP 1		CONN,TAB,FASTON,PRESS-IN,0.110 WIDE	512889	02660	62395	1		
U 1- 5		* IC,LSTTL,OCTAL D F/F,+EDG TRG,W/CLEAR	454892	01295	SN74LS273N	5		1
U 6- 10		* IC,BIPLR,8CHNL FLOURESCNT DISPLY DRVR	535799	56289	UDN6118A	5		
U 11, 17		* IC,LSTTL,RETRG MONOSTAB MULTIVB W/CLR	404186	01295	SN74LS123N	2		1
U 12		* IC,LSTTL,DUAL 4 INPUT AND GATE	408708	01295	SN74LS21N	1		1
U 13, 15		* IC,TTL,HEX INVERTER W/OPEN COLLECTOR	288605	01295	SN7416N	2		1
U 14		* IC,LSTTL,HEX BUFFER W/NOR ENABLE	483800	01295	SN74LS367N	1		1
U 16		* IC,COMPARATOR,DUAL,LO-PWR,8 PIN DIP	478354	12040	LM393N	1		1
U 18		* IC,1.22V,25 PPM T.C.,BANDGAP REF	634154	32293	ITS6935-2	1		1
W 8		CABLE ASSEMBLY, CONTROLLER-DISPLAY	738476	89536	738476	1		
XU 1- 5		SOCKET,DIP,0.100 CTR,20 PIN	454421	09922	DILB20P-108	5		
XU 6- 10		SOCKET,DIP,0.100 CTR,18 PIN	418228	91506	318-AG39D	5		
XU 11, 14, 17		SOCKET,DIP,0.100 CTR,16 PIN	276535	91506	316-AG39D	3		
XU 12, 13, 15		SOCKET,DIP,0.100 CTR,14 PIN	276527	09922	DILB8P-108	3		
XU 16		SOCKET, DIP,0.100 CTR,8 PIN	478016	91506	308-AG39D	1		
Z 1		RES,NET,SIP,10 PIN,9 RES,100K,+2%	461038	80031	95081002CL	1		
Z 2		RES,NET,SIP,10 PIN,9 RES,10K,+2%	414003	80031	95081002CL	1		



**Figure 5-5. A1A1 Display PCA**

# LIST OF REPLACEABLE PARTS

TABLE 5-6. A2A1 SYNTHESIZER PCA  
(SEE FIGURE 5-6.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1, 2		CAP, CER, 2.7PF, +-0.25PF, 100V, COJ	363705	89536	363705	2		
C 3, 4, 62,		CAP, CER, 0.001UF, +-20%, 100V, X7R	402966	72982	8121-A100-W5R-102M	16		
C 98, 100, 181,			402966					
C 182, 185, 186,			402966					
C 189, 190, 193,			402966					
C 196, 198, 199,			402966					
C 215			402966					
C 5, 7, 10-		CAP, CER, 470PF, +-20%, 100V, X7R	358275	72982	8111-A100-W5R-471M	17		
C 13, 20, 39,			358275					
C 40, 43, 52,			358275					
C 53, 205, 231-			358275					
C 234			358275					
C 8, 21, 154		CAP, CER, 6.8PF, +-0.25PF, 100V, COH	512327	89536	512327	3		
C 9, 15, 18,		CAP, CER, 100PF, +-2%, 100V, COG	512848	51406	RPE121	10		
C 26, 28, 64,			512848					
C 89, 137, 139,			512848					
C 146			512848					
C 14, 27, 30,		CAP, POLYES, 0.1UF, +-20%, 50V	732883	89536	732883	71		
C 31, 36, 37,			732883					
C 49, 55, 59-			732883					
C 61, 63, 65,			732883					
C 69, 70, 72-			732883					
C 74, 76- 81,			732883					
C 83, 84, 87,			732883					
C 88, 101-106,			732883					
C 108, 110, 112,			732883					
C 120, 122, 132,			732883					
C 133, 135, 138,			732883					
C 140-145, 157-			732883					
C 165, 167-169,			732883					
C 174, 175, 180,			732883					
C 184, 188, 191,			732883					
C 192, 194, 195,			732883					
C 200			732883					
C 16, 17		CAP, CER, 12PF, +-2%, 100V, COG	376871	89536	376871	2		
C 19		CAP, CER, 4.7PF, +-0.25PF, 100V, COH	362772	89536	362772	1		
C 25		CAP, CER, 10PF, +-5%, 50V, COG	494781	89536	494781	1		
C 29, 38, 201,		CAP, CER, 47PF, +-2%, 100V, COG	512368	89536	512368	4		
C 202			512368					
C 32		CAP, POLYST, 470PF, +-1%, 63V	528356	12954	831063/470/1/63	1		
C 33		CAP, POLYST, 100PF, +-1%, 63V	528372	12954	831063/100/1/63	1		
C 34		CAP, POLYST, 330PF, +-1%, 63V	528364	12954	831063/330/1/63	1		
C 35		CAP, POLYST, 1000PF, +-1%, 63V	528380	12954	831063/1000/1/63	1		
C 41, 42		CAP, POLYES, 0.047UF, +-10%, 50V	714709	89536	714709	2		
C 48		CAP, POLYES, 0.015UF, +-10%, 50V	714691	89536	714691	1		
C 50, 207		CAP, POLYES, 0.082UF, +-10%, 50V	714717	89536	714717	2		
C 51		CAP, POLYES, 0.1UF, +-10%, 50V	696484	89536	696484	1		
C 54, 71, 91,		CAP, TA, 10UF, +-20%, 10V	176214	56289	196D106X0010KA1	5		
C 127, 166			176214					
C 58, 82, 107,		CAP, TA, 39UF, +-20%, 6V	163915	56289	196D394X0020KA1	5		
C 150, 173			163915					
C 75, 85, 86,		CAP, CER, 22PF, +-2%, 100V, COG	512871	89536	512871	6		
C 95, 155, 156			512871					
C 92- 94, 128		CAP, TA, 10UF, +-20%, 35V	417683	56289	196D106X0035KA1	4		
C 99		CAP, POLYST, 0.0075UF, 2%, 100V	484121	89536	484121	1		
C 109, 111		CAP, TA, 15UF, +-20%, 20V	519686	56289	196D156X0020KE4	2		
C 113, 114		CAP, POLYES, 0.22UF, +-10%, 50V	696492	89536	696492	2		
C 115		CAP, POLYPR, 0.0786UF, +-1%, 50V	422998	89536	422998	1		
C 116, 117		CAP, TA, 3.3UF, +-20%, 20V	436071	01884	196D335X0020KA1	2		
C 118, 183, 187		CAP, POLYES, 0.47UF, +-10%, 50V	714725	89536	714725	3		
C 119, 121		CAP, CER, 1000PF, +-5%, 50V, COG	528539	51406	RPE113	2		
C 123		CAP, POLYST, 0.022UF, +-5%, 100V	484147	89536	484147	1		
C 124		CAP, POLYST, 0.056UF, +-5%, 100V	284877	89536	284877	1		
C 125		CAP, POLYST, 0.027UF, +-5%, 100V	484154	89536	484154	1		
C 126		CAP, POLYST, 0.0015UF, +-2%, 100V	484113	89536	484113	1		
C 129, 130		CAP, TA, 82UF, +-20%, 20V	357392	12954	D82G32D20M	2		
C 131		CAP, POLYCA, 5UF, +-10%, 50V	313254	84411	X463UW5.0UF-10P-50	1		
C 134		CAP, TA, 15UF, +-20%, 6V	161935	56289	196D156X0006-KA1	1		
C 136		CAP, TA, 2.2UF, +-10%, 15V	364216	56289	196D225X0015HA1	1		
C 151		CAP, CER, 120PF, +-2%, 50V, T2J	362673	89536	362673	1		
C 152		CAP, CER, 56PF, +-2%, 100V, COG	512970	51406	RPE121	1		
C 153		CAP, VAR, 1 TO 10PF, 250V, AIR	733212	89536	733212	1		
C 176		CAP, POLYES, 0.27UF, +-10%, 50V	733576	89536	733576	1		
C 177		CAP, POLYES, 0.15UF, +-10%, 50V	682955	89536	682955	1		
C 178		CAP, TA, 6.8UF, +-20%, 35V	363713	56289	196D685X0035KA1	1		
C 179		CAP, CER, 2200PF, +-20%, 100V, X7R	358291	89536	358291	1		
C 197, 219, 227		CAP, CER, 10PF, +-2%, 100V, COG	512343	89536	512343	3		
C 204		CAP, CER, 330PF, +-5%, 100V, COG	528620	51406	RPE121	1		
C 206		CAP, VAR, 0.8-10PF, 250V, AIR	229930	91293	5201	1		
C 208, 209, 221		CAP, AL, 220UF, +-50-20%, 16V	435990	57640	SM/VB	3		
C 210, 211, 214,		CAP, CER, 180PF, +-5%, 100V, COG	603506	56289	C023B501E181M	10		
C 216, 218, 224-			603506					
C 226, 228, 230			603506					
C 212, 222		CAP, CER, 330PF, +-20%, 50V, X7R	650093	89536	650093	2		
C 213, 217, 223		CAP, CER, 4.3PF, +-0.5PF, 50V, COG	514216	89536	514216	3		
C 220		CAP, CER, 3.9PF, +-0.25PF, 100V, COJ	512947	89536	512947	1		
CR 2		* ZENER, COMP, 6.4V, 3%, 1 PPM TC, 2.0MA	357848	04713	SZG20118	1	2	
CR 5- 8, 17,		* DIODE, SI, BV= 75.0V, IO=150MA, 500 MW	203323	07910	1N4448	7	1	
CR 18, 21			203323					
CR 9, 10, 12-		* DIODE, SI, SCHOTTKY BARRIER, SMALL SIGNAL	313247	28484	HP5082-6264	6	2	
CR 15			313247					
CR 11		* ZENER, UNCOMP, 10.0V, 10%, 12.5MA, 0.4W	113324	07910	1N961A	1	1	
CR 16		* ZENER, UNCOMP, 8.2V, 5%, 20.0MA, 0.4W	386771	04713	1N756A	1	1	
CR 24, 26, 27		* DIODE, SI, VARACTOR, PIV= 30V, HYPER ABRU	722140	89536	722140	3	1	



## LIST OF REPLACEABLE PARTS

TABLE 5-6. A2A1 SYNTHESIZER PCA (CONT.)  
(SEE FIGURE 5-6.)


REFERENCE DESIGNATOR A->NUMERICS----	S	DESCRIPTION-----	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S T	N O T E
J 1, 3, 14, 17, 35, 55		CONN, POST, PWB, .025SQ, NON-INSUL, SELECT	267500	00779	87022-1	12		
J 2, 7, 11, 12, 14- 16, 22- 25, 27, 31- 46, 49- 54, 56		CONN, TAB, FASTON, PRESS-IN, 0.110 WIDE	267500 512889 512889 512889 512889	02660	62395	35		
J 101		SOCKET, SIP, 0.100 CTR, 9 PIN	436774	30035	33-109-1-09	2		
J 104, 107, 108, J 110		CONN, SOCKET, SPRING TYPE, .0690D, .143L	732826 732826	89536	732826	4		
J 109 J 112		SOCKET, SIP, 0.100 CTR, 7 PIN CONN, COAX, SMB, REC, PWB	520809 512095	30035 16733	SS-109-1-07 702033	1 1		
L 1, 18, 21, 23, 29- 32, 34, 65		CHOKE, 6TURN	320911 320911 320911	89536	320911	10		
L 2, 3, 71, 72		INDUCTOR, 0.10 UH, +/-10%, 400MHZ, SHLDED	257154 257154	24759	MR0R10	4		
L 4, 19, 20, 40- 42, 44, 56- 58		INDUCTOR, 0.68 UH, +/-10%, 221MHZ, SHLDED	320937 320937 320937	24759	MR0.68	10		
L 5, 10, 63, 64		CORE, TOROID, FERRITE, .047X.138X.118	321182 321182	89536	321182	4		
L 11 L 17		INDUCTOR, 150 UH, +/-5%, 10.5 MHZ, SHLDED INDUCTOR, 220 UH, +/-5%, 9.4 MHZ, SHLDED	174763 147835	72259 72259	WEE150 WEE220	1 1		
L 43 L 49		INDUCTOR, 10 UH, +/-10%, 53 MHZ, SHLDED INDUCTOR ADJ 8.4MH	249078 704999	24759 89536	MR10 704999	1 1		
L 50 L 59		INDUCTOR ADJ 11.1MH INDUCTOR, 125UH	705004 738484	89536 89536	705004 738484	1 1		
L 62 L 66		INDUCTOR, 470 UH, +/-5%, 6.5 MHZ, SHLDED INDUCTOR, 0.82UH, +/-10%, 200MHZ, SHLDED	147827 320945	72259 89536	WEE470 320945	1 1		
L 67, 68 L 70		CORE, TOROID, FERRITE, .079X.185X.291 INDUCTOR, 0.044UH, +/-15%, 500MHZ, SHLDED	219535 249110	25088 72259	B62110A5030X025C WEE0R044	2 1		
MP 1		COMPONENT HOLDER	422865	98159	2829-75-2	1		
P 101, 102, 111		CONN, SOCKET, PWB, 0.049 DIAMETER	544056	89536	544056	7		
Q 2, 33, 37 Q 3	*	TRANSISTOR, SI, NPN, HI-FREQ, SMALL SIGNAL TRANSISTOR, SI, NPN, HI-FREQ, SMALL SIGNAL	535013 723379	04713 89536	BFR91 723379	3 1	1	
Q 4, 5 Q 10- 12	*	TRANSISTOR, SI, PNP, HI-SPEED SWITCH TRANSISTOR, SI, N-JFET, TO-92	369629 604678	07263 17856	543576 J2464	2 3	1	
Q 13, 14 Q 15, 21, 23	*	TRANSISTOR, SI, N-DMOS FET, TO-72 TRANSISTOR, SI, NPN, SMALL SIGNAL	477729 218396	18324 04713	SD213EE 2N3904	2 3	1	
Q 16, 17 Q 18, 19	*	TRANSISTOR, SI, NPN, SMALL SIGNAL TRANSISTOR, SI, PNP, SMALL SIGNAL	248351 225599	04713 07263	MPS918 2N4250	2 2	1	
Q 20 Q 22	*	TRANSISTOR, SI, NPN, DARLINGTON TRANSISTOR, SI, PNP, SMALL SIGNAL	381798 195974	04713 64713	MPSA-13 2N3906	1 1	1	
Q 26, 27 Q 28	*	TRANSISTOR, SI, N-JFET, UHF/VHF USE TRANSISTOR, SI, PNP, SMALL SIGNAL	403634 418707	12040 04713	J310 MPS56562	2 1	1	
Q 32, 35 R 1	*	TRANSISTOR, SI, NPN, SMALL SIGNAL RES, CC, 120, +/-10%, 0.5W	483156 108696	89536 01121	483156 EB1211	2 1	1	
R 2, 159, 201, R 209		RES, CF, 0.51, +/-5%, 0.25W	381954 381954	80031	CR251-4-5P0R5E	4		
R 3, 25, 32 R 4		RES, CC, 51, +/-5%, 0.125W RES, CF, 430, +/-5%, 0.25W	266262 441568	01121 80031	BB5105 CR251-4-5P430E	3 1		
R 5 R 6, 56- 58, R 66- 69, 124, R 127, 133-139, R 210, 212		RES, CC, 24, +/-5%, 0.125W RES, CC, 100, +/-5%, 0.125W	681932 714469	89536 89536	681932 714469	1 19		
R 7, 44, 94, R 148, 152, 154, R 169, 170		RES, CF, 1K, +/-5%, 0.25W	343426 343426 343426	80031	CR251-4-5P1K	8		
R 8 R 9		RES, CF, 470, +/-5%, 0.25W RES, CF, 200, +/-5%, 0.25W	343434 441451	80031 80031	CR251-4-5P470E CR251-4-5P200E	1 1		
R 10 R 11, 74, 100, R 153		RES, CC, 33, +/-5%, 0.125W RES, CF, 1.5K, +/-5%, 0.25W	720920 343418	89536 80031	720920 CR251-4-5P1K5	1 4		
R 12, 46, 165, R 167, 171, 172, R 177, 211		RES CC 510 +/-5% 0.125W	715383 715383 715383	89536	715383	8		
R 13 R 14, 15, 198		RES, CC, 150, +/-5%, 0.5W RES, CC, 30, +/-5%, 0.125W	186056 512723	89536 01121	186056 BB3005	1 3		
R 20 R 21, 22		RES, CC, 47, +/-5%, 0.125W RES, CC, 15, +/-10%, 0.125W	512061 261800	01121 89536	BB4705 261800	1 2		
R 23, 24, 40 R 26, 31, 65, R 101		RES, CF, 56, +/-5%, 0.25W RES, MF, 100, +/-1%, 0.125W, 100PPM	342618 168195	80031 91637	CR251-4-5P56E CMF551000F	3 4		
R 27 R 28		RES, MF, 18.2K, +/-1%, 0.125W, 100PPM RES, MF, 10.7K, +/-1%, 0.125W, 100PPM	236810 293613	91637 91637	CMF55 CMF55	1 1		
R 29 R 30		RES, MF, 11.3K, +/-1%, 0.125W, 100PPM RES, MF, 28.7K, +/-1%, 0.125W, 100PPM	293639 235176	91637 91637	CMF551132 CMF552872F	1 1		
R 33, 161 R 39, 164		RES, CF, 51, +/-5%, 0.25W RES, CF, 300, +/-5%, 0.25W	414540 441519	80031 80031	CR251-4-5P51E CR251-4-5P300E	2 2		
R 41 R 42		RES, CF, 270, +/-5%, 0.25W RES, CF, 180, +/-5%, 0.25W	348789 441436	80031 80031	CR251-4-5P270E CR251-4-5P180E	1 1		
R 43 R 45		RES, CF, 91, +/-5%, 0.25W INDUCTOR, 4 TURN	441683 755314	80031 89536	CR251-4-5P91E 755314	1 1		
R 52 R 55		RES, MF, 3.01K, +/-1%, 0.125W, 100PPM RES, CF, 2.7K, +/-5%, 0.25W	312645 386490	91637 80031	CMF553011F CR251-4-5P2K7	1 1		
R 72 R 73		RES, CF, 51K, +/-5%, 0.25W RES, CF, 3.3K, +/-5%, 0.25W	376434 348813	80031 80031	CR251-4-5P51K CR251-4-5P3K3	1 1		
R 75, 76 R 77		RES, MF, 10K, +/-1%, 0.125W, 100PPM RES, MF, 90K, +/-0.1%, 0.25W, 50PPM	168260 225763	91637 89536	CMF551002F 225763	2 1		
R 78 R 79		RES, MF, 9K, +/-0.1%, 0.25W, 50PPM RES, MF, 1K, +/-0.1%, 0.25W, 50PPM	236695 225813	89536 89536	236695 225813	1 1		
R 80, 88, 91 R 81, 182, 191 R 82, 104		RES, MF, 4.99K, +/-1%, 0.125W, 100PPM RES, MF, 1K, +/-1%, 0.125W, 100PPM RES, VAR, CERM, 5K, +/-10%, 0.5W	168252 168229 288282	91637 91637 75378	MFF1-84991 CMF551001F 360T052A2	3 3 2		

# LIST OF REPLACEABLE PARTS

TABLE 5-6. A2A1 SYNTHESIZER PCA (CONT.)  
(SEE FIGURE 5-6.)

REFERENCE DESIGNATOR	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
A--NUMERICS-->	S	-----DESCRIPTION-----				
R 83		RES,CF,75K,+5%,0.25W	394130	80031	CR251-4-5P75K	1
R 84, 89		RES,MF,4.02K,+1%,0.125W,100PPM	235325	91637	CMF554021F	2
R 86		RES,CF,200K,+5%,0.25W	441485	80031	CR251-4-5P200K	1
R 87, 90		RES,VAR,CERM,1K,+10%,0.5W	275750	11236	360T-102A	2
R 92, 93,113-		RES,MF,499,+1%,0.125W,100PPM	168211	91637	CMF554990F	5
R 115			168211			
R 95		RES,CF,9.1K,+5%,0.25W	441691	80031	CR251-4-5P9K1	1
R 96		RES,CF,820,+5%,0.25W	442327	80031	CR251-4-5P820E	1
R 97		RES,CF,6.8K,+5%,0.25W	368761	80031	CR251-4-5P6K8	1
R 98,121,147,		RES,CF,100,+5%,0.25W	348771	80031	CR251-4-5P100E	4
R 149			348771			
R 99		RES,MF,1.5K,+1%,0.125W,100PPM	313098	91637	CMF551501F	1
R 102,103,119,		RES,CF,10K,+5%,0.25W	348839	80031	CR251-4-5P10K	4
R 129			348839			
R 105		RES,CF,20K,+5%,0.25W	441477	80031	CR251-4-5P20K	1
R 106		RES,CF,2.4K,+5%,0.25W	441493	80031	CR251-4-5P2K4	1
R 107		RES,MF,3.48K,+1%,0.125W,100PPM	260687	91637	CMF553481F	1
R 108,116		RES,MF,1.27K,+1%,0.125W,100PPM	267369	91637	CMF551271F	2
R 109,111		RES,CC,510,+5%,0.5W	108951	01121	RC0206F511JS	2
R 110,112		RES,CF,36,+5%,0.25W	442236	80031	CR251-4-5P36E	2
R 117,118		RES,CF,220,+5%,0.25W	342626	80031	CR251-4-5P220E	2
R 120,163		RES,CF,4.7K,+5%,0.25W	348821	01121	CB4725	2
R 122		RES,CF,5.6K,+5%,0.25W	442350	80031	CR251-4-5P5K6	1
R 123		RES,CF,33K,+5%,0.25W	348888	80031	CR251-4-5P33K	1
R 145		RES,CF,1M,+5%,0.25W	348987	80031	CR251-4-5P1M	1
R 146,150		RES,CF,390,+5%,0.25W	441543	80031	CR251-4-5P390E	2
R 151		RES,CF,2.2K,+5%,0.25W	343400	80031	CR251-4-5P2K2	1
R 160		RES,CF,750,+5%,0.25W	441659	80031	CR251-4-5P750E	1
R 162		RES,CC,10K,+5%,0.125W	643940	01121	BB1035	1
R 178,179		RES,CF,5.6,+5%,0.25W	441618	80031	CR251-4-5P5R6	2
R 180,192		RES,MF,178,+1%,0.125W,100PPM	442996	89536	442996	2
R 181,193		RES,MF,1.05K,+1%,0.125W,100PPM	293530	91637	CMF551051F	2
R 183,194		RES,MF,3.24K,+1%,0.125W,100PPM	223578	91637	CMF553241F	2
R 184,195,197,		RES,CC,180,+5%,0.125W	512756	01121	BB1815	4
R 200			512756			
R 185,199		RES,MF,249,+1%,0.125W,100PPM	168203	91637	CMF55249F	2
R 186		RES,CC,47,+5%,0.125W	512061	01121	BB4705	1
R 187,189		RES,CC,120,+5%,0.125W	513978	01121	BB1215	2
R 188,196		RES,CC,12,+5%,0.125W	714451	89536	714451	2
R 190		RES,CF,5.1,+5%,0.25W	441287	80031	CR251-4-5P5R1	1
R 213,214		RES,CC,200,+5%,0.125W	713917	89536	713917	2
U 1		* IC,VOLT REG,FIXED,+5 VOLTS,0.1 AMPS	429910	07263	uA78L05AWC	1
U 1		* 1.3 GHZ DIVIDE BY 2	707943	89536	707943	1
U 6		3DB COUPLER	704965	89536	704965	1
U 7, 8		MIXER,DOUBLE BALANCED,1 - 500 MHZ	733105	89536	733105	2
U 9		* IC,BPLR,MONOLITHIC VHF-UHF AMPLIFIER	723387	89536	723387	1
U 10		* IC,OP AMP,QUAD,JFET INPUT,TO-5 CASE	483438	89536	483438	1
U 15, 58		* IC,TTL,100MHZ DIV BY 2,DIV BY 5 CNTR	473835	01295	SN74LS196N	2
U 16		* IC,LSTTL,DUAL DIV BY 2,DIV BY 5 CNTR	483594	01295	SN74LS390N	1
U 17		* IC,STTL, 360 CELL GATE ARRAY	723718	89536	723718	1
U 18		* IC,ECL,DUAL D M/S F/F,W/SET&RESET	454959	04713	MC10131P	1
U 19		* IC,ECL,QUAD 2 INPUT NOR GATE	380881	04713	MC10102P	1
U 20		* IC,ECL,DIV BY 10,DIV BY 11 COUNTER	454900	89536	454900	1
U 26, 30- 32		* IC,LSTTL,OCTAL D F/F,+EDG TRG,W/CLEAR	454892	01295	SN74LS273N	4
U 27, 29		* IC,CHOS,10BIT DAC,10BIT ACCUR,CUR OUT	507566	24355	AD7533LN	2
U 28		* IC,OP AMP,DUAL,JFET INPUT,8 PIN DIP	495192	12040	LF353BN	1
U 33		* IC,STTL, 360 CELL GATE ARRAY	723700	89536	723700	1
U 34		* IC,FTTL,QUAD 2 INPUT NAND GATE	654640	07263	74F00PC	1
U 35, 66		* IC,FTTL,DUAL D F/F,+EDG TRG,W/CL&SET	659508	07263	74F74PC	2
U 37		* IC,LSTTL,3-8 LINE DCDR W/ENABLE	407585	01295	SN74LS138N	1
U 38		* IC,LSTTL,OCTL LINE DRVR W/3-STATE OUT	429035	01295	SN74LS244N	1
U 41		* IC,OP AMP,QUAD JFET INPUT,14 PIN DIP	659748	89536	659748	1
U 42		* IC,COMPARATOR,QUAD,14 PIN DIP	387233	12040	LM339N	1
U 43, 44, 59		* IC,STTL,DUAL D F/F,+EDG TRG,W/SET&CLR	418269	01295	SN74LS74N	3
U 45, 65		* IC,STTL,QUAD 2 INPUT NAND GATE	363580	01295	SN7400SN	2
U 46		* IC,ARRAY,5 TRANS,5 ISO: 2-PNP,3-NPN	418954	02735	CA3094E	1
U 47		* IC,LSTTL,RETRG MONOSTAB MULTIVIB W/CLR	412734	01295	SN74LS122N	1
U 48, 60		* IC,OP AMP,JFET INPUT,8 PIN DIP	472779	12040	LF386N	2
U 49		* IC,OP AMP,SELECTED GBW 600KHZ	418566	12040	LM358N	1
U 50		* ISOLATOR,OPTO,LED TO TRANSISTOR,DUAL	454330	07263	MCT-6	1
U 54		* IC,FTTL,HEX INVERTER	634444	07235	74F04PC	1
U 55		* DUAL 4-INPUT MULTIPLEXER	707935	89536	707935	1
U 61		* IC,ECL,DIVIDE BY 4 PRESCALER	722157	89536	722157	1
U 62, 63		* IC,ECL,DUAL D M/S F/F,+EDG TRG	525345	04713	MC10231L	2
U 64		* IC,ECL,TRIPLE 2/3 INPUT OR/NOR GATE	723437	89536	723437	1
W 1, 2		CABLE ASSY, RF JUMPER	716985	89536	716985	2
W 3		WIRE,PVC,26AWG,TW-PR,STRND,PUR-BLK	597849	89536	597849	1
XU 10, 15, 34-		SOCKET,DIP,0.100 CTR,14 PIN	276527	09922	DILB8P-108	14
XU 36, 41- 45,			276527			
XU 47, 58, 59,			276527			
XU 65			276527			
XU 18, 19, 27,		SOCKET,DIP,0.100 CTR,16 PIN	276535	91506	316-AG39D	11
XU 29, 46, 62-			276535			1
XU 64			276535			1
XU 26, 30- 32		SOCKET,DIP,0.100 CTR,20 PIN	454421	09922	DILB20P-108	4
XU 28, 38, 41,		SOCKET, DIP,0.100 CTR,8 PIN	478016	91506	308-AG39D	7
XU 48- 50, 60			478016			
Y 1		* CRYSTAL,10MHZ,+0.001%,HC-18/U	385732	89536	385732	1
Z 1		RES,NET,CERM,CUSTOM	501841	89536	501841	1
Z 5		RES,NET,SIP,10 PIN,9 RES,510,+2%	478800	89536	478800	1
Z 6		RES,NET,SIP,6 PIN,5 RES,100K,+2%	412726	89536	412726	1
Z 9		RES,NET,DIP,16 PIN,8 RES,1K,+5%	358119	01121	314	1
Z 10		RES,NET,SIP,6 PIN,5 RES,510,+2%	459974	89536	459974	1

1 ALSO INCLUDES XZ1 AND XZ29.




6060A-1619

Figure 5-6. A2A1 Synthesizer PCA

5-16

THE FOLLOWING COMPONENTS ARE NON FIELD REPLACEABLE:

C1, 3, 4, 5, 6, 8, 10, 11, 14, 15, 18, 19, 21, 26, 27, 29, 31, 32, 36, 37  
CR1, 2, 3, 4  
Q1, 2, 3, 4  
R1, 2, 3, 4, 16, 17, 18, 19, 25, 30



6060A-1618

Figure 5-7. A2A2 VCO PCA

# LIST OF REPLACEABLE PARTS

TABLE 5-8. A2A4 OUTPUT PCA  
(SEE FIGURE 5-8.)

REFERENCE DESIGNATOR A->NUMERIC-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R \$ -Q	N O T -E
C 101, 104, 106, C 115-117, 137, C 138, 144, 151, C 152, 154-156, C 231, 238-240, C 243, 246, 247, C 250, 253, 301, C 303, 305, 307- C 314, 317-321, C 416		CAP, CER, 100PF, +-2%, 100V, COG	512848 512848 512848 512848 512848 512848 512848 512848 512848 512848	51406	RPE121	40		
C 103, 145, 148, C 201-204, 206- C 208, 210, 211, C 213, 214, 235, C 245, 249, 260- C 262, 264-266, C 271-274, 302, C 304, 306, 403, C 404, 406, 412		CAP, POLYES, 0.1UF, +-20%, 50V	732883 732883 732883 732883 732883 732883 732883 732883 732883 732883	89536	732883	34		
C 107, 124, 147, C 157, 242, 254- C 256, 259, 269, C 270		CAP, CER, 0.001UF, +-20%, 100V, X7R	402966 402966 402966 402966	72982	8121-A100-W5R-102M	11		
C 108, 119, 121- C 123		CAP, CER, 5.6PF, +-0.25PF, 100V, COH	512954 512954	89536	512954	5		
C 109, 110, 118 C 111, 236, 237 C 112, 113 C 114, 244, 248, C 263		CAP, CER, 3.9PF, +-0.25PF, 100V, COJ CAP, CER, 3.3PF, +-0.25PF, 100V, COJ CAP, CER, 2.2PF, +-0.25PF, 100V, COG CAP, CER, 1.8PF, +-0.25PF, 100V, COK	512947 519330 362731 512897 512897	89536 89536 89536 89536	512947 519330 362731 512897	3 3 2 4		
C 120, 224, 275 C 125, 127, 129, C 131, 133, 135, C 149		CAP, CER, 2.7PF, +-0.25PF, 100V, COJ CAP, CER, 0.01UF, +-20%, 50V, Z5U	363705 614214 614214 614214	89536 72982	363705 8121-050-651-10NFM	3 7	1	
C 126 C 130, 134 C 139 C 140 C 142 C 146 C 205 C 209, 212, 230 C 216, 218, 220, C 223		CAP, AL, 22UF, +-20%, 16V CAP, AL, 15UF, +-20%, 35V CAP, CER, 1200PF, +-20%, 100V, X7R CAP, CER, 1800PF, +-5%, 50V, COG CAP, CER, 4700PF, +-20%, 100V, X7R CAP, CER, 220PF, +-2%, 100V, COG CAP, CER, 39PF, +-2%, 100V, COG CAP, CER, 27PF, +-2%, 100V, COG CAP, CER, 8.2PF, +-0.25PF, 100V, COH	614750 614024 358283 528547 362871 512111 512962 362749 715359 715359	89536 89536 72982 89536 72982 51406 89536 51406 89536	614750 614024 8121-A100-W5R-122M 528547 8121-A100-W5R-472M RPE121 512962 RPE121 715359	1 2 1 1 1 1 1 3 4		
C 217 C 219, 226-229, C 277		CAP, CER, 18PF, +-2%, 100V, COG CAP, CER, 4.7PF, +-0.25PF, 100V, COH	512335 362772 362772	51406 89536	RD870-100V 362772	1 6		
C 221 C 222 C 225, 252 C 251, 405 C 267, 411 C 322, 409 C 401, 402 C 407, 408 C 410		CAP, CER, 10PF, +-2%, 100V, COG CAP, CER, 12PF, +-2%, 100V, COG CAP, CER, 6.8PF, +-0.25PF, 100V, COH CAP, CER, 47PF, +-2%, 100V, COG CAP, TA, 2.2UF, +-20%, 35V CAP, TA, 0.47UF, +-20%, 35V CAP, AL, 47UF, +-50-20%, 16V CAP, POLYPR, 0.0786UF, +-1%, 50V CAP, TA, 4.7UF, +-20%, 25V	512343 376871 512327 512368 485185 161349 436006 422998 161943	89536 89536 89536 89536 56289 56349 89536 89536 56289	512343 376871 512327 512368 196225X0035KA1 196D474X0035HA1 SM/VB 422998 196D475X0025KA1	1 1 2 2 2 2 2 2 1		
CR 101, 105, 111- CR 116, 203, 205- CR 208, 210 CR 102-104, 106- CR 110, 129, 204, CR 209	*	DIODE, SI, PIN, LO-FREQ, BV=100.0V DIODE, SI, PIN, RF ATTENUATING	321216 321216 321216	28480 26629	5082-3080 KS8379	14 11	1	
CR 117-120 CR 121, 301 CR 123, 124 CR 125 CR 126, 202 CR 127, 128 CR 130, 201 CR 302 CR 401, 402 CR 403	*	DIODE, SI, PIN, SMALL SIGNAL, UHF & VHF ZENER, UNCOMP, 5.1V, 5%, 20.0MA, 0.4W DIODE, SI, BV= 50.0V, IO=150MA, SELCTD VF ZENER, UNCOMP, 4.3V, 5%, 20.0MA, 0.4W DIODE, SI, SCHOTTKY, MATCHED SET OF 2 DIODE, SI, SCHOTTKY BARRIER, SMALL SIGNL DIODE, SI, BV= 75.0V, IO=150MA, 500 MW ZENER, UNCOMP, 15.0V, 5%, 8.5MA, 0.4W DIODE, SI, SCHOTTKY BARRIER, SMALL SIGNL ZENER, COMP, 6.3V, 2%, 50 PPM TC, 7.5MA	402776 159798 234468 180455 722470 535195 203323 266601 313247 172148	28480 04713 07910 07910 89536 28480 07910 04713 28484 89536	HP3379 1N751A TD9039 IN749A 722470 5082-2800 1N4448 1N965B HP5082-6264 172148	4 2 2 1 1 2 2 1 2 1	1	
L 102, 106, 108, L 110, 115, 230 L 103-105, 225 L 113, 116, 209, L 210, 214-217, L 220, 224, 227 L 201-203, 221, L 228		INDUCTOR, 0.68 UH, +/-10%, 221MHZ, SHLDED INDUCTOR, 10 TURNS INDUCTOR, 390 UH, +/-5%, 6.9 MHZ, SHLDED	320911 320911 186288 186288	24759 89536 72259	MR0.68 463448 WEE390	4 11 5		
P 101, 113 P 102, 107, 108 P 104 P 106 Q 101, 102, 202 Q 103, 302, 304, Q 306 Q 104, 201, 203, Q 205, 208, 210, Q 212, 214 Q 105, 106 Q 204, 206, 209, Q 211		CONN, SOCKET, PWB, 0.049 DIAMETER PIN TEST BASE CONN, POST, PWB, .025SQ, NON-INSUL, SELECT CONN, SOCKET, PWB, 0.022 DIAMETER TRANSISTOR, SI, NPN, HI-FREQ, SMALL SIGNL TRANSISTOR, SI, NPN, SMALL SIGNAL TRANSISTOR, SI, PNP, SMALL SIGNAL TRANSISTOR, SI, NPN, SMALL SIGNAL TRANSISTOR, SI, NPN, HI-FREQ, SMALL SIGNL	544056 698472 267500 376418 535013 330803 330803 195974 195974 195974 218396 723379 723379	89536 89536 00779 22526 04713 07263 04713 64713 04713 89536	544056 698472 87022-1 75060-005 BFR91 HPS6560 2N3904 2N3904 723379	19 3 14 1 3 4 8 2 4	1	

# LIST OF REPLACEABLE PARTS

TABLE 5-8. A2A4 OUTPUT PCA (CONT.)  
(SEE FIGURE 5-8.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
Q 207	*	TRANSISTOR, SI, NPN, SMALL SIG, MICROWAVE	483172	89536	483172	1	1	
Q 213, 215	*	TRANSISTOR, SI, NPN, HI-FREQ, SMALL SIGNAL	722256	89536	722256	2	1	
Q 301, 303, 305,	*	TRANSISTOR, SI, PNP, SMALL SIGNAL	418707	04713	MFS56562	4	1	
Q 307	*		418707					
Q 401, 403	*	TRANSISTOR, SI, N-JFET, TO-92, SWITCH	261578	15818	U2366J	2	1	
Q 402	*	TRANSISTOR, SI, N-JFET, TO-92	376475	15818	U2810J	1	1	
R 101, 102, 104,		RES, CF, 1K, +-5%, 0.25W	343426	80031	CR251-4-5P1K	19		
R 114-120, 151,			343426					
R 156, 269-271,			343426					
R 316-318, 320			343426					
R 103, 121, 122		RES, CC, 39, +-5%, 0.125W	713909	89536	713909	3		
R 105		RES, CC, 82, +-5%, 0.125W	721043	89536	721043	1		
R 106		RES, CF, 470, +-5%, 0.25W	343434	80031	CR251-4-5P470E	1		
R 107		RES, CF, 200, +-5%, 0.25W	441451	80031	CR251-4-5P200E	1		
R 108, 124, 125		RES, MF, 2.15K, +-1%, 0.125W, 100PPM	293712	91637	CHF552151F	3		
R 109		RES, CC, 510, +-5%, 0.125W	715383	89536	715383	1		
R 110		RES, CC, 270, +-5%, 0.5W	159616	01121	EB2715	1		
R 111, 112, 159,		RES, CC, 51, +-5%, 0.125W	266262	01121	BB5105	6		
R 243-245			266262					
R 113		RES, CC, 18, +-5%, 0.125W	500397	01121	BB1805	1		
R 123, 238		RES, MF, 2.67K, +-1%, 0.125W, 100PPM	289587	91637	CHF552671F	2		
R 126		RES, MF, 1.65K, +-1%, 0.125W, 100PPM	293662	91637	CHF551631	1		
R 127		RES, MF, 665, +-1%, 0.125W, 100PPM	320028	91637	CHF556650F	1		
R 128, 129		RES, MF, 124K, +-1%, 0.125W, 100PPM	288407	91637	CHF551243F	2		
R 130		RES, MF, 1.54K, +-1%, 0.125W, 100PPM	289066	91637	CHF551541F	1		
R 131		RES, MF, 3.48K, +-1%, 0.125W, 100PPM	260687	91637	CHF553481F	1		
R 132		RES, MF, 24.3K, +-1%, 0.125W, 100PPM	236745	91637	CHF55	1		
R 133		RES, MF, 6.04K, +-1%, 0.125W, 100PPM	285189	91637	CHF556041F	1		
R 134		RES, MF, 21.5K, +-1%, 0.125W, 100PPM	168278	89536	168278	1		
R 135, 304, 413,		RES, MF, 10K, +-1%, 0.125W, 100PPM	168260	91637	CHF551002F	4		
R 414			168260					
R 136, 266		RES, MF, 2.55K, +-1%, 0.125W, 100PPM	325498	91637	CHF552551F	2		
R 137		RES, MF, 499, +-1%, 0.125W, 100PPM	168211	91637	CHF554990F	1		
R 138		RES, MF, 16.9K, +-1%, 0.125W, 100PPM	267146	91637	CHF551692F	1		
R 139		RES, MF, 34.8K, +-1%, 0.125W, 100PPM	261487	89536	261487	1		
R 140, 148, 149		RES, MF, 1K, +-1%, 0.125W, 100PPM	168229	91637	CHF551001F	3		
R 141		RES, MF, 37.4K, +-1%, 0.125W, 100PPM	226241	91637	CHF553742F	1		
R 142		RES, MF, 100K, +-1%, 0.125W, 100PPM	248807	91637	CHF551003F	1		
R 143, 147		RES, MF, 20K, +-1%, 0.125W, 100PPM	291872	91637	CHF552002F	2		
R 144		RES, VAR, CERM, 2K, +-10%, 0.5W	309666	89536	309666	1	3	
R 145		RES, MF, 66.5K, +-1%, 0.125W, 100PPM	289082	91637	CHF556652F	1		
R 146, 422		RES, MF, 49.9K, +-1%, 0.125W, 100PPM	268821	91637	CHF554992F	2		
R 150, 233, 242		RES, CC, 180, +-5%, 0.125W	512756	01121	BB1815	3		
R 152		RES, CF, 270, +-5%, 0.25W	348789	80031	CR251-4-5P270E	1		
R 153, 158, 314,		RES, CF, 4.7K, +-5%, 0.25W	348821	01121	CB4725	4		
R 319			348821					
R 154		RES, CC, 22, +-5%, 0.125W	474767	01121	BB1-82205	1		
R 155		RES, CF, 1, +-5%, 0.25W	357665	80031	CR251-4-5P1E	1		
R 157, 272		RES, CC, 1K, +-5%, 0.125W	643932	01121	BB1025	2		
R 201, 207, 213,		RES, CF, 2K, +-5%, 0.25W	441469	80031	CR251-4-5P2K	7		
R 232, 240, 248,			441469					
R 265			441469					
R 202		RES, CF, 360, +-5%, 0.25W	352286	80031	CR251-4-5P360E	1		
R 203, 209, 214		RES, MF, 287, +-1%, 0.125W, 100PPM	443002	89536	443002	3		
R 204, 205		RES, CF, 15, +-5%, 0.125W	740027	89536	740027	2		
R 206, 212, 217		RES, CF, 11, +-5%, 0.125W	740019	89536	740019	3		
R 208, 220, 234,		RES, CC, 150, +-5%, 0.5W	186056	89536	186056	4		
R 241			186056					
R 210, 211, 215,		RES, CF, 18, +-5%, 0.125W	740035	89536	740035	4		
R 216			740035					
R 218, 239		RES, MF, 6.65K, +-1%, 0.125W, 100PPM	294918	91637	CHF551272F	2		
R 219		RES, MF, 8.45K, +-1%, 0.125W, 100PPM	221671	89536	221671	1		
R 221		RES, MF, 1.21K, +-1%, 0.125W, 100PPM	229146	91637	CHF551211F	1		
R 222		RES, MF, 5.36K, +-1%, 0.125W, 100PPM	370981	89536	370981	1		
R 223		RES, CC, 300, +-5%, 0.5W	108829	01121	EB3015	1		
R 224, 262		RES, CF, 160, +-5%, 0.125W	740092	89536	740092	2		
R 225, 229		RES, CF, 75, +-5%, 0.125W	740068	89536	740068	2		
R 226		RES, CF, 51, +-5%, 0.125W	740050	89536	740050	1		
R 227		RES, VAR, CERM, 100, +-10%, 0.5W	275735	11236	360T-101A	1		
R 228		RES, CF, 110, +-5%, 0.125W	740076	89536	740076	1		
R 230, 231		RES, CC, 100, +-5%, 0.125W	714469	89536	714469	2		
R 235		RES, CC, 47, +-5%, 0.125W	512061	01121	BB4705	1		
R 236, 237		RES, CC, 30, +-5%, 0.125W	512723	01121	BB3005	2		
R 246		RES, MF, 5.76K, +-1%, 0.125W, 100PPM	260349	91637	CHF555761F	1		
R 249		RES, MF, 63.4, +-1%, 0.5W, 100PPM	155101	89536	155101	1		
R 250		RES, CC, 160, +-5%, 0.125W	721027	89536	721027	1		
R 251, 252		RES, CC, 24, +-5%, 0.125W	681932	89536	681932	2		
R 253		RES, CC, 110, +-5%, 0.125W	500983	01121	BB1115	1		
R 254		RES, CC, 220, +-5%, 0.125W	721159	89536	721159	1		
R 255		RES, CC, 300, +-5%, 0.125W	512772	01121	BB3015	1		
R 256		RES, CF, 120, +-5%, 0.12K	740084	89536	740084	1		
R 258		RES, CF, 1.2K, +-5%, 0.25W	441378	80031	CR251-4-5P1K2	1		
R 259		RES, CC, 390, +-5%, 0.5W	109082	89536	109082	1		
R 261		RES, CC, 620, +-5%, 0.5W	108704	89536	108704	1		
R 263, 264		RES, CF, 24, +-5%, 0.125W	740043	89536	740043	2		
R 267		RES, MF, 1.4K, +-1%, 0.125W, 100PPM	344333	91637	CHF551401F	1		
R 268		RES, MF, 59.0, +-1%, 0.5W, 100PPM	150920	89536	150920	1		
R 301		RES, MF, 8.45K, +-1%, 0.125W, 100PPM	221671	89536	221671	1		
R 302		RES, MF, 3.4K, +-1%, 0.125W, 100PPM	260323	91637	CHF553401F	1		
R 303		RES, MF, 715, +-1%, 0.125W, 100PPM	313080	91637	CHF557150F	1		
R 305		RES, MF, 392, +-1%, 0.125W, 100PPM	260299	91637	CHF553920F	1		
R 306		RES, MF, 39.2K, +-1%, 0.125W, 100PPM	236414	91637	CHF553922F	1		
R 307		RES, CF, 47, +-5%, 0.25W	441592	80031	CR251-4-5P47E	1		

# LIST OF REPLACEABLE PARTS

TABLE 5-8. A2A4 OUTPUT PCA (CONT.)  
(SEE FIGURE 5-8.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
R 308		RES,CF,56K,+5%,0.25W	441626	80031	CR251-4-5P56K	1		
R 309		RES,VAR,CERM,10K,+10%,0.5W	309674	75378	360T103A	1		
R 310		RES,MF,523,+1%,0.125W,100PPM	294835	91637	CMF555230D	1		
R 311		RES,VAR,CERM,200,+10%,0.5W	275743	89536	275743	1		
R 312		RES,MF,294,+1%,0.125W,100PPM	288472	91637	CMF55294F	1		
R 313		RES,CF,33K,+5%,0.25W	348888	80031	CR251-4-5P33K	1		
R 315		RES,CF,620,+5%,0.25W	442319	80031	CR251-4-5P620E	1		
R 324		RES,CF,62K,+5%,0.25W	348904	80031	CR251-4-5P62K	1		
R 401		RES,MF,681,+1%,0.125W,100PPM	543785	91637	CMF556810F	1		
R 402		RES,CF,1M,+5%,0.25W	348987	80031	CR251-4-5P1M	1		
R 403,408		RES,MF,3.32K,+1%,0.125W,100PPM	312652	91637	CMF55321F	2		
R 404,407		RES,MF,34.8,+1%,0.125W,100PPM	343897	89536	343897	2		
R 405,409		RES,MF,4.99K,+1%,0.125W,100PPM	168252	91637	MFF1-84991	2		
R 406,410		RES,MF,71.5,+1%,0.125W,100PPM	393603	91637	CMF551715F	2		
R 411		RES,MF,4.02K,+1%,0.125W,100PPM	235325	91637	CMF554021F	1		
R 412		RES,MF,1.69K,+1%,0.125W,100PPM	321414	91637	CMF551691F	1		
R 415		RES,MF,6.34K,+1%,0.125W,100PPM	267344	91637	CMF556341F	1		
R 416		RES,MF,147K,+1%,0.125W,100PPM	291344	91637	CMF551473F	1		
R 417		RES,MF,23.2K,+1%,0.125W,100PPM	291351	91637	CMF552322F	1		
R 418		RES,MF,301K,+1%,0.125W,100PPM	289488	91637	CMF5530102F	1		
R 419		RES,VAR,CERM,100K,+10%,0.5W	369520	11236	360T-104A	1		
R 420		RES,CF,4.3K,+5%,0.25W	441576	80031	CR251-4-5P4K3	1		
R 421		RES,VAR,CERM,20K,+10%,0.5W	335760	11236	360T-203A	1		
RT 301		THERMISTOR,DISC,NEG.,10K,+10%,25C	104596	73168	JA41J1	1		
TP 1- 5		CONN,POST,PWB,.025SQ,NON-INSUL,SELECT	267500	00779	87022-1	10		
TP 6- 11		CONN,TAB,FASTON,PRESS-IN,0.110 WIDE	512889	02660	62395	6		
U 101,402		* IC,OP AMP,DUAL,JFET INPUT,8 PIN DIP	495192	12040	LF353BN	2		
U 201		MIXER,DOUBLE BALANCED,1 - 1000 MHZ	525493	89536	525493	1	1	
U 301		* IC,CMOS,DUAL 8 BIT DAC,CURRENT OUTPUT	722272	89536	722272	1	1	
U 302,311,405		* IC,OP AMP,QUAD JFET INPUT,14 PIN DIP	659748	89536	659748	3	1	
U 303		* CMOS,12 BIT MULTIPLYING DAC	722264	89536	722264	1	1	
U 304,305,308,		* IC,LSTTL,OCTAL D F/F,+EDG TRG,W/CLEAR	454892	01295	SN74LS273N	4	1	
U 404		*	454892					
U 306		* IC,LSTTL,QUAD 2 INPUT NAND GATE	393033	01295	SN74LS00N	1	1	
U 307		* IC,LSTTL,3-8 LINE DCDR W/ENABLE	407585	01295	SN74LS138N	1	1	
U 309,310		* IC,COMPARATOR,QUAD,14 PIN DIP	387233	12040	LM339N	2	1	
U 401		* IC,CMOS,QUAD BILATERAL SWITCH	408062	89536	408062	1	1	
U 403		* IC,CMOS,10BIT DAC,10BIT ACCUR,CUR OUT	507566	24355	AD7533LN	1		
W 1		CABLE ASSY, RF JUMPER	716993	89536	716993	1		
XU 301,304,305,		SOCKET,DIP,0.100 CTR,20 PIN	454421	09922	DILB20P-108	5		
XU 308,404			454421					
XU 302,306,309-		SOCKET,DIP,0.100 CTR,14 PIN	276527	09922	DILB8P-108	7		
XU 311,401,405			276527					
XU 303		SOCKET,DIP,0.100 CTR,18 PIN	418228	91506	318-AG39D	1		
XU 307,403		SOCKET,DIP,0.100 CTR,16 PIN	276535	91506	316-AG39D	3		1
XU 402		SOCKET, DIP,0.100 CTR,8 PIN	478016	91506	308-AG39D	2		2
Z 301		RES,NET,SIP,8 PIN,7 RES,10K,+2%	412924	80031	95081002CL	1		
Z 401		RES,NET,CERM,CUSTOM	501841	89536	501841	1		


1 ALSO INCLUDES XZ401.

2 ALSO INCLUDES XR144.

THE FOLLOWING COMPONENTS ARE NON FIELD REPLACEABLE:

C202-206,208,209,211,212,216-222,224,225,252,254,263,264,271,277  
CR126,202-210  
L217,220  
Q202,204,206,215  
R203-206,209-212,214-217,224-228,253-256,262-264  
U201





# LIST OF REPLACEABLE PARTS

TABLE 5-9. A2A6 ATTENUATOR ASSEMBLY

REFERENCE DESIGNATOR		S	DESCRIPTION	FLUKE	MFRS	MANUFACTURERS	TOT	R	N
A- > NUMERICS < >				STOCK	SPLY	PART NUMBER		S	O
				--NO--	CODE--	--OR GENERIC TYPE--	QTY	-Q	-E
A	4	*	ATTENUATOR PCA (RELAY)	752675	89536	752675	1		
A	5	*	RELAY DRIVER PCA	752808	89536	752808	1		
FL	1		FILTER, RF, EYELET STYLE, 2000PF, BL	529495	89536	529495	11		
H	1		SCREW, MACH, PHP, STL, 6-32X1/4	152140	89536	152140	1		
H	2		SCREW, MACH, PHP, STL, 6-32X1/2	152173	89536	152173	7		
H	3		SCREW, MACH, PHP, STL, 6-32X7/8	114868	89536	114868	11		
H	4		SCREW, MACH, PHP, STL, 6-32X1/2	152173	89536	152173	2		
MP	1		HOUSING, PLATED, ATTENUATOR, RELAYVERSN	717017	89536	717017	1	1	
U	26	*	IC, 2K X 8 EPROM	454603	01295	TMS2516JL	1		1
W	24		CABLE ASSEMBLY, ATTENUATOR	752725	89536	752725	1		

1 UNPROGRAMMED PART

TABLE 5-10. A2A6A4 ATTENUATOR PCA  
(SEE FIGURE 5-9.)

REFERENCE DESIGNATOR		FLUKE STOCK	MFRS SPLY	MANUFACTURERS PART NUMBER	TOT	R	N
A->NUMERICS----	S -----DESCRIPTION-----	--NO--	CODE--	--OR GENERIC TYPE--	QTY	S	O
						-Q	-E
H 1	WASHER, SPRNG, COPPER, 0.316 ID	544239	89536	544239	7		
J 2	CONN, COAX, SMA, REC, PWB OR BLKHD	512087	16733	705147-001	1		
J 3	CONN, SOCKET, SPRING TYPE, .06900, .143L	732826	89536	732826	1		
K 1- 7	RELAY, ARMATURE, 2 FORM C, 26.5VDC	528638	11532	712-26	7		
P 1- 8	CONN, SOCKET, PWB, 0.049 DIAMETER	544056	89536	544056	8		
R 1, 7, 10,	RES, MF, 402, +-0.5%, 0.125W, 50PPM	461632	89536	461632	5		
R 16, 19		461632					
R 2, 3, 8,	RES, MF, 56.9, +-0.5%, 0.125W, 50PPM	461590	89536	461590	10		
R 9, 11, 12,		461590					
R 17, 18, 20,		461590					
R 21		461590					
R 4	RES, MF, 94.2, +-0.5%, 0.125W, 50PPM	461616	89536	461616	1		
R 5, 6	RES, MF, 83.5, +-0.5%, 0.125W, 50PPM	461608	89536	461608	2		
R 13	RES, MF, 37.4, +-0.5%, 0.125W, 50PPM	461079	89536	461079	1		
R 14, 15	RES, MF, 150, +-0.5%, 0.125W, 50PPM	461624	89536	461624	2		

ALL COMPONENTS NON FIELD REPLACEABLE




Figure 5-9. A2A6A4 Attenuator PCA

**LIST OF REPLACEABLE PARTS**

TABLE 5-11. A2A6A5 RELAY DRIVER PCA  
 (SEE FIGURE 5-10.)

REFERENCE DESIGNATOR	A- ) NUMERICS	S	DESCRIPTION	FLUKE STOCK	MFRS SPLY --NO-- CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C	1- 7		CAP, POLYES, 0.1UF, +-20%, 50V	732883	89536	732883	7		
C	14, 15		ELECTRO, MIN, LO LEAK, 4.7MF, 35V	603993	89536	603993	2		
J	1		CONN, POST, PWB, .025SQ, NON-INSUL, SELECT	267500	00779	87022-1	14		
J	2		SOCKET, DIP, 0.100 CTR, 24 PIN	376236	91506	324-AG39D	1		
L	1- 7		CHOKE, 6TURN	320911	89536	320911	7		
L	11		INDUCTOR, 470 UH, +/-5%, 6.5 MHZ, SHLDED	147827	72259	WEE470	1		
L	12, 13		INDUCTOR, 47 UH, +/-5%, 26.5 MHZ, SHLDED	147850	72259	WEE47	2	2	
MP	1		PWB, RELAY DRIVER	752774	89536	752774	1		
P	1- 7		CONN, SOCKET, PWB, 0.049 DIAMETER	544056	89536	544056	7		
Q	1- 7	*	TRANSISTOR, SI, PNP, SMALL SIGNAL	418707	04713	MPS56562	7	2	
R	1, 4, 7,		RES, CF, 510, +-5%, 0.25W	441600	80031	CR251-4-5P510E	7		
R	10, 13, 16,			441600					
R	19			441600					
R	2, 5, 8,		RES, CF, 4.7K, +-5%, 0.25W	348821	01121	CR4725	7		
R	11, 14, 17,			348821					
R	20			348821					
R	3, 6, 9,		RES, CF, 100, +-5%, 0.25W	348771	80031	CR251-4-5P100E	7		
R	12, 15, 18,			348771					
R	21			348771					
VR	1- 7	*	ZENER, UNCOMP, 30.0V, 10%, 4.2MA, 0.4W	272633	04713	1N972A	7		




Figure 5-10. A2A6A5 Relay Driver PCA

# LIST OF REPLACEABLE PARTS


TABLE 5-12. A2A7 CONTROLLER PCA  
(SEE FIGURE 5-11.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SFLY CODE-	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1		CAP,AL,47UF,+50-20%,16V	436006	62643	SM/VB	1		
C 2, 6, 7,		CAP,POLYEST,0.22UF,+/-10%,50V	696492	89536	696492	26		
C 10- 13, 16,			696492					
C 18, 19, 21,			696492					
C 23- 25, 28-			696492					
C 31, 34, 35,			696492					
C 39- 42, 44,			696492					
C 45			696492					
C 3		CAP,TA,0.47UF,+/-20%,35V	161349	56349	196D474X0035HA1	1		
C 4, 5		CAP,TA,10UF,+/-20%,20V	330662	56289	196D106X0020KA1	2		
C 22, 51, 53-		CAP,CER,220PF,+/-10%,1000V,Z5F	368605	89536	368605	7		
C 57			368605					
C 50, 52, 58,		CAP,CER,2000PF,+/-10%,1000V,Z5U	105569	71590	DA140-139CB	4		
C 59			105569					
C 60		CAP,CER,100PF,+/-10%,1000V,S3N	105593	71590	DD-101	1		
C 61		CAP,CER,22PF,+/-2%,100V,C0G	512871	89536	512871	1		
CR 1		* DIODE,S1,BV= 75.0V,IO=150MA,500 MW	203323	07910	1N4448	1	1	
J 101,105,107		CONN,POST,PWB,.025SQ,NON-INSUL,SELECT	267500	00779	87022-1	53		
J 102		SOCKET,SIP,0.100 CTR,16 PIN	485037	30035	SS-109-1-16C	2		
J 106		CONN,PWB,HEADER,DIP,90,0.100,26 PIN	512590	89536	512590	1		
L 1, 2		CHOKE,6TURN	320911	89536	320911	2	1	
P 101		CONN,SOCKET,PWB,0.049 DIAMETER	544056	89536	544056	18		
R 1, 6- 11		RES,CF,180,+/-5%,0.25W	441436	80031	CR251-4-5P180E	7		
R 2, 13		RES,CF,4.7K,+/-5%,0.25W	348821	01121	CB4725	2		
R 3		RES,CF,20K,+/-5%,0.25W	441477	80031	CR251-4-5P20K	1		
R 4		RES,CF,390K,+/-5%,0.25W	442475	80031	CR251-4-5P390K	1		
R 5		RES,CF,100K,+/-5%,0.25W	348920	80031	CR251-4-5P100K	1		
R 12		RES,CF,100,+/-5%,0.25W	348771	80031	CR251-4-5P100E	1		
R 14, 15		RES,CF,1.3K,+/-5%,0.25W	441394	80031	CR251-4-5P1K3	2		
S 1		SWITCH,DIL,6-POS,SPST, ASSY	454124	00779	435166-4	1		
U 1		* IC,NMOS,16 BIT MICROCOMPUTER	640417	01295	THS9995N	1		
U 2		* IC,LSTTL,HEX BUFFER W/NOR ENABLE	483800	01295	SN74LS367N	1	1	
U 3, 4, 18		* IC,LSTTL,OCTL BUS TRNSCVR W/3-ST OUT	477406	01295	SN74LS245N	3	1	
U 5, 44		* IC,LSTTL,HEX INVERTER	393058	01295	SN74LS04N	2	1	
U 7		* IC,COMPARATOR,DUAL,LO-PWR,8 PIN DIP	478354	12040	LM393N	1	1	
U 8		* IC,LSTTL,TRIPLE 3 INPUT NAND GATE	393074	01295	SN74LS10N	1	1	
U 9		* IC,LSTTL,HEX D F/F,+EDG TRG,W/CLEAR	393207	01295	SN74LS174N	1	1	
U 10		* IC,STTL,QUAD 2 INPUT OR GATE	604629	01295	SN74LS32N	1	1	
U 11, 40		* IC,LSTTL,OCTL D TRANSPARENT LATCHES	504514	01295	SN74LS373N	2	1	
U 14		* IC,LSTTL,2-4 LINE DEMUX	393165	01295	SN74LS139N	1	1	
U 15, 16, 33,		* IC,LSTTL,OCTL LINE DRVR W/3-STATE OUT	429035	01295	SN74LS244N	4	1	
U 34			429035					
U 17, 27		* IC,LSTTL,OCTL D F/F,+EDG TRG,W/CLEAR	454892	01295	SN74LS273N	2	1	
U 20, 35, 36,		* IC,LSTTL,3-8 LINE DCDR W/ENABLE	407585	01295	SN74LS138N	4	1	
U 38			407585					
U 21		EPROM, PROGRAMMED 2764 (FOR 100KHZ)	748749	89536	748749	1		
U 22		EPROM, PROGRAMMED 27256 (FOR 100KHZ)	748756	89536	748756	1	1	
U 25		* IC, 2K X 8 STAT RAM	584144	33297	uPD4016C-2	1		
U 30, 31		* IC,ARRAY,7 TRANS,NPN,DARLINGTON PAIRS	454116	01295	ULN2003	2	1	
U 37		* IC,LSTTL,QUAD 2 INPUT OR GATE	393108	01295	SN74LS32N	1	1	
U 42		* IC,LSTTL,DUAL JK F/F,-EDG TRIG	414029	01295	SN74LS112N	1	1	
XU 1		SOCKET,DIP,0.100 CTR,40 PIN	429282	09922	DILB40P-108	1		
XU 2, 9, 14,		SOCKET,DIP,0.100 CTR,16 PIN	276535	91506	316-AG39D	10		
XU 20, 30, 31,			276535					
XU 35, 36, 38,			276535					
XU 42			276535					
XU 3, 4, 11,		SOCKET,DIP,0.100 CTR,20 PIN	454421	09922	DILB20P-108	11		
XU 15- 18, 27,			454421					
XU 33, 34, 40			454421					
XU 5, 8, 10,		SOCKET,DIP,0.100 CTR,14 PIN	276527	09922	DILB8P-108	5		
XU 37, 44			276527					
XU 7		SOCKET, DIP,0.100 CTR,8 PIN	478016	91506	308-AG39D	1		
XU 21, 22		SOCKET,DIP,0.100 CTR,28 PIN	448217	91506	328-AG39D	2		
XU 23- 26		SOCKET,DIP,0.100 CTR,24 PIN	376236	91506	324-AG39D	4		
Y 41		* CRYSTAL,10MHZ,+/-0.01%,HC-18/U	520239	89536	520239	1	1	
Z 1		RES,NET,SIP,10 PIN,9 RES,4.7K,+/-2%	484063	80031	95081002CL	1		
Z 2- 5		RES,NET,SIP,10 PIN,9 RES,10K,+/-2%	414003	80031	95081002CL	4		

## NOTE

U23 EPROM PART OF A2A2  
U24 EPROM PART OF A2A4  
U26 EPROM PART OF A2A6

## 5-26



# LIST OF REPLACEABLE PARTS

TABLE 5-13. A3A1 POWER SUPPLY PCA  
(SEE FIGURE 5-12.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION-----	FLUKE STOCK --NO--	MFRS SPLY CODE-	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1		CAP,AL,2200UF,+30-10%,35V	715334	89536	715334	1		
C 2, 5		CAP,AL,10000UF,+30-20%,35V	614990	89536	614990	2		
C 3, 6, 12		CAP,CER,0.1UF,+20%,50V,X7R	573808	72892	8131-050-W5R100NFM	3		
C 4, 7, 15,		CAP,TA,6.8UF,+20%,35V	363713	56289	196D685X0035KA1	4		
C 20			363713					
C 8		CAP,AL,15000UF,+30-10%,25V	732958	89536	732958	1		
C 9, 21, 22		CAP,TA,2.2UF,+20%,20V	161927	56289	196D225X0020HA1	3		
C 10		CAP,TA,22UF,+20%,15V	423012	56289	196D226X0015KA1	1		
C 11		CAP,AL,470UF,+30-20%,80V	574160	62643	NM	1		
C 13, 14		CAP,TA,4.7UF,+20%,50V	363721	56289	196D475X9015HA1	2		
C 16- 19		CAP,POLYES,0.22UF,+10%,100V	436113	73445	C280MAH1A220K	4	1	
CR 1, 2, 6	*	DIODE,SI,RECT,BRIDGE,BV=200V,IO=1.0A	296509	09423	FR200	3	1	
CR 3, 4, 8	*	DIODE,SI, 100 PIV, 1.0 AMP	343491	01295	1N4002	3		
CR 5		DIODE,SI,45PIV,7.5A,DUAL SCHOTTKY	741322	89536	741322	1	1	
CR 6	*	THYRISTOR,SI,TRIAC,VBO=200V,8.0A	413013	02735	T2800B	1		
CR 9, 10	*	ZENER,UNCOMP, 62.0V, 5%, 20MA, 5.0W	559567	89536	559567	2	1	
H 1		SCREW,MACH,PHP,SEMS,STL,4-40X1/4	185918	89536	185918	1		
H 2		NUT,MACH,HEX,STL,4-40	110635	89536	110635	1		
J 1		CONN,PWB,HEADER,SIP,0.156,12 PIN	512160	27264	09-80-1123	1		
J 2		CONN,PWB,HEADER,SIP,0.156,5 PIN	512186	27264	09-80-1053	1	1	
J 3- 6		CONN,POST,PWB,.025SQ,NON-INSUL,SELECT	267500	00779	87022-1	39		
HP 1		HEATSINK, TO-220	524934	13103	6025B-TT	1		
R 1		RES,MF,249,+1%,0.125W,100PPM	168203	91637	CMF55249F	1		
R 2		RES,MF,6.65K,+1%,0.125W,100PPM	294918	91637	CMF551272F	1		
R 3		RES,VAR,CERM,1K,+10%,0.5W	285155	71450	360S102A	1		
R 4		RES,CF,10K,+5%,0.25W	348839	80031	CR251-4-5P10K	1		
R 6- 9		RES,CF,5.1,+5%,0.25W	441287	80031	CR251-4-5P5R1	4		
R 10, 13		RES,CF,220,+5%,0.25W	342626	80031	CR251-4-5P220E	2		
R 11		RES,CF,1,+5%,0.25W	357665	80031	CR251-4-5P1E	1		
R 12		RES,CF,0.51,+5%,0.25W	381954	80031	CR251-4-5P0R5E	1		
S 1		SLIDE SWITCH,DPDT SWIDGET JR.	452862	89536	452862	1	1	
TP 1- 11		CONN,TAB,FASTON,PRESS-IN,0.110 WIDE	512889	02660	62395	11		
VR 7	*	ZENER,UNCOMP, 6.2V, 5%, 20.0MA, 0.4W	325B11	07910	1N753A	1	1	

U1,2,4,5 LISTED IN TABLE 5-4 (A3).




Figure 5-12. A3A1 Power Supply PCA



## Section 6 Options

<b>OPTION NO.</b>	<b>TITLE</b>	<b>PAGE</b>
-130	High-Stability Reference .....	130-1
-131	Sub-Harmonic Reference .....	131-1
-488	IEEE-488 Interface .....	488-1
-570	Non-Volatile .....	570-1
-651	Low-Rate Fm .....	651-1
-830	Rear Panel RF Output and Mod Input .....	830-1
-870	Attenuator/RPP (Reverse Power Protector) .....	870-1

### **6-1. INTRODUCTION**

This section includes the theory of operation, a circuit description, and maintenance instructions for each option. The IEEE-488 Interface and the Non-Volatile Memory options theory of operation is covered in Section 2.

## Option -130 High-Stability Reference

### **130-1. INTRODUCTION**

Option -130 the High-Stability Reference, with the rear panel REF INT/EXT switch set to INT, configures the Generator's reference to be supplied by the High-Stability Reference.

### **130-2. OPERATION**

The High-Stability Reference consists of the Auxiliary Power Supply (A3A2), and an Ovened Oscillator (Y1). The Auxiliary Power Supply is mounted inside the Generator on the rear panel, and the Ovened Oscillator is mounted inside the instrument on the side rail. Only the Auxiliary Power Supply is field repairable, and it is described here. The Auxiliary Power Supply is also available under the Module Exchange program.

### **130-3. CIRCUIT DESCRIPTION**

The Auxiliary Power Supply is connected directly to the line power on the fuse/filter/line-voltage selector assembly to supply power to the Ovened Oscillator even when the Generator POWER switch is off. The Auxiliary Power Supply PCB (A3A2A1) includes a linear-regulated supply and an automatic line-voltage selector circuit.

The linear-regulated supply consists of a diode rectifier bridge CR1, filter capacitor C1, voltage regulator U1, and associated resistors R2, R3, and R4. The circuit associated with CR3, Q1 and U2, provides automatic line voltage selection between two line-voltage ranges. This is implemented by configuring the rectifier circuit as a bridge rectifier for the lower line voltages or as a center-tapped, full-wave rectifier for the higher line voltages.

At low line voltages (less than approximately 150V ac), transistor Q1 is conducting, thus grounding the minus terminal of rectifier CR1 and causing diode CR3 to be reverse biased. This causes the full secondary voltage of T1 to be rectified by the bridge rectifier, CR1.

When the line voltage is greater than 180V ac, (there is approximately 30V hysteresis), the comparator U2 turns off transistor Q1. Diode CR3 becomes forward biased, and the transformer center tap is effectively grounded. The voltage applied to the rectifier CR1 is then half the secondary voltage.

The comparator U2 input voltages are set by resistors R1, R6, R9, and zener diode CR4. U2 controls the base of transistor Q1. The comparator switching point is set between the low and high line voltages, with sufficient hysteresis to accommodate variations in input loading. At very low line voltages, the resistor diode combination R10 and CR5, from the 37V output of the main power supply, augment the Auxiliary Power Supply.

The Ovened Oscillator output is disabled when the control line EXREFL is set low, i.e., when the REF INT/EXT switch is set to EXT during external reference operation. The status line HSOPTL, normally at +5V, is pulled to ground when the High-Stability Reference option is installed.

#### **130-4. ADJUSTMENTS**

##### **TEST EQUIPMENT**

Frequency Standard

Oscilloscope

Two 3-ft. 50-Ohm coaxial cables, Y9111

##### **REMARKS**

The generator may be equipped with either the High-Stability Reference option or the Sub-Harmonic Reference option, or both. The instrument reference may be the 10-MHz crystal oscillator, the High-Stability Reference, or an external signal. If the Sub-Harmonic Reference option is present, and the rear panel REF switch is set to EXT, the 10-MHz crystal oscillator is phase-locked to the applied external signal.

The voltage adjustment (A3A2A1-R4) should be made after the first half hour of the three-hour Generator warmup period has begun. For the best results in the frequency accuracy adjustment, the Generator should be operated at room temperature for at least three hours before continuing with the adjustment procedures.

##### **PROCEDURE**

The High-Stability Reference Power supply voltage is first adjusted. Then the UUT reference and the Frequency Standard waveforms are viewed on the oscilloscope while triggering on the Frequency Standard. The ovened oscillator FREQ ADJ, COARSE, and then FINE are adjusted for a stationary display.

##### **Voltage Adjustment**

1. Remove the Generator top cover.
2. Connect the DMM to the UUT. Connect the positive lead to TP1 and the negative lead to TP3.
3. Adjust R4 for  $23.4 \pm 0.1V$ .
4. Remove the DMM connections from the UUT and replace the top cover (temporarily). Wait the remaining Generator warmup time, and perform the frequency accuracy adjustment.

##### **Frequency Adjustment**

1. Remove the top Generator cover and the two FREQ ADJ access screws from the top of the ovened oscillator.
2. Connect the Frequency Standard signal to the oscilloscope vertical input channel 1, 50 Ohms termination. Connect the UUT rear panel 10 MHz IN/OUT to the oscilloscope vertical input channel 2, 50 Ohms termination.
3. Set the UUT rear panel UUT REF INT/EXT switch to INT.

4. Set the vertical controls of the oscilloscope to display the UUT 10-MHz signal and the Frequency Standard 10-MHz signal. Set for internal triggering on channel 1, and adjust timebase for  $0.1\mu\text{sec}/\text{div}$ .
5. Adjust the oscilloscope COARSE, and then adjust the FINE controls for a drift of less than one cycle in 10 seconds (for 0.01 ppm or better if desired).

#### **130-5. LIST OF REPLACEABLE PARTS**

Table 130-1 lists replaceable parts for the 6060A-130. Figure 130-1 is the component location diagrams for the 6060-130.

**OPTION -130**  
**HIGH STABILITY REFERENCE**

TABLE 130-1. A3A2A1 HIGH-STABILITY (OVENED) REFERENCE PCA  
 (SEE FIGURE 130-1.)

REFERENCE DESIGNATOR	FLUKE STOCK	MFRS SPLY	MANUFACTURERS PART NUMBER	TOT	R	N
A--NUMERICS---	--NO--	CODE--	--OR GENERIC TYPE--	QTY	S	O
					-Q	-E
C 1	478792	89536	478792	1		
C 2, 6	363721	56289	196D475X9015HA1	2		
C 3, 4	417683	56289	196D106X0035KA1	2		
C 5	649731	89536	649731	1		
C 7	696484	89536	696484	1		
C 8	393439	80031	719A1	1		
CR 1	296509	09423	FB200	1	1	
CR 2, 3, 5	343491	01295	1N4002	3	1	
CR 6	203323	07910	1N4448	1	1	
J 2, 3	267500	00779	87022-1	10		
R 1	268821	91637	CMF554992F	1		
R 2	168203	91637	CMF55249F	1		
R 3	235325	91637	CMF554021F	1		
R 4	325613	89536	325613	1	1	
R 5	218743	89536	218743	1		
R 6, 9	267344	91637	CMF556341F	2		
R 7	348821	01121	CB4725	1		
R 8	348839	80031	CR251-4-5P10K	1		
R 10	109934	01121	HB1011	1		
TP 1- 4	512889	02660	62395	4		
U 2	478354	12040	LM393N	1		
VR 4	325803	89536	325803	1	1	




Figure 130-1. A3A2A1 High Stability (Ovened) Reference PCA

## Option -131

# Sub-Harmonic Reference

### 131-1. INTRODUCTION

The Sub-Harmonic Reference (Option -131), allows an external signal of any sub-harmonic of 10 MHz above 1 MHz (generally 1, 2, 2.5, 5 or 10 MHz) to be used as the Signal Generator frequency reference. The signal can be any sine or square wave between 0.3 to 4.0V p-p into 50-ohms termination.

To operate the Generator on an external reference, connect the external reference signal to the rear panel REF IN connector, and set REF INT/EXT switch to EXT. The instrument reference signal (10-MHz TTL) is available at the 10 MHz OUT connector.

### CAUTION

**When operating the Generator on the internal reference (REF INT/EXT switch set to INT), remove any signal applied to the REF IN connector to prevent reference frequency instability due to interaction (pulling) of the two signals.**

**With the REF IN/EXT switch set to EXT, and with no external reference signal applied to the REF IN connector, the Generator output frequency has a significant error from the programmed frequency because the internal oscillator is unlocked. There is no annunciation of this abnormal operating condition.**

### 131-2. OPERATION

The Sub-Harmonic Reference option operates in conjunction with the 10-MHz crystal oscillator on the Synthesizer PCA (A2A1) to form a sampling phase-locked loop. It basically consists of an ac-to-TTL converter, a sub-harmonic phase detector, an analog control switch, and an out-of-lock detector. When this option is installed, the Synthesizer PCA is modified by adding a frequency control input to the 10-MHz crystal oscillator. Also, a BNC connector labeled REF IN is added to the rear panel of the Generator with a cable assembly connected to the Synthesizer PCA.

The existing 10 MHz IN/OUT connector is relabeled 10 MHz OUT. The option switch on the Controller PCA is set to signal the Controller that the Sub-Harmonic Reference option is installed. The Sub-Harmonic Reference option assembly sits on top of the Synthesizer PCA in the Synthesizer compartment (top side) of the module plate (A2).

### 131-3. CIRCUIT DESCRIPTION

Comparator U1 forms an ac-to-TTL converter. Diodes CR1 and CR2 precondition the REF IN signal to protect the comparator. Resistors R2, R3, R5, and R7 provide hysteresis, preventing oscillation when there is no input.

MOS switch U3 connects the control voltage of the 10-MHz crystal oscillator to a fixed bias network R22 and R23 when the REF IN/OUT switch is set to INT, or to the loop amplifier when the switch is set to EXT, thus closing a phase-locked loop.

The phase detector and loop amplifier are made up of U4, Q1, Q2, Q3, and U5. The signal from the external reference input through the ac-to-TTL converter is applied to the flip-flop clock input, U4-3. The 10-MHz signal at J1-5 from the crystal oscillator goes to the other flip-flop clock input, U4-11. The flip-flops are connected, so the width of the pulse that switches Q2 is the difference in time of these two signals (U4-3, and U4-11). The phase-detector operating point is set by R12 and R13.

The U5 op-amp operates as an integrating loop amplifier providing a loop gain bandwidth of about 300 Hz. A current source Q3, R16, and storage-multiplier network, C5 and R15, maintain constant phase detector gain and constant loop bandwidth for all sub-harmonic input references.

The output of the loop amplifier is applied as the control signal SHTUNE to the frequency control input of the 10-MHz crystal oscillator on the Synthesizer PCA A2A1 through the control switch U3 and connector J1-7. The control switch U3 is controlled by the Generator Controller through the control line SHENL at J1-3. This line is enabled when the rear panel REF IN/EXT switch is set to EXT.

An out-of-lock detector is formed with flip-flop U2 and one-shot U7. The out-of-lock detector provides a status output to the Controller that indicates the 10-MHz oscillator is not locked to the external reference signal. An out-of-lock condition causes the flip-flop output to toggle and triggers the one-shot to act as a pulse stretcher.

The output of the one-shot is an active-low signal and is combined through diode CR3 with other signals on the Synthesizer assembly to form the UNLOCK status signal.

#### **131-4. ADJUSTMENT**

If the Generator has the Sub-Harmonic Reference option but not the High-Stability Reference option, use the Reference Frequency Adjustment procedure in Section 4C under Synthesizer Assembly Adjustments.

If the generator has both the Sub-Harmonic and the High-Stability Reference options, use the following adjustment procedure.

#### **TEST EQUIPMENT**

Frequency Standard  
Low Frequency Synthesized Signal Generator (LFSSG)  
Oscilloscope  
BNC Tee

#### **REMARKS**

The UUT reference output and the LFSSG signal are viewed simultaneously on the oscilloscope for frequencies near the limit of the lock-in range. The 10-MHz crystal oscillator is adjusted for a stable display on the oscilloscope at both upper and lower limits. The external reference input level to the Generator is reduced to determine sensitivity.



## PROCEDURE

1. Remove the top Generator cover and the 10-MHz adjustment access screw from the the module plate. (See Figure 4C-3 C153 for 10-MHz adjustment location.)
2. Connect the frequency standard to the reference input of the LFSSG.
3. Connect the LFSSG output to the oscilloscope vertical input channel 1 using a BNC tee, and then connect the cable to the UUT 10 MHz IN using a cable less than three feet in length.
4. Connect the UUT rear panel 10 MHz OUT to oscilloscope vertical input channel 2.
5. Program the LFSSG to 10 MHz and 0 dBm.
6. Set the UUT rear panel REF INT/EXT switch to EXT.
7. Set the vertical controls of the oscilloscope to display both the LFSSG output and the UUT 10-MHz signal. Set the triggering to channel 1, and adjust the timebase for 0.1  $\mu$ s/div.
8. Edit the LFSSG to 80 Hz above 10 MHz (10.00008 MHz).
9. If the signals are unlocked, adjust C153 for a locked condition. Verify the UNCAL indicator is not lit.
10. Adjust C153 clockwise until the two waveforms are not synchronized (break lock). Verify the UNCAL indicator is flashing. Turn C153 counterclockwise to the first stable, locked point. Note the adjustment position of C153.
11. Edit the LFSSG to 80 Hz below 10 MHz (9.99992 MHz).
12. Adjust C153 counterclockwise to an unlock condition. Turn C153 clockwise to the first stable, locked point. Finally, turn C153 midway between this point and the locked point noted in step 10.
13. Program the LFSSG to 10 MHz.
14. Reduce the level of LFSSG until the signals displayed on the oscilloscope indicate an unlock condition.
15. Increase the LFSSG level until the oscilloscope display first indicates the locked-point. Verify that this level is greater than 300 mV peak-to-peak as measured with the oscilloscope.


### **131-5. LIST OF REPLACEABLE PARTS**

Table 131-1 lists replaceable parts for the 6060A-131. Figure 131-1 is the component location diagrams for the 6060A-131.

**OPTION -131**  
**SUB-HARMONIC REFERENCE**

TABLE 131-1. A2A3 SUB-HARMONIC REFERENCE PCA  
(SEE FIGURE 131-1.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION-----	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1, 11, 12,		CAP,POLYES,0.1UF,+10%,50V	696484	89536	696484	4		
C 14			696484					
C 2- 5, 7,		CAP,TA,10UF,+20%,20V	330662	56289	196D106X0020KA1	7		
C 9, 10			330662					
C 6		CAP,CER,4700PF,+20%,100V,X7R	362871	72982	8121-A100-W5R-472M	1		
C 8		CAP,POLYES,0.022UF,+10%,50V	715268	89536	715268	1		
C 15		CAP,CER,56PF,+2%,100V,C0G	512970	51406	RPE121	1		
C 16		CAP,TA,22UF,+20%,15V	423012	56289	196D226X0015KA1	1		
CR 1, 2		* DIODE,SI,BV= 75.0V,IO=150MA,500 MW	203323	07910	1N4448	2	1	
CR 3		* DIODE,SI,SCHOTTKY BARRIER,SMALL SIGNAL	313247	28484	HP5082-6264	1	1	
J 1		CONN,POST,PWB,.025SQ,NON-INSUL,GOLD30	277418	89536	277418	7		
J 2		CONN,COAX,SMB,REC,PWB	512095	16733	702033	1		
Q 1- 3		* TRANSISTOR,SI,NPN,SMALL SIGNAL	218081	04714	MPS6520	3	1	
R 1		RES,CF,68,+5%,0.25W	414532	80031	CR251-4-5P68E	1		
R 2, 15		RES,CC,270,+5%,0.125W	512764	01121	BB2715	2		
R 3, 7, 18,		RES,CC,10K,+5%,0.125W	643940	01121	BB1035	5		
R 19, 22			643940					
R 4		RES,CF,1.2K,+5%,0.25W	441378	80031	CR251-4-5P1K2	1	1	
R 5		RES,CC,330,+5%,0.125W	643945	01121	BB3315	1		
R 6, 11		RES,CC,1K,+5%,0.125W	643932	01121	BB1025	2		
R 8		RES,CF,470,+5%,0.25W	343434	80031	CR251-4-5P470E	1		
R 12		RES,MF,15K,+1%,0.125W,100PPH	285296	91637	CMF551502F	1		
R 13		RES,MF,6.04K,+1%,0.125W,100PPH	285189	91637	CMF556041F	1		
R 14, 17		RES,CC,47,+5%,0.125W	512061	01121	BB4705	2		
R 16		RES,CF,10K,+5%,0.25W	348839	80031	CR251-4-5P10K	1		
R 20		RES,MF,100K,+1%,0.125W,100PPH	248807	91637	CMF551003F	1		
R 21		RES,CF,56,+5%,0.25W	342618	80031	CR251-4-5P56E	1		
R 23		RES,CF,5.6K,+5%,0.25W	442350	80031	CR251-4-5P5K6	1		
R 25		RES,CF,390,+5%,0.25W	441543	80031	CR251-4-5P390E	1		
R 26		RES,CF,33K,+5%,0.25W	348888	80031	CR251-4-5P33K	1		
TP 1- 4		TURRET,MINI HOLLOW LUG #2010B-1	179283	88245	2010B-5	4		
U 1		* IC,COMPARATOR,HI-SPEED,14 PIN DIP	386920	18324	NE529A	1	1	
U 2, 4		* IC,STTL,DUAL D F/F,+EDG TRG,W/SET&CLR	418269	01295	SN74S74N	2	1	
U 3		* IC,CMOS, SPDT ANALOG SWITCH	723742	89536	723742	1	1	
U 5		* IC,OP AMP,JFET INPUT,8 PIN DIP	472779	12040	LF386N	1	1	
U 7		* IC,TTL,RTGRBLE MONOSTABLE MULTIVBRTR	293134	04713	MC8601P	1		



6060A-1623

Figure 131-1. A2A3 Sub-Harmonic Reference PCA



## Option -488

# IEEE-488 Interface

### **488-1. INTRODUCTION**

The IEEE-488 Interface (Option -488), consists of the IEEE-488 printed circuit assembly (A3A3A1) mounted in a metal frame on the Generator rear panel. It is interfaced directly with the Controller assembly A2A7.

### **488-2. OPERATION**

The operation of this option is covered in Section 2 of this manual.

### **488-3. CIRCUIT DESCRIPTION**

The IEEE-488 Interface uses an 8291A Talker/Listener IC (U1) to handle all IEEE-488 standard communications protocol. All data, address, and control lines to the 8291A are buffered on the Controller. Two MC3447 bus drivers (U3 and U4) interface the 8291A directly to the IEEE-488 bus.

The presence of the optional IEEE-488 Interface is detected by the microprocessor when the option is plugged into the Controller board. The signal IEINL, normally at +5V, is pulled to circuit ground when the option is installed.

### **488-4. Address Switches**

Tri-state buffer U6 provides the status of the IEEE-488 rear panel address switches when the Generator is interrogated. These switches determine the IEEE-488 bus address and talk-only (to) or listen-only (lo) modes. When opened, the switch just to the left of the IEEE-488 bus connector disconnects the bus shield ground from the system ground.

### **488-5. MAINTENANCE**

This option does not change the performance test or calibration adjustments of the Generator. Troubleshooting information for this option is in Section 4D under Digital and Control troubleshooting.

### **488-6. LIST OF REPLACEABLE PARTS**

Table 488-1 lists replaceable parts for the 6060A-488. Figure 488-1 is the component location diagrams for the 6060A-488.

TABLE 488-1. A3A3A1 IEEE-488 INTERFACE PCA  
(SEE FIGURE 488-1.)

REFERENCE DESIGNATOR			FLUKE STOCK	MFRS SPLY	MANUFACTURERS PART NUMBER	TOT	R	N
A-->NUMERICUS-->	S	-----DESCRIPTION-----	--NO--	CODE--	--OK GENERIC TYPE--	QTY	--Q	--E
C	1-- 4, 6,	CAP,POLYES,0.22UF,+/-10%,50V	696492	89536	696492	9		
C	7, 9- 11		696492					
J	1	CONN,PWB,RIBBON,90,24 POS,STD ORIENT	658039	89536	658039	1		
L	1- 3	CHOKE,6TURN	320911	89536	320911	3		
P	1	CONN,PWB,SKT,HOUSING,DIP,26	543512	00779	86063-9	1		
R	1	RES,CF,1K,+/-5%,0.25W	343426	80031	CR251-4-5P1K	1		
S	1	PIANO MULTI-POLE, ST, SIDE ACTUATED	658567	89536	658567	1		
U	1	* IC,NMOS,GPIB TALKER/LISTENER	586909	34649	P8291A	1	1	
U	3, 4	* IC,LSTTL,OCTL IEEE-488 BUS TRNSCVR	524835	04713	MC3447P	2		
U	6	* IC,LSTTL,OCTL D TRANSPARENT LATCHES	504514	01295	SN74LS373N	1	1	
U	7	* IC,LSTTL,OCTL BUS TRNSCVR W/3-ST OUT	477406	01295	SN74LS245N	1	1	
U	8	* IC,TTL,QUAD 2 INPUT AND GATE	393066	01295	SN74LS08N	1		
XU	1	SOCKET,DIP,0.100 CTR,40 PIN	429282	09922	DILB40P-108	1		
XU	3, 4	SOCKET,DIP,0.100 CTR,16 PIN	276535	91506	316-AG39D	2		
XU	3, 4	SOCKET, DIP,0.100 CTR,8 PIN	478016	91506	308-AG39D	2		
XU	6, 7	SOCKET,DIP,0.100 CTR,20 PIN	454421	09922	DILB20P-108	2		
XU	8	SOCKET,DIP,0.100 CTR,14 PIN	276527	09922	DILB8P-108	1		
Z	1- 4	RES,NET,SIP,10 PIN,9 RES,10K,+/-2%	414003	80031	95081002CL	4	1	




Figure 488-1. A3A3A1 IEEE-488 Interface PCA

## Option -570

# Non-Volatile Memory

### **570-1. INTRODUCTION**

The A2A8 Non-Volatile Memory (Option -570) stores 50 front panel states. These states are retained when the main power is disconnected from the Generator. A 2K-byte CMOS RAM (U1) stores the front panel states, and a lithium battery (B1) provides the Non-Volatile Memory with backup power when the generator is disconnected from the main power. The battery provides power for memory retention for more than two years with no main power applied.

### **570-2. OPERATION**

Operation of the Non-Volatile Memory option is covered in Section 2 of this manual.

### **570-3. CIRCUIT DESCRIPTION**

The circuit is functionally divided into a power circuit and a memory control.

#### **570-4. Power Circuit**

There are two sources of power for the Non-Volatile Memory RAM IC. These are the battery and the regulated +5V Signal Generator supply. Diodes CR1 and CR2 form a basic diode switching circuit that allows the power source with the higher voltage to provide current to the CMOS RAM and isolate the other power source.

Q1 and Q4 are turned on by Q2 and Q3 when the +5V supply is above the threshold voltage set by VR1, R2, and R3. Q1 has a low collector saturation voltage. When it is turned on, the supply voltage to the CMOS RAM is very close to +5V. The output of Q4 is the power valid signal. The CMOS RAM cannot be accessed until the output of Q4 goes high.

#### **570-5. Memory Control**

All address, data, and control lines to the CMOS RAM are buffered. The enable signals WEL, DBINL, and the CMOS RAM are buffered with open-collector gates. These signals are held at the same potential as the CMOS RAM supply when the +5V supply goes down, ensuring the CMOS RAM draws the minimum standby current.

The presence of the Non-Volatile Memory is detected by the microprocessor when the option is plugged into the Controller board. The signal NVMENL, normally at +5V, is pulled to ground when the option is installed.

### **570-6. MAINTENANCE**

This option does not change the performance test or calibration of the Generator. Troubleshooting information for this option is presented in Section 4D under the Digital and Control Troubleshooting.

**570-7. LIST OF REPLACEABLE PARTS**

Table 570-1 lists replaceable parts for the 6060A-570. Figure 570-1 is the component location diagrams for the 6060A-570.



TABLE 570-1. A2A8 NON-VOLATILE (STORE/RECALL) MEMORY PCA  
(SEE FIGURE 570-1.)

REFERENCE DESIGNATOR	FLUKE STOCK	MFRS SPLY CODE	MANUFACTURERS PART NUMBER	TOT QTY	R S -Q	N O T -E
A>NUMERICS--> S	DESCRIPTION	NO--	--OR GENERIC TYPE--			
C 1	CAP, TA, 10UF, +-20%, 20V	330662	56289 196D106X0020KA1	1		
C 2- 6	CAP, POLYES, 0.22UF, +-10%, 50V	696492	89536 696492	5	1	
CR 1, 2	* DIODE, SI, BV= 75.0V, IO=150MA, 500 MW	203323	07910 1N4448	2		
CR 3	* ZENER, UNCOMP, 3.3V, 10%, 20.0MA, 0.4W	309799	04713 1N746	1	1	
P 1	CONN, POST, PWB, .025SQ, NON-INSUL, SELECT	267500	00779 87022-1	32		
Q 1	* TRANSISTOR, SI, PNP, SMALL SIG, SELECTED	380394	89536 380394	1	1	
Q 2, 3	* TRANSISTOR, SI, NPN, SMALL SIGNAL	218396	04713 2N3904	2	1	
Q 4	* TRANSISTOR, SI, N-DMOS FET, TO-72	477729	18324 SD213EE	1	1	
R 1	RES, MF, 432, +-1%, 0.125W, 100PPM	326397	91637 CMF554320F	1		
R 2	RES, MF, 33.2, +-1%, 0.125W, 100PPM	296681	91637 CMF553320F	1	1	
R 3	RES, MF, 100, +-1%, 0.125W, 100PPM	168195	91637 CMF551000F	1		
R 4	RES, MF, 562, +-1%, 0.125W, 100PPM	340828	91637 CMF555620F	1		
R 5	RES, CF, 100K, +-5%, 0.25W	348920	80031 CR251-4-5P100K	1		
R 6	RES, CF, 10K, +-5%, 0.25W	348839	80031 CR251-4-5P10K	1		
TP 1, 2	CONN, TAB, FASTON, PRESS-IN, 0.110 WIDE	512889	02660 62395	2		
U 1	* IC, 2K X 8 STAT RAM	647222	51157 HM6116P-3	1		
U 2	* IC, LSTTL, OCTL BUS TRNSVR W/3-ST OUT	477406	01295 SN74LS245N	1	1	
U 3	* IC, LSTTL, OCTL LINE DRVR W/3-STATE OUT	429035	01295 SN74LS244N	1	1	
U 4	* IC, LSTTL, QUAD BUS BFR W/3-STATE OUT	472746	01295 SN74LS125N	1	1	
U 5	* IC, TTL, TRIPLE 3 INPUT NAND GATE	363465	01295 SN7412N	1	1	
U 6	* IC, LSTTL, HEX INVERTER	393058	01295 SN74LS04N	1	1	
XU 1	SOCKET, DIP, 0.100 CTR, 24 PIN	376236	91506 324-AG39D	1		
XU 2, 3	SOCKET, DIP, 0.100 CTR, 20 PIN	454421	09922 D1L820P-108	2		
XU 4- 6	SOCKET, DIP, 0.100 CTR, 14 PIN	276527	09922 D1L88P-108	3		
Z 1	RES, NET, SIP, 6 PIN, 5 RES, 10K, +-2%	500876	80031 95081002CL	1		




Figure 570-1. A2A8 Non-Volatile (Store/Recall) Memory PCA



## Option -651

# Low-Rate Fm

### 651-1. INTRODUCTION

The Low-Rate FM (Option -651), extends the FM 3-dB bandwidth to a lower frequency (approximately 0.5 Hz instead of 20 Hz). This option makes the Generator useful for testing FM radios that use sub-audio tones or low-rate digital techniques.

The option consists of a small printed circuit assembly A2A9 mounted atop the Synthesizer PCB. When installed, certain components are removed from the Synthesizer PCB, the option switch is set on the Controller, and a coupling capacitor is shorted on the Output PCB. A DIP switch on the Low-Rate FM PCB allows the Generator to be configured for Low-Rate FM or standard (normal) operation (except that the coupling capacitor on the Output PCB is shorted in both states). The DIP switch settings are listed in Table 651-1.

### 651-2. OPERATION

Operation of the Generator with the Low-Rate FM option is the same as operation of a standard instrument except that the maximum FM deviation is limited to 9.99 kHz.

### 651-3. CIRCUIT DESCRIPTION

The Low-Rate FM option allows frequency modulation at very low rates for use in digital modulation testing. In the low-rate mode, ac coupling capacitor A2A1 C16 is shorted to prevent any dc current from entering the loop amplifier (A2A1 U27) and changing the phase-detector operating point. The voltage at the output of the audio integrator (A2A1 U41-1) is kept at zero volts.

Keeping the voltage at the output of A2A1 U41 at zero volts is accomplished with a voltage-zeroing loop consisting of A2A9 U1. The positive terminal of this op-amp monitors the output voltage of the audio integrator through A2A9 R8. The negative terminal is connected to ground at A2A9 R9. By feeding current through A2A9 R7 back to the negative input of the audio integrator (A2A1 U41), its output voltage is kept at 0V. This is a lead-lag circuit with a low frequency break of approximately 0.3 Hz.

Potentiometer A2A9 R4 adjusts the compliance of the voltage-zeroing loop. Part of the active high-pass filter (A2A9 U41) is disabled by connecting the previous stage directly to A2A1 C114. Since the maximum deviation is limited to 9.99 kHz, the gain of the audio integrator and the VCO summing network (A2A1 R88, C117, C146) is decreased by a factor of ten. The Generator can be reconfigured back to the normal mode by programming the DIP switches on the option board (See Table 651-1).

### 651-4. PERFORMANCE TEST

The Generator is externally frequency modulated with a low-frequency square wave signal. The droop of the demodulated signal is measured using a spectrum analyzer as an FM demodulator (slope detection is used).

## REQUIREMENT

FM Droop is less than 15% with 10 Hz external square wave modulation.

## REMARKS

When using the RF Spectrum Analyzer as an FM demodulator using slope detection, it is important to operate the RF Spectrum Analyzer detector in a linear range. This can be checked by stepping the UUT frequency up 5 kHz and then down 5 kHz from the operating point and noting that the display moves equal amounts. If it doesn't, tune the RF Spectrum Analyzer slightly and check for linearity again.

## TEST EQUIPMENT

Low-Frequency Synthesized Signal Generator (LFSSG)  
RF Spectrum Analyzer

## PROCEDURE

1. Remove the Generator top and the Synthesizer module plate covers.
2. Connect the LFSSG TTL output through a 604-ohm resistor and a 320 uF, 6V capacitor to the UUT MOD INPUT. This provides a square wave approximately 2V p-p at the Generator's MOD input.
3. Program the LFSSG to 10 Hz and any level around 1V.
4. Program the UUT to the [RCL][9][8] and 3-kHz deviation. This provides a 300-MHz signal at -10 dBm.
5. Connect the input of the RF Spectrum Analyzer to the UUT RF OUTPUT. Set the RF Spectrum Analyzer so that the signal response is at the top of the display using linear detection.
6. Program UUT for EXT FM.
7. Using a 10-kHz Resolution Bandwidth and zero Span/Div, adjust either the Generator frequency or the RF Spectrum Analyzer tuning for slope detection to obtain a square-wave display. Adjust Time/Div and Trigger as necessary to obtain a stable square-wave display.
8. Verify that the droop of the demodulated FM is less than 15%. For example, if the displayed square-wave amplitude (vertical edge) is 3.4 divisions, then the droop should be less than 0.51 divisions ( $0.15 \times 3.4$ ).

## 651-5. ADJUSTMENT

### TEST EQUIPMENT

DMM

### PROCEDURE

The Offset adjustment (A2A9 R4) is set to 0V.

1. Program UUT to [RCL][9][8] and 9.99 kHz deviation, and set the rear panel EXT/INT FM switch to EXT, with no external modulation signal applied.

2. With the DMM, measure the dc voltage at A2A9 U1-6. Adjust R4 for  $0V \pm 0.1V$ .

#### **651-6. LIST OF REPLACEABLE PARTS**

Table 651-2 lists replaceable parts for the 6060A-651. Figure 651-1 is the component location diagrams for the 6060A-651.

**Table 651-1. Low-Rate FM DIP Switch**

NORMAL	LOW-RATE FM
1. Closed	Open
2. Open	Closed
3. Closed	Open
4. Closed	Open
5. Not Applicable	Not Applicable
6. Open	Closed

OPTION -651  
LOW-RATE Fm

TABLE 651-2. A2A9 LOW-RATE FM PCA  
(SEE FIGURE 651-1.)

REFERENCE DESIGNATOR	FLUKE STOCK	MFRS SPLY	MANUFACTURERS PART NUMBER	TOT QTY	R S	N O T
A->NUMERICS----	--NO--	CODE--	--OR GENERIC TYPE--		-Q-	-E-
C 1, 2	732883	89536	732883	2		
C 3	714725	89536	714725	1		
C 4	436071	01884	196D335X0020KA1	1		
C 6	512848	51406	RPE121	1		
C 7	512343	89536	512343	1		
R 1	168286	91637	MFF1-83012F	1		
R 2	281816	91637	CMF5524R2F	1		
R 3	312652	91637	CMF553321F	1		
R 4	369520	11236	360T-104A	1		
R 5, 7	394064	01121	CB	2		
R 6	441485	80031	CR251-4-5P200K	1		
R 8, 9	348995	80031	CR251-4-5P1M2	2		
R 11	168252	91637	MFF1-84991	1		
R 13	268821	91637	CMF554992F	1		
S 1	454124	00779	435166-4	1		
U 1	472779	12040	LF386N	1		
XU 1	478016	91506	308-AC39D	1	1	
* IC, OP AMP, JFET INPUT, 8 PIN DIP						
SOCKET, DIP, 0.100 CTR, 8 PIN						




Figure 651-1. A2A9 Low-Rate FM PCA

## Option -830

# Rear Panel RF Output and Mod Input

### **830-1. INTRODUCTION**

The Rear Panel RF Output and MOD Input (Option -830), moves the RF OUTPUT and MOD INPUT connectors from the front panel to the rear panel of the Generator. An insulating spacer is used when the RF OUTPUT connector is mounted on the rear panel to reduce ground loops. A longer semi-rigid coaxial SMA cable assembly (W17) replaces the standard cable (W1). The option switch on the Controller is set to indicate that the option is installed.

### **830-2. OPERATION**

The additional signal loss of this longer cable is compensated using instrument-independent correction data stored in the Output Calibration EPROM. The Controller applies this correction data only when the rear panel RF Output and MOD Input option jumper is installed on the Controller PCB.

### **830-3. CIRCUIT DESCRIPTION**

This option does not change the operation or specifications of the Generator.

### **830-4. MAINTENANCE**

This option does not change the performance tests, calibration, adjustment, or service of the Generator.





## Option -870

# Attenuator/RPP (Reverse Power Protector)

### 870-1. INTRODUCTION

The Attenuator/RPP (Option -870) protects the Generator from damaging dc and/or RF signal levels applied to the Generator RF OUTPUT connector. Protection for the RF Output is provided only when the Generator is on.

### 870-2. OPERATION

Option -870 Attenuator/RPP (A2A5) replaces the standard Attenuator (A2A6) assembly, and includes two printed circuit assemblies, the Attenuator/RPP (A2A5A4) and the Relay Driver RPP Control (A2A5A5). The frequency response correction data is unique to the complete Attenuator/RPP assembly (A2A5) and is stored in the Attenuator calibration EPROM. Although the assembly is field-repairable, if certain parts are replaced, the EPROM must be reprogrammed.

If any of these parts need replacement, it is recommended the Attenuator/RPP assembly (complete with the housing and calibration EPROM) be replaced by means of the Module Exchange Program.

### 870-3. CIRCUIT DESCRIPTION

Coupling capacitors C6 and C7 protect against dc or low-frequency power. The diode limiter, consisting of CR2 through CR9, provides protection against medium RF power levels and short-term protection (fast acting) against high RF power levels. Long-term (latched) protection is provided by relay K8 whenever the reverse RF power exceeds a preset level.

RF power detected by CR1 is compared with the preset voltage in one section of comparator U1. When the detected voltage exceeds the set value, the output of U1 pin 1 goes positive, turning on Q1 and Q2. This actuates K8 to the protect position. In the protect position, the output connector is shorted to ground and the Generator output is disconnected from the output connector.

CR15 and R6 form a latching network such that K8 remains in the protect position until the Generator RF Output is reset by an RF ON entry. The output of the comparator is buffered and sent as RPTRPL to interrupt the Controller signal that annunciates the RPP trip condition by flashing the UNCAL and RF OFF lights.

### 870-4. MAINTENANCE

This option does not change the performance test of the Generator and there are no adjustments.

When servicing the A2A5A2 Attenuator/RPP Control PCB, use the three dual-pin test points to aid in the troubleshooting of the assembly. The RPP can be tripped (to the protect position) by momentarily shorting the two points of TP1. It can be reset by

**OPTION -870**  
**ATTENUATOR/RPP (REVERSE POWER PROTECTOR)**

momentarily shorting TP2. Shorting TP3 reduces the level required to trip the Attenuator/RPP, so it trips on the Generator's own output. This provides a convenient way to verify the operation of the entire trip circuitry, although at a reduced trip level.

To check the trip function with TP3 shorted, it is best to program the Generator to an output level of +10 dBm; then, program it for fixed amplitude range ([SPCL][9][1]). This allows the level to be varied from a low value up to the maximum value without any transients that might otherwise trip the RPP. Then, starting at a low level, such as -10 dBm (with the RPP reset), increase (EDIT) the UUT level in 1 dB steps until the RPP trips. RPP trip normally occurs between +10 and +15 dBm.

**870-5. LIST OF REPLACEABLE PARTS**

Table 870-1 lists replaceable parts for the 6060A-870. Figure 870-1 is the component location diagram for the 6060A-870.

**OPTION -870**  
**ATTENUATOR/RPP (REVERSE POWER PROTECTOR)**

TABLE 870-1. A2A5 ATTENUATOR/RPP ASSEMBLY

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE-	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
A 4		ATTENUATOR/RPP PCA	752667	89536	752667	1		
A 5		RELAY DRIVER/RPP PCA	752816	89536	752816	1		
FL 1		FILTER, RF, EYELET STYLE, 2000PF, BL	529495	89536	529495	11		
H 1		SCREW, MACH, PHP, STL, 6-32X1/4	152140	89536	152140	1		
H 2		SCREW, MACH, PHP, STL, 6-32X1/2	152173	89536	152173	7		
H 3		SCREW, MACH, PHP, STL, 6-32X7/8	114868	89536	114868	11		
H 4		SCREW, MACH, PHP, STL, 6-32X1/2	152173	89536	152173	2		
MP 1		HOUSING, PLATED, ATTENUATOR, RELAYVERSN	717017	89536	717017	1	1	
U 26	*	IC, 2K X 8 EPROM	454603	01295	TMS2516JL	1		
W 24		CABLE ASSEMBLY, ATTENUATOR	752725	89536	752725	1		


FOR MODULE EXCHANGE, ORDER P/N 750414 (INCLUDES CALIBRATED EPROM)

TABLE 870-2. A2A5A4 ATTENUATOR/RPP PCA  
(SEE FIGURE 870-1.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE-	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1, 2, 4		CAP, CER, 1000PF, +-20%, 50V, X7R	514059	89536	514059	3		
C 3, 5		CAP, AL, 4.7UF, +-10%, 15V	519363	56289	193D475X9015C2	2		
C 6, 7		CAP, POLYEST, 0.1UF, +-20%, 50V	732883	89536	732883	2		
CR 1	*	DIODE, SI, SCHOTTKY BARRIER, SMALL SIGNAL	535195	28480	5082-2800	1	2	
CR 2- 9	*	DIODE, SI, BV= 70.0V, 500 MW	454181	03508	1N4606	8		
H 1		WASHER, SPRNG, COPPER, 0.316 ID	544239	89536	544239	8		
J 2		CONN, COAX, SMA, REC, PWB OR BLKHD	512087	16733	705147-001	1		
J 3		CONN, SOCKET, SPRING TYPE, .0690D, .143L	732826	89536	732826	1		
K 1- 8		RELAY, ARMATURE, 2 FORM C, 26.5VDC	528638	11532	712-26	8		
P 1- 8		CONN, SOCKET, PWB, 0.049 DIAMETER	544056	89536	544056	8		
P 9- 11		CONN, SOCKET, PWB, 0.038 DIAMETER	386144	89536	386144	3		
R 1, 7, 10,		RES, MF, 402, +-0.5%, 0.125W, 50PPM	461632	89536	461632	5		
R 16, 19			461632					
R 2, 3, 8,		RES, MF, 56.9, +-0.5%, 0.125W, 50PPM	461590	89536	461590	10		
R 9, 11, 12,			461590					
R 17, 18, 20,			461590					
R 21			461590					
R 4		RES, MF, 94.2, +-0.5%, 0.125W, 50PPM	461616	89536	461616	1		
R 5, 6		RES, MF, 83.5, +-0.5%, 0.125W, 50PPM	461608	89536	461608	2		
R 13		RES, MF, 37.4, +-0.5%, 0.125W, 50PPM	461079	89536	461079	1	1	
R 14, 15		RES, MF, 150, +-0.5%, 0.125W, 50PPM	461624	89536	461624	2		
R 22		RES, CC, 10K, +-5%, 0.125W	643940	01121	BB1035	1		

ALL COMPONENTS NON FIELD REPLACEABLE

**OPTION -870**  
**ATTENUATOR/RPP (REVERSE POWER PROTECTOR)**



**Figure 870-1. A2A5A4 Attenuator/RPP PCA**


**OPTION -870**  
**ATTENUATOR/RPP (REVERSE POWER PROTECTOR)**

TABLE 870-3. A2A5A5 RELAY DRIVER/RPP PCA  
(SEE FIGURE 870-2.)

REFERENCE DESIGNATOR A->NUMERICS-->	S	DESCRIPTION	FLUKE STOCK --NO--	MFRS SPLY CODE--	MANUFACTURERS PART NUMBER --OR GENERIC TYPE--	TOT QTY	R S -Q	N O T -E
C 1- 7, 11		CAP,POLYES,0.1UF,+20%,50V	732883	89536	732883	8		
C 8, 9, 12,		CAP,CER,0.01UF,+20%,100V,X7R	407361	72982	8121-A100-W5R-103M	4		
C 13			407361					
C 10, 16		CAP,CER,0.22UF,+20%,50V,Z5U	519157	51406	RPE111Z5U224M50V	2		
C 14, 15		ELECTRO, MIN,LD LEAK, 4.7MF, 35V	603993	89536	603993	2		
CR 11- 14, 16,	*	DIODE,SI,BV= 75.0V,I0=150MA,500 MW	203323	07910	1N4448	6	1	
CR 17	*		203323					
J 2		SOCKET,DIP,0.100 CTR,24 PIN	376236	91506	324-AG39D	1		
L 1- 10		CHOKE,4TURN	320911	89536	320911	10		
L 11		INDUCTOR,470 OH,+/-5%,6.5 MHZ,SHLDED	147827	72259	WEE470	1		
L 12, 13		INDUCTOR,47 OH,+/-5%,26.5 MHZ,SHLDED	147850	72259	WEE47	2	2	
P 1- 11		CONN,SOCKET,PWB,0.049 DIAMETER	544056	89536	544056	11		
Q 1- 7, 9	*	TRANSISTOR,SI,PNP,SMALL SIGNAL	418707	04713	MPS56562	8	1	
Q 8	*	TRANSISTOR,SI,NPN,SMALL SIGNAL	330803	07263	MPS6560	1	1	
R 1, 4, 7,		RES,CF,510,+5%,0.25W	441600	80031	CR251-4-5P510E	8	1	
R 10, 13, 16,			441600					
R 19, 38			441600					
R 2, 5, 8,		RES,CF,4.7K,+5%,0.25W	348821	01121	CB4725	9		
R 11, 14, 17,			348821					
R 20, 39, 41			348821					
R 3, 6, 9,		RES,CF,100,+5%,0.25W	348771	80031	CR251-4-5P100E	8		
R 12, 15, 18,			348771					
R 21, 40			348771					
R 22, 23, 29,		RES,CF,1K,+5%,0.25W	343426	80031	CR251-4-5P1K	7		
R 35, 36, 42,			343426					
R 45			343426					
R 24		RES,CF,30K,+5%,0.25W	368753	80031	CR251-4-5P30K	1		
R 25, 30, 31,		RES,CF,10K,+5%,0.25W	348839	80031	CR251-4-5P10K	4		
R 37			348839					
R 27		RES,MF,1.07K,+1%,0.125W,100PPM	344325	89536	344325	1		
R 28		RES,MF,422,+1%,0.125W,100PPM	288506	91637	CMF554220F	1		
R 32		RES,MF,1.5K,+1%,0.125W,100PPM	313098	91637	CMF551501F	1		
R 33		RES,CF,56,+5%,0.25W	342618	80031	CR251-4-5P56E	1		
R 34		RES,CF,100K,+5%,0.25W	348920	80031	CR251-4-5P100K	1		
R 43		RES,CF,13K,+5%,0.25W	441402	80031	CR251-4-5P13K	1		
R 44		RES,CF,2K,+5%,0.25W	441469	80031	CR251-4-5P2K	1		
R 46		RES,CF,470,+5%,0.25W	343434	80031	CR251-4-5P470E	1		
R 47		RES,CF,12K,+5%,0.25W	348847	80031	CR251-4-5P12K	1		
R 48		RES,CF,4.3K,+5%,0.25W	441576	80031	CR251-4-5P4K3	1		
TP 1- 11		CONN,POST,PWB,.025SQ,NON-INSUL,SELECT	267500	00779	87022-1	20		1
U 1	*	IC,OP AMP,QUAD,JFET INPUT,TO-5 CASE	483438	89536	483438	1		
VR 1- 7, 15	*	ZENER,UNCOMP, 30.0V,10%, 4.2MA, 0.4W	272633	04713	1N972A	8		
VR 8, 9, 18	*	ZENER,UNCOMP, 4.7V, 5%, 20.0MA, 0.4W	524058	14552	1N751	3	2	
VR 10	*	ZENER,COMP, 6.4V, 5%, 1 PPM TC, 2.0MA	381988	89536	381988	1	2	

1 ALSO INCLUDES J1.

**OPTION -870**  
**ATTENUATOR/RPP (REVERSE POWER PROTECTOR)**



6060A-1645

**Figure 870-2. A2A5A5 Relay Driver/RPP PCA**

## **Section 7**

# **General Information**

7-1. This section of the manual contains generalized user information as well as supplemental information to the List of Replaceable Parts contained in Section 5.

## List of Abbreviations and Symbols

<b>A or amp</b>	ampere	<b>hf</b>	high frequency	<b>(+) or pos</b>	positive
<b>ac</b>	alternating current	<b>Hz</b>	hertz	<b>pot</b>	potentiometer
<b>af</b>	audio frequency	<b>IC</b>	integrated circuit	<b>p-p</b>	peak-to-peak
<b>a/d</b>	analog-to-digital	<b>if</b>	intermediate frequency	<b>ppm</b>	parts per million
<b>assy</b>	assembly	<b>in</b>	inch(es)	<b>PROM</b>	programmable read-only memory
<b>AWG</b>	american wire gauge	<b>intl</b>	internal	<b>psi</b>	pound-force per square inch
<b>B</b>	bel	<b>I/O</b>	input/output	<b>RAM</b>	random-access memory
<b>bcd</b>	binary coded decimal	<b>k</b>	kilo ( $10^3$ )	<b>rf</b>	radio frequency
<b>°C</b>	Celsius	<b>kHz</b>	kilohertz	<b>rms</b>	root mean square
<b>cap</b>	capacitor	<b>kΩ</b>	kilohm(s)	<b>ROM</b>	read-only memory
<b>ccw</b>	counterclockwise	<b>kV</b>	kilovolt(s)	<b>s or sec</b>	second (time)
<b>cer</b>	ceramic	<b>lf</b>	low frequency	<b>scope</b>	oscilloscope
<b>cermet</b>	ceramic to metal(seal)	<b>LED</b>	light-emitting diode	<b>SH</b>	shield
<b>ckt</b>	circuit	<b>LSB</b>	least significant bit	<b>Si</b>	silicon
<b>cm</b>	centimeter	<b>LSD</b>	least significant digit	<b>serno</b>	serial number
<b>cmrr</b>	common mode rejection ratio	<b>M</b>	mega ( $10^6$ )	<b>sr</b>	shift register
<b>comp</b>	composition	<b>m</b>	milli ( $10^{-3}$ )	<b>Ta</b>	tantalum
<b>cont</b>	continue	<b>mA</b>	milliampere(s)	<b>tb</b>	terminal board
<b>crt</b>	cathode-ray tube	<b>max</b>	maximum	<b>tc</b>	temperature coefficient or temperature compensating
<b>cw</b>	clockwise	<b>mf</b>	metal film	<b>tcxo</b>	temperature compensated crystal oscillator
<b>d/a</b>	digital-to-analog	<b>MHz</b>	megahertz	<b>tp</b>	test point
<b>dac</b>	digital-to-analog converter	<b>min</b>	minimum	<b>u or μ</b>	micro ( $10^{-6}$ )
<b>dB</b>	decibel	<b>mm</b>	millimeter	<b>uhf</b>	ultra high frequency
<b>dc</b>	direct current	<b>ms</b>	millisecond	<b>us or μs</b>	microsecond(s) ( $10^{-6}$ )
<b>dmm</b>	digital multimeter	<b>MSB</b>	most significant bit	<b>uut</b>	unit under test
<b>dvm</b>	digital voltmeter	<b>MSD</b>	most significant digit	<b>V</b>	volt
<b>elect</b>	electrolytic	<b>MTBF</b>	mean time between failures	<b>v</b>	voltage
<b>ext</b>	external	<b>MTTR</b>	mean time to repair	<b>var</b>	variable
<b>F</b>	farad	<b>mV</b>	millivolt(s)	<b>vco</b>	voltage controlled oscillator
<b>°F</b>	Fahrenheit	<b>mv</b>	multivibrator	<b>vhf</b>	very high frequency
<b>FET</b>	Field-effect transistor	<b>MΩ</b>	megohm(s)	<b>vlf</b>	very low frequency
<b>ff</b>	flip-flop	<b>n</b>	nano ( $10^{-9}$ )	<b>W</b>	watt(s)
<b>freq</b>	frequency	<b>na</b>	not applicable	<b>ww</b>	wire wound
<b>FSN</b>	federal stock number	<b>NC</b>	normally closed	<b>xfmr</b>	transformer
<b>g</b>	gram	<b>(-) or neg</b>	negative	<b>xstr</b>	transistor
<b>G</b>	giga ( $10^9$ )	<b>NO</b>	normally open	<b>xtal</b>	crystal
<b>gd</b>	guard	<b>ns</b>	nanosecond	<b>xtlo</b>	crystal oscillator
<b>Ge</b>	germanium	<b>opnl ampli</b>	operational amplifier	<b>Ω</b>	ohm(s)
<b>GHz</b>	gigahertz	<b>p</b>	pico ( $10^{-12}$ )	<b>μ</b>	micro ( $10^{-6}$ )
<b>gmV</b>	guaranteed minimum value	<b>para</b>	paragraph		
<b>gnd</b>	ground	<b>pcb</b>	printed circuit board		
<b>H</b>	henry	<b>pF</b>	picofarad		
<b>hd</b>	heavy duty	<b>pn</b>	part number		



# Federal Supply Codes for Manufacturers

00213 Nytronics Comp. Group Inc. Subsidiary of Nytronics Inc. Formerly Sage Electronics Rochester, New York	02660 Bunker Ramo Corp., Conn Div. Formerly Amphenol-Borg Electric Corp. Broadview, Illinois	04946 Standard Wire & Cable Los Angeles, California	06751 Components, Inc. Semcor Div. Phoenix, Arizona
00327 Welwyn International, Inc. Westlake, Ohio	02799 Areo Capacitors, Inc. Chatsworth, California	05082 Replaced by 94988	06860 Gould Automotive Div. City of Industry, California
00656 Aerovox Corp. New Bedford, Massachusetts	03508 General Electric Co. Semiconductor Products Syracuse, New York	05236 Jonathan Mfg. Co. Fullerton, California	06961 Vernitron Corp., Piezo Electric Div. Formerly Clevite Corp., Piezo Electric Div. Bedford, Ohio
00686 Film Capacitors, Inc. Passaic, New Jersey	03614 Replaced by 71400	05245 Components Corp. now Corcom, Inc. Chicago, Illinois	06980 Eimac Div. Varian Associates San Carlos, California
00779 AMP Inc. Harrisburg, Pennsylvania	03651 Replaced by 44655	05277 Westinghouse Electric Corp. Semiconductor Div. Youngwood, Pennsylvania	07047 The Ross Milton Co. South Hampton, Pennsylvania
01121 Allen-Bradley Co. Milwaukee, Wisconsin	03797 Eldema Div. Genisco Technology Corp. Compton, California	05278 Replaced by 43543	07115 Replaced by 14674
01281 TRW Electronic Comp. Semiconductor Operations Lawndale, California	03877 Transistron Electronic Corp. Wakefield, Massachusetts	05279 Southwest Machine & Plastic Co. Glendora, California	07138 Westinghouse Electric Corp., Electronic Tube Div. Horsehead, New York
01295 Texas Instruments, Inc. Semiconductor Group Dallas, Texas	03888 KDI Pyrofilm Corp. Whippany, New Jersey	05397 Union Carbide Corp. Materials Systems Div. New York, New York	07233 TRW Electronic Components Cinch Graphic City of Industry, California
01537 Motorola Communications & Electronics Inc. Franklin Park, Illinois	03911 Clairex Electronics Div. Clairex Corp. Mt. Vernon, New York	05571 Use 56289 Sprague Electric Co. Pacific Div. Los Angeles, California	07256 Silicon Transistor Corp. Div. of BBF Group Inc. Chelmsford, Massachusetts
01686 RCL Electronics Inc. Manchester, New Hampshire	03980 Muirhead Inc. Mountainside, New Jersey	05574 Viking Industries Chatsworth, California	07261 Aumet Corp. Culver City, California
01730 Replaced by 73586	04009 Arrow Hart Inc. Hartford, Connecticut	05704 Replaced by 16258	07263 Fairchild Semiconductor Div. of Fairchild Camera & Instrument Corp. Mountain View, California
01884 Use 56289 Sprague Electric Co. Dearborn Electronic Div. Lockwood, Florida	04062 Replaced by 72136	05820 Wakefield Engineering Inc. Wakefield, Massachusetts	07344 Bircher Co., Inc. Rochester, New York
02114 Ferroxcube Corp. Saugerties, New York	04202 Replaced by 81312	06001 General Electric Co. Electronic Capacitor & Battery Products Dept. Columbia, South Carolina	07597 Burndy Corp. Tape/Cable Div. Rochester, New York
02131 General Instrument Corp. Harris ASW Div. Westwood, Maine	04217 Essex International Inc. Wire & Cable Div. Anaheim, California	06136 Replaced by 63743	07792 Lerma Engineering Corp. Northampton, Massachusetts
02395 Rason Mfg. Co. Brooklyn, New York	04221 Aemco, Div. of Midtex Inc. Mankato, Minnesota	06383 Panduit Corp. Tinley Park, Illinois	07910 Teledyne Semiconductor Formerly Continental Device Hawthorne, California
02533 Snelgrove, C.R. Co., Ltd. Don Mills, Ontario, Canada M3B 1M2	04222 AVX Ceramics Div. AVX Corp. Myrtle Beach, Florida	06473 Bunker Ramo Corp. Amphenol SAMS Div. Chatsworth, California	07933 Use 49956 Raytheon Co. Semiconductor Div. HQ Mountain View, California
02606 Fenwal Labs Div. of Travenal Labs. Morton Grove, Illinois	04423 Telonic Industries Laguna Beach, California	06555 Beede Electrical Instrument Co. Penacook, New Hampshire	08225 Industro Transistor Corp. Long Island City, New York
	04645 Replaced by 75376	06739 Electron Corp. Littleton, Colorado	
	04713 Motorola Inc. Semiconductor Products Phoenix, Arizona	06743 Clevite Corp. Cleveland, Ohio	

# Federal Supply Codes for Manufacturers (cont)

08261 Spectra Strip Corp. Garden Grove, California	11726 Qualidyne Corp. Santa Clara, California	13606 Use 56289 Sprague Electric Co. Transistor Div. Concord, New Hampshire	16299 Corning Glass Electronic Components Div. Raleigh, North Carolina
08530 Reliance Mica Corp. Brooklyn, New York	12014 Chicago Rivet & Machine Co. Bellwood, Illinois	13839 Replaced by 23732	16332 Replaced by 28478
08806 General Electric Co. Miniature Lamp Products Dept Cleveland, Ohio	12040 National Semiconductor Corp. Danbury, Connecticut	14099 Semtech Corp. Newbury Park, California	16473 Cambridge Scientific Ind. Div. of Chemed Corporation Cambridge, Maryland
08863 Nylomatic Corp. Norrisville, Pennsylvania	12060 Diodes, Inc. Chatsworth, California	14140 Edison Electronic Div. Mc Gray-Edison Co. Manchester, New Hampshire	16742 Paramount Plastics Fabricators, Inc. Downey, California
08988 Use 53085 Skottie Electronics Inc. Archbald, Pennsylvania	12136 Philadelphia Handle Co. Camden, New Jersey	14193 Cal-R-Inc. formerly California Resistor, Corp. Santa Monica, California	16758 Delco Electronics Div. of General Motors Corp. Kokomo, Indiana
09214 G.E. Co. Semi-Conductor Products Dept. Power Semi-Conductor Products OPN Sec. Auburn, New York	12300 Potter-Brumfield Div. AMF Canada LTD. Guelph, Ontario, Canada	14298 American Components, Inc. an Insilco Co. Conshohocken, Pennsylvania	17001 Replaced by 71468
09353 C and K Components Watertown, Massachusetts	12323 Presin Co., Inc. Shelton, Connecticut	14655 Cornell-Dublier Electronics Division of Federal Pacific Electric Co. Govt. Control Dept. Newark, New Jersey	17069 Circuit Structures Lab. Burbank, California
09423 Scientific Components, Inc. Santa Barbara, California	12327 Freeway Corp. formerly Freeway Washer & Stamping Co. Cleveland, Ohio	14752 Electro Cube Inc. San Gabriel, California	17338 High Pressure Eng. Co., Inc. Oklahoma City, Oklahoma
09922 Burndy Corp. Norwalk, Connecticut	12443 The Budd Co. Polychem Products Plastic Products Div. Bridgeport, Pennsylvania	14869 Replaced by 96853	17545 Atlantic Semiconductors, Inc. Asbury Park, New Jersey
09969 Dale Electronics Inc. Yankton, S. Dakota	12615 U.S. Terminals Inc. Cincinnati, Ohio	14936 General Instrument Corp. Semi Conductor Products Group Hicksville, New York	17856 Siliconix, Inc. Santa Clara, California
10059 Barker Engineering Corp. Formerly Amerace, Amerace ESNA Corp. Kenilworth, New Jersey	12617 Hamlin Inc. Lake Mills, Wisconsin	15636 Elec-Trol Inc. Saugus, California	17870 Replaced by 14140
11236 CTS of Berne Berne, Indiana	12697 Clarostat Mfg. Co. Dover, New Hampshire	15801 Fenwal Electronics Inc. Div. of Kidde Walter and Co., Inc. Framingham, Massachusetts	18178 Vactec Inc. Maryland Heights, Missouri
11237 CTS Keene Inc. Paso Robles, California	12749 James Electronics Chicago, Illinois	15818 Teledyne Semiconductors, formerly Amelco Semiconductor Mountain View, California	18324 Signetics Corp. Sunnyvale, California
11358 CBS Electronic Div. Columbia Broadcasting System Newburyport, Minnesota	12856 Micrometals Sierra Madre, California	15849 Litton Systems Inc. Useco Div. formerly Useco Inc. Van Nuys, California	18612 Vishay Resistor Products Div. Vishay Intertechnology Inc. Malvern, Pennsylvania
11403 Best Products Co. Chicago, Illinois	12954 Dickson Electronics Corp. Scottsdale, Arizona	15898 International Business Machines Corp. Essex Junction, Vermont	18736 Voltronics Corp. Hanover, New Jersey
11503 Keystone Columbia Inc. Warren, Michigan	12969 Unitrode Corp. Watertown, Massachusetts	15909 Replaced by 14140	18927 GTE Sylvania Inc. Precision Material Group Parts Division Titusville, Pennsylvania
11532 Teledyne Relays Hawthorne, California	13103 Thermalloy Co., Inc. Dallas, Texas	16258 Space-Lok Inc. Burbank, California	19451 Perine Machinery & Supply Co. Seattle, Washington
11711 General Instrument Corp. Rectifier Division Hicksville, New York	13327 Solitron Devices Inc. Tappan, New York		19701 Electro-Midland Corp. Mepco-Electra Inc. Mineral Wells, Texas
	13511 Amphenol Cadre Div. Bunker-Ramo Corp. Los Gatos, California		20584 Enochs Mfg. Inc. Indianapolis, Indiana

# Federal Supply Codes for Manufacturers (cont)

20891 Self-Organizing Systems, Inc. Dallas, Texas	28480 Hewlett Packard Co. Corporate HQ Palo Alto, California	43543 Nytronics Inc. Transformer Co. Div. Geneva, New York	70903 Belden Corp. Geneva, Illinois
21604 Bucheys Stamping Co. Columbus, Ohio	28520 Heyman Mfg. Co. Kenilworth, New Jersey	44655 Ohmite Mfg. Co. Skokie, Illinois	71002 Birnback Radio Co., Inc. Freeport, New York
21845 Solitron Devices Inc. Transistor Division Riveria Beach, Florida	29083 Monsanto, Co., Inc. Santa Clara, California	49671 RCA Corp. New York, New York	71400 Bussmann Mfg. Div. of McGraw-Edison Co. Saint Louis, Missouri
22767 ITT Semiconductors Palo Alto, California	29604 Stackpole Components Co. Raleigh, North Carolina	49956 Raytheon Company Lexington, Massachusetts	71450 CTS Corp. Elkhart, Indiana
23050 Product Comp. Corp. Mount Vernon, New York	30148 AB Enterprise Inc. Ahsokie, North Carolina	50088 Mostek Corp. Carrollton, Texas	71468 ITT Cannon Electric Inc. Santa Ana, California
23732 Tracor Inc. Rockville, Maryland	30323 Illinois Tool Works, Inc. Chicago, Illinois	50579 Litronix Inc. Cupertino, California	71482 Clare, C.P. & Co. Chicago, Illinois
23880 Stanford Applied Engrng. Santa Clara, California	31091 Optimax Inc. Colmar, Pennsylvania	51605 Scientific Components Inc. Linden, New Jersey	71590 Centrelab Electronics Div. of Globe Union Inc. Milwaukee, Wisconsin
23936 Pamotor Div., Wm. J. Purdy Co. Burlingame, California	32539 Mura Corp. Great Neck, New York	53021 Sangamo Electric Co. Springfield, Illinois	71707 Coto Coil Co., Inc. Providence, Rhode Island
24248 Replaced by 94222	32767 Griffith Plastic Corp. Burlingame, California	54294 Cutler-Hammer Inc. formerly Shallcross, A Cutter-Hammer Co. Selma, North Carolina	71744 Chicago Miniature Lamp Works Chicago, Illinois
24355 Analog Devices Inc. Norwood, Massachusetts	32879 Advanced Mechanical Components Northridge, California	55026 Simpson Electric Co. Div. of Am. Gage and Mach. Co. Elgin, Illinois	71785 TRW Electronics Components Cinch Connector Operations Div. Elk Grove Village Chicago, Illinois
24655 General Radio Concord, Massachusetts	32897 Erie Technological Products, Inc. Frequency Control Div. Carlisle, Pennsylvania	56289 Sprague Electric Co. North Adams, Massachusetts	72005 Wilber B. Driver Co. Newark, New Jersey
24759 Lenox-Fugle Electronics Inc. South Plainfield, New Jersey	32997 Bourns Inc. Trimpot Products Division Riverside, California	58474 Superior Electric Co. Bristol, Connecticut	72092 Replaced by 06980
25088 Siemen Corp. Isilen, New Jersey	33173 General Electric Co. Products Dept. Owensboro, Kentucky	60399 Torin Corp. formerly Torrington Mfg. Co. Torrington, Connecticut	72136 Electro Motive Mfg. Co. Williamantic, Connecticut
25403 Amperex Electronic Corp. Semiconductor & Micro-Circuits Div. Slatersville, Rhode Island	34333 Silicon General Westminister, California	63743 Ward Leonard Electric Co., Inc. Mount Vernon, New York	72259 Nytronics Inc. Pelham Manor, New Jersey
27014 National Semiconductor Corp. Santa Clara, California	34335 Advanced Micro Devices Sunnyvale, California	64834 West Mfg. Co. San Francisco, California	72619 Dialight Div. Amperex Electronic Corp. Brooklyn, New York
27264 Molex Products Downers Grove, Illinois	34802 Electromotive Inc. Kenilworth, New Jersey	65092 Weston Instruments Inc. Newark, New Jersey	72653 G.C. Electronics Div. of Hydrometals, Inc. Brooklyn, New York
28213 Minnesota Mining & Mfg. Co. Consumer Products Div. St. Paul, Minnesota	37942 P.R. Mallory & Co., Inc. Indianapolis, Indiana	66150 Winslow Tele-Tronics Inc. Eaton Town, New Jersey	72665 Replaced by 90303
28425 Serv-/Link formerly Bohannon Industries Fort Worth, Texas	42498 National Radio Melrose, Massachusetts	70485 Atlantic India Rubber Works Chicago, Illinois	72794 Dzus Fastener Co., Inc. West Islip, New York
28478 Deltrol Controls Div. Deltrol Corporation Milwaukee, Wisconsin		70563 Amperite Company Union City, New Jersey	72928 Gulton Ind. Inc. Gudeman Div. Chicago, Illinois

# Federal Supply Codes for Manufacturers (cont)

72982 Erie Tech. Products Inc. Erie, Pennsylvania	75382 Kulka Electric Corp. Mount Vernon, New York	80583 Hammarlund Mfg. Co., Inc. Red Bank, New Jersey	83594 Burrhoughs Corp. Electronic Components Div. Plainfield, New Jersey
73138 Bechman Instrument Inc. Helipot Division Fullerton, California	75915 Littlefuse Inc. Des Plaines, Illinois	80640 Arnold Stevens, Inc. South Boston, Massachusetts	83740 Union Carbide Corp. Battery Products Div. formerly Consumer Products Div. New York, New York
73293 Hughes Aircraft Co. Electron Dynamics Div. Torrance, California	76854 Oak Industries Inc. Switch Div. Crystal Lake, Illinois	81073 Grayhill, Inc. La Grange, Illinois	84171 Arco Electronics Great Neck, New York
73445 Amperex Electronic Corp. Hicksville, New York	77342 AMF Inc. Potter & Brumfield Div. Princeton, Indiana	81312 Winchester Electronics Div. of Litton Industries Inc. Oakville, Connecticut	84411 TRW Electronic Components TRW Capacitors Ogallala, Nebraska
73559 Carling Electric Inc. West Hartford, Connecticut	77638 General Instrument Corp. Rectifier Division Brooklyn, New York	81483 Therm-O-Disc Inc. Mansfield, Ohio	84613 Fuse Indicator Corp. Rockville, Maryland
73586 Circle F Industries Trenton, New Jersey	77969 Rubbercraft Corp. of CA. LTD. Torrance, California	81483 International Rectifier Corp. Los Angeles, California	84682 Essex International Inc. Industrial Wire Div. Peabody, Massachusetts
73734 Federal Screw Products, Inc. Chicago, Illinois	78189 Shakeproof Div. of Illinois Tool Works Inc. Elgin, Illinois	81590 Korby Mfg. Co. Seattle, Washington	86577 Precision Metal Products of Malden Inc. Stoneham, Massachusetts
73743 Fischer Special Mfg. Co. Cincinnati, Ohio	78277 Sigma Instruments, Inc. South Braintree, Massachusetts	81741 Chicago Lock Co. Chicago, Illinois	86684 Radio Corp. of America Electronic Components Div. Harrison, New Jersey
73899 JFD Electronics Co. Components Corp. Brooklyn, New York	78488 Stackpole Carbon Co. Saint Marys, Pennsylvania	82305 Palmer Electronics Corp. South Gate, California	86928 Seastrom Mfg. Co., Inc. Glendale, California
73949 Guardian Electric Mfg. Co. Chicago, Illinois	78553 Eaton Corp. Engineered Fastener Div. Tinnerman Plant Cleveland, Ohio	82389 Switchcraft Inc. Chicago, Illinois	87034 Illuminated Products Inc. Subsidiary of Oak Industries Inc. Anaheim, California
74199 Quan Nichols Co. Chicago, Illinois	79136 Waldes Kohinoor Inc. Long Island City, New York	82415 North American Phillips Controls Corp. Frederick, Maryland	88219 Gould Inc. Industrial Div. Trenton, New Jersey
74217 Radio Switch Corp. Marlboro, New Jersey	79497 Western Rubber Company Goshen, Indiana	82872 Roanwell Corp. New York, New York	88245 Litton Systems Inc. Usecu Div. Van Nuys, California
74276 Signalite Div. General Instrument Corp. Neptune, New Jersey	79963 Zierick Mfg. Corp. Mt. Kisko, New York	82877 Rotron Inc. Woodstock, New York	88419 Cornell-Dubilier Electronic Div. Federal Pacific Co. Fuquay-Varian, North Carolina
74306 Piezo Crystal Co. Carlisle, Pennsylvania	80031 Electro-Midland Corp. Mepco Div. A North American Phillips Co. Norristown, New Jersey	82879 ITT Royal Electric Div. Pawtucket, Rhode Island	88486 Plastic Wire & Cable Jewitt City, Connecticut
74542 Hoyt Elect. Instr. Works Penacook, New Hampshire	80145 LFE Corp., Process Control Div. formerly API Instrument Co. Chesterland, Ohio	83003 Varo Inc. Garland, Texas	88690 Replaced by 04217
74970 Johnson E.F., Co. Waseca, Minnesota	80183 Use 56289 Sprague Products North Adams, Massachusetts	83058 The Carr Co., United Can Div. of TRW Cambridge, Massachusetts	89536 John Fluke Mfg. Co., Inc. Seattle, Washington
75042 TRW Electronics Components IRC Fixed Resistors Philadelphia, Pennsylvania	80294 Bourns Inc., Instrument Div. Riverside, California	83298 Bendix Corp. Electric Power Div. Eatontown, New Jersey	89730 G.E. Co., Newark Lamp Works Newark, New Jersey
75376 Kurz-Kasch Inc. Dayton, Ohio		83330 Herman H. Smith, Inc. Brooklyn, New York	
75378 CTS Knights Inc. Sandwich, Illinois		83478 Rubbercraft Corp. of America, Inc. West Haven, Connecticut	

# Federal Supply Codes for Manufacturers (cont)

90201 Mallory Capacitor Co. Div. of P.R. Mallory Co., Inc. Indianapolis, Indiana	91836 King's Electronics Co., Inc. Tuckahoe, New York	95354 Methode Mfg. Corp. Rolling Meadows, Illinois	98291 Sealectro Corp. Mamaroneck, New York
90211 Use 56365 Square D Co. Chicago, Illinois	91929 Honeywell Inc. Micro Switch Div. Freeport, Illinois	95712 Bendix Corp. Electrical Components Div. Microwave Devices Plant Franklin, Indiana	98388 Royal Industries Products Div. San Diego, California
90215 Best Stamp & Mfg. Co. Kansas City, Missouri	91934 Miller Electric Co., Inc. Div. of Aunet Woonsocket, Rhode Island	95987 Weckesser Co. Inc. Chicago, Illinois	98743 Replaced by 12749
90303 Mallory Battery Co. Div. of Mallory Co., Inc. Tarrytown, New York	92194 Alpha Wire Corp. Elizabeth, New Jersey	96733 San Fernando Electric Mfg. Co. San Fernando, California	98925 Replaced by 14433
91094 Essex International Inc. Suglex/IWP Div. Newmarket, New Hampshire	93332 Sylvania Electric Products Semiconductor Products Div. Woburn, Massachusetts	96853 Gulton Industries Inc. Measurement and Controls Div. formerly Rustrak Instruments Co. Manchester, New Hampshire	99120 Plastic Capacitors, Inc. Chicago, Illinois
91293 Johanson Mfg. Co. Boonton, New Jersey	94145 Replaced by 49956	96881 Thomson Industries, Inc. Manhasset, New York	99217 Bell Industries Elect. Comp. Div. formerly Southern Elect. Div. Burbank, California
91407 Replaced by 58474	94154 Use 94988 Wagner Electric Corp. Tung-Sol Div. Newark, New Jersey	97540 Master Mobile Mounts, Div. of Whitehall Electronics Corp. Ft. Meyers, Florida	99392 STM Oakland, California
91502 Associated Machine Santa Clara, California	94222 Southco Inc. formerly South Chester Corp. Lester, Pennsylvania	97913 Industrial Electronic Hardware Corp. New York, New York	99515 ITT Jennings Monrovia Plant Div. of ITT Jennings formerly Marshall Industries Capacitor Div. Monrovia, California
91506 Augat Inc. Attleboro, Massachusetts	95146 Alco Electronic Products Inc. Lawrence, Massachusetts	97945 Penwalt Corp. SS White Industrial Products Div. Piscataway, New Jersey	99779 Use 29587 Bunker-Ramo Corp. Barnes Div. Landsdowne, Pennsylvania
91637 Dale Electronics Inc. Columbus, Nebraska	95263 Leecraft Mfg. Co. Long Island City, New York	97966 Replaced by 11358	99800 American Precision Industries Inc. Delevan Division East Aurora, New York
91662 Elco Corp. Willow Grove, Pennsylvania	95264 Replaced by 98278	98094 Replaced by 49956	99942 Centrelab Semiconductor Centrelab Electronics Div. of Globe-Union Inc. El Monte, California
91737 Use 71468 Gremar Mfg. Co., Inc. ITT Cannon/Gremar Santa Ana, California	95275 Vitramon Inc. Bridgeport, Connecticut	98159 Rubber-Teck, Inc. Gardena, California	Toy Electronics (R-Ohm Corp.) Irvine, California
91802 Industrial Devices, Inc. Edgewater, New Jersey	95303 RCA Corp. Receiving Tube Div. Cincinnati, Ohio	98278 Malco A Microdot Co., Inc. Connector & Cable Div. Pasadena, California	National Connector Minneapolis, Minnesota
91833 Keystone Electronics Corp. New York, New York	95348 Gordo's Corp. Bloomfield, New Jersey		



# U.S. SALES AREAS for all Fluke products

## AL, Huntsville

John Fluke Mfg. Co., Inc.  
3322 S. Memorial Parkway  
Suite 96  
Huntsville, AL 35801  
(205) 881-6220

## AZ, Tempe

John Fluke Mfg. Co., Inc.  
2211 S. 48th Street  
Suite B  
Tempe, AZ 85282  
(602) 438-8314

## Tucson

(602) 790-9881

## CA, Irvine

P.O. Box 19676  
Irvine, CA 92713  
16969 Von Karman  
Suite 100  
Irvine, CA 92714  
(714) 863-9031

## Los Angeles

John Fluke Mfg. Co., Inc.  
20902 South Bonita St.  
Carson, CA 90746  
(213) 538-3900

## San Diego

John Fluke Mfg. Co., Inc.  
4540 Kearny Villa Rd., Suite 115  
San Diego, CA 92123  
(619) 292-7656

## Santa Clara

John Fluke Mfg. Co., Inc.  
2300 Walsh Ave., Bldg. K  
Santa Clara, CA 95051  
(408) 727-0513

## CO, Denver

John Fluke Mfg. Co., Inc.  
1980 South Quebec St. #4  
Denver, CO 80231  
(303) 750-1222

## CT, Hartford

John Fluke Mfg. Co., Inc.  
Glen Lochen East  
41-C New London Turnpike  
Glastonbury, CT 06033  
(203) 659-3541

## FL, Orlando

John Fluke Mfg. Co., Inc.  
940 N. Fern Creek Ave.  
Orlando, FL 32803  
(305) 896-4881

## GA, Atlanta

John Fluke Mfg. Co., Inc.  
2700 Delk Rd., Suite 250  
Marietta, GA 30067  
(404) 953-4747

## IA, Iowa City

(319) 354-2811

## IL, Chicago

John Fluke Mfg. Co., Inc.  
3740 Industrial Ave.  
Rolling Meadows, IL 60008  
(312) 398-0850

## IN, Indianapolis

John Fluke Mfg. Co., Inc.  
8777 Purdue Road  
Suite 101  
Indianapolis, IN 46268  
(317) 875-7870

## KS, Kansas City

(913) 381-9800

## LA, New Orleans

(504) 455-0814

## MA, Burlington

John Fluke Mfg. Co., Inc.  
25 "B" Street  
Burlington MA 01803  
(617) 273-4674

## MD, Baltimore

(301) 792-7060

## Rockville

John Fluke Mfg. Co., Inc.  
5640 Fishers Lane  
Rockville, MD 20852  
(301) 770-1570

## MI, Detroit

John Fluke Mfg. Co., Inc.  
33031 Schoolcraft  
Livonia, MI 48150  
(313) 522-9140

## MN, Bloomington

John Fluke Mfg. Co., Inc.  
1801 E. 79th St., Suite 9  
Bloomington, MN 55420  
(612) 854-5526

## MO, St. Louis

John Fluke Mfg. Co., Inc.  
2029 Woodland Parkway  
Suite 105  
St. Louis, MO 63141  
(314) 993-3805

## NC, Greensboro

John Fluke Mfg. Co., Inc.  
1310 Beaman Place  
Greensboro, NC 27408  
(919) 273-1918

## NJ, Paramus

John Fluke Mfg. Co., Inc.  
P.O. Box 930  
West 75 Century Road  
Paramus, NJ 07652  
(201) 262-9550

## NM, Albuquerque

John Fluke Mfg. Co., Inc.  
1108 Alvarado Drive N.E.  
Albuquerque, NM 87110  
(505) 881-3550

## NY, Rochester

John Fluke Mfg. Co., Inc.  
4515 Culver Road  
Rochester, NY 14622  
(716) 323-1400

## OH, Cleveland

John Fluke Mfg. Co., Inc.  
7830 Freeway Circle  
Middleburg Heights, OH 44130  
(216) 234-4540

## Columbus

(614) 889-5715

## Dayton

John Fluke Mfg. Co., Inc.  
4756 Fishburg Rd.  
Dayton, OH 45424  
(513) 233-2238

## OK, Tulsa

(918) 749-0190

## OR, Portland

John Fluke Mfg. Co., Inc.  
2700 NW 185th  
Suite 2080  
Portland, OR 97229  
(503) 629-5928

## PA, Philadelphia

John Fluke Mfg. Co., Inc.  
1010 West 8th Ave., Suite H  
King of Prussia, PA 19406  
(215) 265-4040

## Pittsburgh

(412) 261-5171

## TX, Austin

(512) 459-3344

## Dallas

John Fluke Mfg. Co., Inc.  
14400 Midway Road  
Dallas, TX 75234  
(214) 233-9990

## Houston

John Fluke Mfg. Co., Inc.  
4240 Blue Bonnet Dr.  
Stafford, TX 77477  
(713) 491-5995

## San Antonio

John Fluke Mfg. Co., Inc.  
10417 Gulfdale  
San Antonio, TX 78216  
(512) 340-2621

## UT, Salt Lake City

6914 So. 3000 East  
Suite 206  
Salt Lake City, UT 82021  
(801) 268-9331

## WA, Seattle

John Fluke Mfg. Co., Inc.  
5020 148th Ave. N.E.  
Suite 110  
Redmond, WA 98052  
(206) 881-6966

## Service Center Areas

**CA, Burbank** (213) 849-4641  
**CA, Santa Clara** (408) 727-8121  
**CO, Denver** (303) 750-1228  
**FL, Orlando** (305) 896-2296  
**IL, Chicago** (312) 398-5880  
**MA, Burlington** (617) 273-4678  
**MD, Rockville** (301) 770-1576  
**NJ, Paramus** (201) 262-9550  
**TX, Dallas** (214) 233-9945  
**WA, Everett** (206) 356-5560

For more information on Fluke products or Sales Offices you may dial (800) 426-0361 toll-free in most of the U.S.A.  
From Alaska, Hawaii, or Washington phone (206) 356-5400. From Canada and other countries phone (206) 356-5500.



John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett, WA 98206  
Fluke (Holland) B.V., P.O. Box 5053, 5004 EB, Tilburg, The Netherlands. Phone (013) 673973  
Litho in U.S.A. 10/84

# INTERNATIONAL SALES OFFICES

## Argentina •

Coasin S.A.  
Virrey del Pino 4071 DEP E-1  
1430 CAP FED  
Buenos Aires, Argentina  
Tel: (1) 552-5248, TLX: (390) 22284

## Australia •

Elmeasco Instruments Pty, Ltd.  
P.O. Box 30  
Concord, N.S.W. 2137  
Australia  
Tel: (2) 736-2888, TLX: (790) 25887  
Elmeasco Instruments Pty, Ltd.  
21-23 Anthony Drive  
Mt. Waverly, Victoria 3149  
Australia  
Tel: (3) 233-4044, TLX: (790) 36206  
Elmeasco Instruments Pty, Ltd.  
Professional Suites Bldg.  
G.P.O. Box 2360  
Brisbane 4001, Australia  
Tel: (7) 369-8688, TLX: (790) 44062

Elmeasco Instruments Pty, Ltd.  
G.P.O. Box 1240  
Adelaide, South Australia 5001  
Tel: (8) 271-1839

Elmeasco Instruments Pty, Ltd.  
P.O. Box 95  
Gosnells, West Australia 6110  
Australia  
Tel: (9) 398-3362

## Austria ■

Walter Rekersch Elektronische  
Geräte GmbH & Co.  
Vertrieb KG  
Obachgasse 28  
1220 Vienna, Austria  
Tel: (222) 235555, TLX: (847) 134759

## Bangladesh •

Motherland Corporation  
24 Hatkhola Road, Tikatuli  
Dacca-3, Bangladesh  
Tel: 257249, TLX: (950) 642022

## Belgium ■

Fluke (Belgium) S.A./N.V.  
6 Rue de Geneve  
1140 Brussels, Belgium  
Tel: (2) 2164090, TLX: (846) 26312

## Bolivia •

Coasin Bolivia S.R.L.  
Casilla 7295  
La Paz, Bolivia  
Tel: (2) 40962, TLX: (336) 3233

## Brazil •

Fluke Brasil-Industria e  
Comercio Ltda.  
Al. Amazonas 422,  
Alphaville, Barueri,  
CEP 06400, Sao Paulo, Brazil  
Tel: (11) 421-5477, TLX: (391) 1135589

Fluke Brasil-Industria e  
Comercio Ltda.  
Av. Henrique Valadares, No. 23/401  
Rio de Janeiro, Brazil  
Tel: (21) 252-1297

## Brunei •

Rank O'Connor's Berhad, Ltd.  
No. 8 Block D Sufri Complex  
Mile 1 Jalan Tutong  
Bandar Seri Begawan  
Negara Brunei Darussalam  
Tel: (2) 23109 or 23557  
TLX: (799) BU2265 RANKOC

## Canada •

Allan Crawford Assoc., Ltd.  
6503 Northam Drive  
Mississauga, Ontario  
L4V 1J2 Canada  
Tel: (416) 678-1500, TLX: 06968769

Allan Crawford Assoc., Ltd.  
7018 Cote de Liesse  
St. Laurent, Quebec  
H4T 1E7 Canada  
Tel: (514) 731-8564, TLX: 05824944

Allan Crawford Assoc., Ltd.  
881 Lady Ellen Place  
Ottawa, Ontario  
K1Z 5L3 Canada  
Tel: (613) 722-7682, TLX: 0533600

Allan Crawford Assoc., Ltd.  
Suite 106  
4180 Lougheed Hwy.  
Burnaby, British Columbia  
V5C 6A8 Canada  
Tel: (604) 294-1326, TLX: 0454247

Allan Crawford Assoc., Ltd.  
1935 30th Avenue, N.E.  
Calgary, Alberta  
T2E 6Z5 Canada  
Tel: (403) 230-1341, TLX: 03821186

## Chile •

Intronica Chile, Ltda.  
Manuel Montt 024-Of.D  
Casilla 16228  
Santiago 9, Chile  
Tel: (2) 44940, TLX: (332) 240301

## China, Peoples Republic of •

Fluke International Corp.  
P.O. Box C9090 M/S 206-A  
Everett, WA 98206 U.S.A.  
Tel: (206) 356-5511  
TLX: 185103 FLUKE UT

## Colombia •

Sistemas E Instrumentacion, Ltda.  
Carrera 13, No. 37-43, Of. 401  
Ap. Aereo 29583  
Bogota DE, Colombia  
Tel: 232-4532, TLX: (396) 45787

## Cyprus ■

Chris Radiovision, Ltd.  
P.O. Box 1989  
Nicosia, Cyprus  
Tel: (21) 66121, TLX: (826) 2395

## Cyprus, Northern

Ucok Buroteknik  
2C & 2D Muftu Ziyai Street  
Lefkosa, Northern Cyprus  
Mersin 10, Turkey  
Tel: (741) 357-20-71777, TLX: (821) 57267

## Czechoslovakia ■

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

## Denmark ■

Tage Olsen A/S  
Ballerup Byvej 222  
2750 Ballerup  
Denmark  
Tel: (2) 658111, TLX: (855) 35293

## Ecuador •

Proteco Coasin Cia., Ltda.  
P.O. Box 228-A  
Ave. 12 de Octubre 2285  
y Orellana  
Quito, Ecuador  
Tel: (2) 529684, TLX: (393) 2865

Proteco Coasin Cia., Ltda.  
P.O. Box 9733  
Ave. Principal No. 204  
y Calle Segunda  
Urbanizacion Miraflores  
Guayaquil, Ecuador  
Tel: (4) 387519

## Egypt and Sudan ■

Electronic Engineering Liaison Office  
P.O. Box 2891 Horreya  
11361 Heliopolis, Cairo  
Egypt  
Tel: (2) 695705, TLX: (927) 23082

## England ■

Fluke GB, Ltd.  
Colonial Way  
Watford, Herts,  
WD2 4TT England  
Tel: (923) 40511, TLX: (851) 934583

## Fiji •

Awa Fiji  
47 Forster Road  
Walu Bay  
Suva, Fiji  
Tel: 312079, TLX: (792) FJ2347

## Finland ■

Instrumentarium Electronics  
P.O. Box 64  
02631 Espoo 63  
Finland  
Tel: (0) 5281, TLX: (857) 124426

## France ■

M.B. Electronique S.A.  
Rue Fournay  
P.O. Box 31  
78530 BUC, France  
Tel: (3) 956-8131, TLX: (842) 695414

## German Democratic Republic ■

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

## Germany, West ■

Fluke (Deutschland) GmbH  
Oskar-Messter-Strasse 18  
WG-8045 Ismaning/Munich  
West Germany  
Tel: (089) 96050, TLX: (841) 0522472  
Rapifax: 49-89-9605166

## Fluke (Deutschland) GmbH

Viertriebsburo - Dusseldorf  
Meineckestrasse 53  
D-4000 Dusseldorf-30  
West Germany  
Tel: (0211) 450831, TLX: (841) 08585576

Fluke (Deutschland) GmbH  
Vertriebsburo - Hamburg  
Habichthorst 42  
D-2000 Hamburg 61  
West Germany  
Tel: (40) 5519031, TLX: (841) 02174556

## Greece ■

Hellenic Scientific Representations Ltd.  
11, Vrassida Street  
Athens 612, Greece  
Tel: (1) 7211140, TLX: (863) 219330

## Hong Kong •

Schmidt & Co (H.K.), Ltd.  
18th Floor, Great Eagle Centre  
23 Harbour Road  
Wanchai, Hong Kong  
Tel: (5) 8330-222  
TLX: (780) 74766 or (780) 76762

## Hungary ■

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

## India •

Hinditron Services Pvt., Ltd.  
69/A.L. Jagmohandas Marg  
Bombay 400 006, India  
Tel: 8121316, 8125344, TLX: (953) 112326

Hinditron Services Pvt., Ltd.  
8th Main Road  
33/44A Raj Mahal Vilas Extension  
Bangalore 560 080, India  
Tel: 33139, TLX: (953) 0845741

Hinditron Services Pvt. Ltd.  
Shantiniketan, Office No. 6  
6th Floor, 8 Camac Street  
Calcutta 700 017, India  
Tel: 434032, 447541

Hinditron Services Pvt. Ltd.  
204-5-6 Hemkunt Tower  
98 Nehru Place  
New Delhi, 110019, India  
Tel: 640380, TLX: (953) 314890

Hinditron Services Pvt. Ltd.  
Srinath Complex, 5th Floor  
1-1-58/1 to 1-1-58/11  
Sarajini Devi Road  
Secunderabad 500 003, India  
Tel: 821117, TLX: (953) 0155575

## Indonesia •

P.T. Dwi Tunggal Jaya Sakti  
P.O. Box 4435  
Jalan Panglima Polim Raya #29  
Kebayoran Baru  
Jakarta Selatan, Indonesia  
Tel: (21) 716374, TLX: (796) 47308

## Ireland ■

Euro Instruments & Electronics Ltd.  
Euro House  
Swords Road, Santry  
Dublin 9, Ireland  
Tel: (1) 425666, TLX: (851) 31821



John Fluke Mfg. Co., Inc. / PO Box C9090 / Everett, WA 98206 / (206) 356 5400

Litho in U.S.A. 10/84



**Israel ■**

R.D.T. Electronics Engineering Ltd.  
P.O. Box 43137  
Tel Aviv 61430  
Israel  
Tel: (3) 4832111, TLX: (922) 32143

**Italy ■**

Sistrel S.p.A.  
Via Pelizza da Volpedo 59  
20092 Cinisello Balsamo  
Milan, Italy  
Tel: (2) 6181893, TLX: (843) 334643

Sistrel S.p.A.  
Via Giuseppe Armellini No. 39  
00143 Rome, Italy  
Tel: (6) 591-5551, TLX: (843) 680356

Sistrel S.p.A.  
Via Cintia  
Parco S. Paolo 35  
80126 Naples, Italy  
Tel: (81) 7679700

**Japan ■**  
John Fluke Mfg. Co., Inc.  
Japan Branch  
Sumitomo Higashi Shinbashi Bldg.  
1-1-11 Hamamatsucho  
Minato-ku, Tokyo 105, Japan  
Tel: (3) 434-0181, TLX: (781) 2424331

John Fluke Mfg. Co., Inc.  
Japan Branch  
SF Katsushige Building  
2-45 Kohraibashi  
Higashi-ku, Osaka 541  
Japan  
Tel: (6) 229-0871

**Korea, Republic of ■**

Electro-Science Korea Co.  
201 Hyunjin Building  
951-19 Bangbae-Dong Gangnam-ku  
Seoul, Republic of Korea  
Tel: (2) 583-7703, TLX: (787) 25381

**Kuwait ■**  
Al Bahar International Group  
P.O. Box 26672 Safat  
Kuwait, Arabian Gulf  
Tel: 848601, TLX: (959) 44822

**Lebanon and Jordan ■**  
Mabek (Electronic Division)  
P.O. Box 11-3823  
Beirut, Lebanon  
Tel: 812523, TLX: (923) 22889

**Malaysia ■**  
Mecomb Malaysia SND BHD  
Lot 20, Jalan 225  
P.O. Box 24  
Petaling Jaya, Malaysia  
Tel: (3) 743422, TLX: (784) MA37764

**Malta ■**  
Fabian Enterprises  
20, Msida Road  
Gzira, Malta  
Tel: 513283/40216, TLX: (838) 1837

**Mexico ■**  
Electronica y Tecnologia  
Avanzada S.A. de C.V.  
Pafnucio Padilla 53 5° Piso  
Centro Comercial  
53100 Ciudad Satelite  
Estado de Mexico  
Tel: (5) 3930902, TLX: (383) 172697

Mexicana de Electronica  
Industrial, S.A. (Mexel)  
Blvd. Ptd. Adolfo Lopez Mateos  
Nos. 163 Col. Mixcoac  
03910 Mexico  
Tel: (5) 563-54-11, TLX: (383) 1771038

**Nepal ■**

Associated Enterprises  
GPO Box 790, Pyaphal Tole  
Kathmandu, Nepal  
Tel: 13868

**Netherlands ■**

Fluke (Nederland) B.V.  
Gasthuisring 14  
P.O. Box 115  
5000 AC Tilburg  
The Netherlands  
Tel: (13) 352455, TLX: (844) 52683

**New Zealand ■**

McLean Information Technology, Ltd.  
459 Khyber Pass Road, Newmarket  
P.O. Box 9464, Newmarket  
Auckland 1, New Zealand  
Tel: (9) 501-801; TLX: (791) NZ21570

McLean Information Technology, Ltd.  
P.O. Box 496  
Wellington, New Zealand  
Tel: (4) 851-450 or 844-424

**Norway ■**

Morgenstjerne & Co A/S  
Konghellgate 3  
P.O. Box 6688 - Rodelokka  
Oslo 5, Norway  
Tel: (2) 356110, TLX: (856) 71719

**Oman ■**

OHI Telecommunications  
P.O. Box 889  
Muscat  
Sultanate of Oman  
Tel: 703862, TLX: (926) 3168

**Pakistan ■**

International Operations (PAK), Ltd.  
505 Muhammadi House  
I.I. Chundrigar Road  
P.O. Box 5323, Karachi, Pakistan  
Tel: (21) 221127, TLX: (952) 24494

**Peru ■**

Importaciones y Representaciones  
Electronicas S.A.  
Avda. Franklin D. Roosevelt 105  
Lima 1, Peru  
Tel: (14) 28-8650, TLX: (394) 25663

**Philippines, Republic of ■**

Spark Radio & Electronics, Inc.  
452 Shaw Boulevard  
Mandaluyong, Metro Manila  
Republic of Philippines  
Tel: (2) 775192, TLX: (722 or 732) 27901

**Poland ■**

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

**Portugal ■**

Decada Espectral  
Equipamentos de Electronica  
Av. Bombeiros Voluntarios  
Lote 102B, Miraflores/Alges  
1495 Lisbon, Portugal  
Tel: (1) 2103420, TLX: (832) 15515

**Qatar ■**

Technology Organization  
P.O. Box 5549  
Doha, Qatar  
Tel: 321431, TLX: (957) 4581

**Rumania ■**

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

**Saudi Arabia ■**

Electronic Equipment Marketing Co.  
P.O. Box 3750  
Riyadh, Saudi Arabia  
Tel: (1) 477-1650, TLX: (928) 201120

**Singapore, Republic of ■**

Rank O'Connor's Singapore (PTE) Ltd.  
O'Connor House  
98 Pasir Panjang Road  
Singapore 0511  
Republic of Singapore  
Tel: 637944, TLX: (786) RS21023

**South Africa ■**

Fluke S.A. (Pty) Ltd.  
Wynberg Park  
777 Andries Street  
Wynberg, South Africa  
Tel: (11) 786-3170, TLX: (960) 424328

**Spain ■**

ESSA  
Equipos y Sistemas S.A.  
C/Apolonio Morales, 13-B  
Madrid 16, Spain  
Tel: (1) 458-0150, TLX: (831) 42856

**Sri Lanka ■**

Computerlink Data Systems, Ltd.  
294 Union Place  
Colombo, 2, Sri Lanka  
Tel: (1) 28641/2, TLX: (954) 21321

**Sweden ■**

Teletinstrument AB  
Maltesholmsvagen 138  
P.O. Box 4490  
162 04 Vallingby 4  
Sweden  
Tel: (8) 380370, TLX: (854) 15770

**Switzerland ■**

Traco Electronic AG  
Jenatschstrasse 1  
8002 Zurich  
Switzerland  
Tel: (1) 201-0711, TLX: (845) 815570

**Syria ■**

Mabek (Electronic Division)  
P.O. Box 4238  
Damascus, Syria

**Taiwan ■**

Schmidt Electronics Corp.  
6th Floor Cathay Min-Sheng  
Commercial Building,  
344 Min-Sheng East Road  
Taipei 104, Taiwan  
Tel: (2) 501-3468, TLX: (785) 10548

**Thailand ■**

Measuretronix Ltd.  
2102/63 Ramkamhaeng Road  
Bangkok 10240  
Thailand  
Tel: (2) 378-2516, TLX: (788) 81143

**Tunisia ■**

Selep S.A.R.L.  
6, Rue de Sparte  
Tunis - 1000 RP  
Tunisia  
Tel: (1) 248093, TLX: (934) 13030

**Turkey ■**

Erkman Elektronik Aletler  
Ticaret Anonim Sirketi  
Necatibey Cad 92/3  
Karakoy, Istanbul, Turkey  
Tel: (11) 4415461, TLX: (821) 24399

**United Arab Emirates ■**

Al-Sanani Cen. Trad. Est.  
P.O. Box 7187  
Abu-Dhabi, U.A.E.  
Tel: (2) 821370 or 821371  
TLX: (958) 23966

Haris Al-Afaq, Ltd.  
P.O. Box 545  
Sharjah, U.A.E.  
Tel: (6) 359120, TLX: (958) 68540

**Uruguay ■**

Coasin Uruguaya S.A.  
Libertad 2529  
Casilla de Correo 1400  
Montevideo, Uruguay  
Tel: (2) 789015, TLX: (398) 6445

**USSR ■**

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

**Venezuela ■**

Coasin C.A.  
Calle 9 Con Calle 4, Edif Edinurbi  
Apartado de Correos NR-70.136  
Los Ruices  
Caracas 1070-A, Venezuela  
Tel: (2) 239-0967; TLX: (395) 21027

**Yugoslavia ■**

Amtest Associates, Ltd.  
Clarence House  
31 Clarence Street  
Staines, Middlesex TW18 4SY  
England  
Tel: (784) 63555, TLX: (851) 928855

**■ Supplied and Supported by —**

Fluke (Holland) B.V.  
P.O. Box 5053, 5004 EB Tilburg  
Zevenheuvelenweg 53, 5048 AN Tilburg  
The Netherlands  
Tel: (013) 673973, TLX: 52237

**● Supplied and Supported by —**

Fluke International Corporation  
P.O. Box C9090  
Everett, WA 98206 U.S.A.  
Tel: (206) 356-5500  
TLX: 152662 JOHN FLUKE EVT



# TECHNICAL SERVICE CENTERS

## Brazil, Sao Paulo

Fluke Brasil-Industria E Comercio Ltda.  
Tel: 421-5477  
TLX: 1135589 FLKE BR

## Canada, Calgary, AB

Allan Crawford Associates Ltd.  
Tel: (403) 230-1341

## Canada, Burnaby, BC

Allan Crawford Associates Ltd.  
Tel: (604) 294-1326

## Canada, Mississauga, ON

Allan Crawford Associates Ltd.  
Tel: (416) 678-1500

## Canada, St. Laurent, PQ

Allan Crawford Associates Ltd.  
Tel: (514) 731-8564

## Chile, Santiago

Intronica Chile Ltda.  
Tel: 44940  
TLX: 240301

## China, Beijing

Beijing Radio Research Institute  
Tel: 445612

## Colombia, Bogota

Sistemas E Instrumentacion, Ltda.  
Tel: 232-4532  
TLX: 45787 COASN CO

## Denmark, Ballerup

Tage Olson A/S  
Tel: 658111  
TLX: 35293 TOAS DK

## Ecuador, Quito

Proteco Coasin Cia., Ltda.  
Tel: 529684, 526759  
TLX: 2865 PROTEC ED

## Egypt, Cairo

Electronic Engineering Liaison Office  
Tel: 695705  
TLX: 23082

## England, Watford, Herts

Fluke (Great Britain) LTD  
Tel: 40511  
TLX: 934583

## Finland, Espoo

Instrumentarium Electronics  
Tel: 5281  
TLX: 124426 HAVUL SF

## France, Paris

M.B. Electronique S.A.  
Tel: 9568131  
TLX: 695414

## Greece, Athens

Hellenic Scientific Representations  
Tel: 7211140  
TLX: 219330

## Hong Kong, Wanchai

Schmidt & Co (H.K.) Ltd.  
Tel: 8330-222  
TLX: 74766 SCHMC HX

## India, Bombay

Hinditron Services Pvt. Ltd.  
Tel: 8121316  
TLX: 112326 HSPL IN

## India, Bangalore

Hinditron Services Pvt. Ltd.  
Tel: 33139  
TLX: 0845741 HSPL IN

## India, New Delhi

Hinditron Services Pvt. Ltd.  
Tel: 619118  
TLX: 0314890 SRMP IN

## Indonesia, Jakarta Selatan

P.T. Dwi Tunggal Jaya Sakti  
Tel: 716374  
TLX: 47308 DIJS IA

## Israel, Ramat Hasharon

R.D.T. Electronics Engineering Ltd.  
Tel: 483216  
TLX: 32143 RDT IL

## Italy, Milan

Sistrel S.p.A.  
Tel: 6181893  
TLX: 334643

## Italy, Rome

Sistrel S.p.A.  
Tel: 5915551  
TLX: 680356

## Japan, Tokyo

John Fluke Mfg. Co., Inc.  
Japan Branch  
Tel: 434-0185  
TLX: 2424331 (FLUKJPJ)

## Korea, Seoul

Electro-Science Korea Co.  
Tel: 583-7703  
TLX: 25381 ESKOREA

## Malaysia, Petaling Jaya

Mecomb Malaysia SDN BHD  
Tel: 743422  
TLX: MA37764 MECOMB

## Mexico, Mexico D.F.

Electronica y Tecnologia  
Avanzada S.A. de C.V. (ETA)  
Tel: 393 09 02 or 393 57 62  
TLX: 172697 BIOSME

## Netherlands, Tilburg

Fluke (Nederland) B.V.  
Tel: 352455  
TLX: 52683

## New Zealand, Auckland

McLean Information Technology, Ltd.  
Tel: 501-801, 501-219  
TLX: NZ21570 THERMAL

## Norway, Oslo

Morgenstjerne & Co. A/S  
Tel: 356110  
TLX: 71719

## U.S.A.

### CA, Burbank

John Fluke Mfg. Co., Inc.  
(213) 849-4641

### CA, Santa Clara

John Fluke Mfg. Co., Inc.  
(408) 727-8121

### CO, Denver

John Fluke Mfg. Co., Inc.  
(303) 750-1228

### FL, Orlando

John Fluke Mfg. Co., Inc.  
(305) 896-2296

### IL, Rolling Meadows

John Fluke Mfg. Co., Inc.  
(312) 398-5800

### MA, Burlington

John Fluke Mfg. Co., Inc.  
(617) 273-4678

### MD, Rockville

John Fluke Mfg. Co., Inc.  
(301) 770-1576

### NJ, Paramus

John Fluke Mfg. Co., Inc.  
(201) 262-9550

### TX, Dallas

John Fluke Mfg. Co., Inc.  
(214) 233-9945

### WA, Everett

John Fluke Mfg. Co., Inc.  
(206) 356-5560

## Other Countries

### Argentina, Buenos Aires

Coasin S.A.  
Tel: 552-5248/3485  
TLX: 22284 COASN AR

### Australia, Concord

Elmeasco Instruments Pty Ltd.  
Tel: 736-2888  
TLX: 25887 ELSCO

### Australia, Mount Waverley

Elmeasco Instruments Pty. Ltd.  
Tel: 233-4044  
TLX: 36206 ELMVIC

### Australia, Brisbane

Elmeasco Instruments Pty. Ltd.  
Tel: 369-8688  
TLX: 44062 ELMQLD

### Austria, Vienna

Walter Rekirsch  
Elektronische Gerate GmbH & Co.  
Tel: 235555  
TLX: 134759

### Belgium, Brussels

Fluke (Belgium) SA/NA  
Tel: 2164090  
TLX: 26312

## Pakistan, Karachi

International Operations (PAK), Ltd.  
Tel: 221127, 239052  
TLX: 24494 PIO PK

## Peru, Lima

Importaciones Y Representaciones  
Electronicas S.A.  
Tel: 288650  
TLX: 25663 PE IREING

## Philippines, Metro Manila

Spark Radio & Electronics Corp.  
Tel: 775192, 704096  
TLX: 27901 RLA PH

## Portugal, Lisbon

Decada Espectral Equipamentos  
de Electronica, Lda.  
Tel: 2103420  
TLX: 15515

## Republic of Singapore, Singapore

Rank O'Connor's (PTE) Limited  
Tel: 637944, 239052  
TLX: RS21023 OCONSIN

## Republic of South Africa, Wynberg

Fluke S.A. (Pty) Ltd.  
Tel: 786-3170  
TLX: 424328

## Spain, Madrid

Equipos y Sistemas S.A.  
Tel: 458-0150  
TLX: 42856 EYS E

## Sweden, Vallingby

Teleinstrument AB  
Tel: 380370  
TLX: 15770

## Switzerland, Zurich

Traco Electronic AG  
Tel: 2010711  
TLX: 815570 TRCO CH

## Taiwan, Taipei

Schmidt Electronics Corp.  
Tel: 5013468  
TLX: 11111 SCHMIDT  
10548 EVERGOFT

## Thailand, Bangkok

Measuretronix Ltd.  
Tel: 378-2516  
TLX: 81143 DEJOBKK TH

## Turkey, Istanbul

Erkman Elektronik Aletler  
Tel: 4415461  
TLX: 24399

## Uruguay, Montevideo

Coasin Uruguay S.A.  
Tel: 789015  
TLX: UY6571 OROCUER SA

## Venezuela, Caracas

Coasin C.A.  
Tel: 239-0967, 239-5079  
TLX: 21027 EMVEN VE

## West Germany, Ismaning/Munich

Fluke (Deutschland) GmbH  
Tel: 96050  
TLX: 0522472



John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett, WA 98206  
Fluke (Holland) B.V., P.O. Box 5053, 5004 EB, Tilburg, The Netherlands. Phone (013) 673973  
Litho in U.S.A. 10/84

## **Appendix 7A**

# **Manual Change Information**

### **7A-1. INTRODUCTION**

This appendix contains information necessary to backdate the manual to conform with the earlier PCB configurations. To identify the configuration of the PCBs used in your instrument, refer to the revision letter (marked in ink) on the component side of each PCB assembly. Table 7A-1 defines the assembly revision levels documented in this manual.

As changes and improvements are made to the instrument, they are identified by incrementing the revision letter marked on the affected PCA. These changes are documented on a supplemental change/errata sheet which, when applicable, is inserted at the front of the manual. To identify the configuration the PCAs used in your Generator, refer to the revision letter on the component side of each PCA.

### **7A-2. BACKDATING INSTRUCTIONS**

To backdate this manual to conform with an earlier assembly revision level, perform the changes indicated in Table 7A-1. If this manual documents all PCAs at their original level, no changes are necessary, and no changes will be indicated in Table 7A-1.

# MANUAL CHANGE INFORMATION

**Table 7A-1. Manual Status and Backdating Information**

REF OR OPTION NO.	ASSEMBLY NAME	FLUKE PART NO.	*To adapt manual to earlier rev configurations perform changes in decending order (by no.), ending with change under desired rev letter																
			—	A	B	C	D	E	F	G	H	J	K	L	M	N	P		
A1A1	Display PCA	738609	X																
A2A1	Synthesizer PCA	748814	X																
A2A2	VCO PCA	748780	X																
A2A4	Output PCA	744045	X																
A2A6 A4	Attenuator PCA	752675	X																
A2A6 A5	Relay Driver PCA	752808	X																
A2A7	Controller PCA	755330	X																
A3A1	Power Supply PCA	744052	X																
-130	High Stability Reference PCA	744102	X																
-131	Sub-Harmonic Reference PCA	738583	X																
-488	IEEE-488 PCA	738617	X																
-570	Non-Volatile Memory PCA	744094	X																
-651	Low-Rate FM PCA	716969	X																
-870	A4 Attenuator/ RPP PCA	752667	X																
-870	Relay Driver/A5 RPP Control PCA	752816	X																
			<ul style="list-style-type: none"> <li>* X The PCB revision levels documented in this manual.</li> <li>• These revision letters were never used in the instrument.</li> <li>— No revision letter on the PCB.</li> <li>• Change did not affect manual.</li> </ul>																

## Section 8

# Schematic Diagrams

FIGURE	TITLE	PAGE
8-1.	Mnemonics .....	8-2
8-2.	Schematic Symbols .....	8-3
8-3.	Synthesizer Block Diagram .....	8-5
8-4.	Output Block Diagram .....	8-6
8-5.	A1A1 Display PCA .....	8-7
8-6.	A2A1 Synthesizer PCA .....	8-10
8-7.	A2A2 VCO PCA .....	8-15
8-8.	A2A4 Output PCA .....	8-16
8-9.	A2A6A4 Attenuator PCA .....	8-21
8-10.	A2A6A5 Relay Driver PCA .....	8-22
8-11.	A2A7 Controller PCA .....	8-23
8-12.	A3A1 Power Supply PCA .....	8-27
8-13.	A3A2A1 High-Stability (Ovened) Reference PCA .....	8-28
8-14.	A2A3 Sub-Harmonic Reference PCA .....	8-29
8-15.	A3A3A1 IEEE-488 Interface PCA .....	8-30
8-16.	A2A8 Non-Volatile (Store/Recall) Memory PCA .....	8-31
8-17.	A2A9 Low-Rate FM PCA .....	8-32
8-18.	A2A5A4 Attenuator/RPP PCA .....	8-33
8-19.	A2A5A5 Relay Driver/RPP PCA .....	8-34

# SCHEMATIC DIAGRAMS

MNEMONIC	DESCRIPTION	SIGNAL TYPE *	MNEMONIC	DESCRIPTION	SIGNAL TYPE *
A 0-15	Address	B	LRFM	Low-Rate FM Option Installed	L
A12DB	Attenuator 12-dB Section Control	L	MF400	Modulation Frequency Control	L
A24(1-5)	Attenuator 24-dB Section Controls	L	MID	Mid Band Control	L
A6DB	Attenuator 6-dB Section Control	L	MLEVHI	External Modulation High-Level Status	H
BAB 0-3	Module Section Address	H	MLEVLO	External Modulation Low-Level Status	H
BD 0-7	Module Section Data	B	MODE	Triple-Modulus Prescaler	L
BSEL 0,1	Module Section Select	L	NVCS	NVM RAM Chip Select	L
CKN	N-Divider Clock	L	NVEN	NVM Enable	L
CLR	Display Clear	L	NVIN	NVM Option Installed	L
D 0-7	Data	B	RIN	10-MHz Output Buffer Enable	H
DBIN	Read Enable	L	RMUXO,1	Reference Multiplexer Select	H
DD 0-7	Display Data	B	ROPT	Rear Output Option Installed	L
DIG	Display Digit Select	L	RPP	RPP Option Installed	L
EXREF	External Reference Control	L	RPRST	RPP Reset Control	H
EXTAM	External AM Control	L	RPTRP	RPP Tripped Status	L
EXTFM	External FM Control	L	SEG 1-3,9	Display Segment Select	L
FIL 1,2	Display Filament Supply	AC+DC	SHEN	Sub-Harmonic Reference Control	L
FM 0-9	FM Deviation DAC Control	H	SHET	Synthesizer Heterodyne Control	L
FMEN	FM Enable	H	SHREF	Sub-Harmonic Ref Option Installed	L
FMRNG 0-2	FM Range Control	H	SHTUNE	Sub-Harmonic Ref Tuning Voltage	DC
FMV	FM Audio	AF	TBOUT	Output Test Bit	H
HAOCT	Half-Octave Control	H	TBSYN	Synthesizer Test Bit	H
HET	Het (Low) Band Control	L	TRMOD	Triple-Modulus Prescaler Select	L
HSOPT	High-Stability Option Installed	L	TRSEQ	Remote Sequence Trigger	L
IEA 13-15	IEEE Address Bus	B	TUNE	Main PLL Tuning Voltage	DC
IEADR	IEEE Address Latch Enable	L	UNLOK	PLL Unlocked or Overmodulated Status	L
IECS	IEEE Chip Enable	L	UNLVL	ALC Loop Unleveled Status	L
IED 0-7	IEEE Data Bus	B	WE	Write Enable	L
IEDB	IEEE Read Enable	L	XOEN	10-MHz Crystal Oscillator Control	L
IEIN	IEEE Option Installed	L			
IEINT	IEEE Interrupt	L			
IEW	IEEE Write Enable	L			
INTAM	Internal AM Control	L			
INTFM	Internal FM Control	L			
KBIN	Keyboard Input Select	H			
KN 0-9	PLL Gain Compensation DAC	H			
KNV	Main PLL Gain Compensation Voltage	DC			
KV 0-9	VCO Compensation DAC Control	H			
LEV 0-11	RF Level DAC Control	H			

\* Six SIGNAL types are listed in the following:

DC= DC Control  
AC= Line Frequency  
AF= Audio (modulation) Signal  
L = Logic (binary) signal, active low at the source  
H = Logic (binary) signal, active high at the source  
B = Dynamic bus

Figure 8-1. Mnemonics
















Multitpath Interconnection	Printed Capacitor
	
Dual-Pin Connector Service Aide	Feed-Through Capacitor
	
Dual-Pin Connector Test Point	Diode, General
	
Test Point 4	Diode, Varactor
	
Test Point 5, no post	Diode, Pin
	
Microstrip Transmission Line	Diode, Zener
	
Stripline Transmission Line	Diode, Schottky
	
Printed Inductor	Factor Selected Value
	*

Figure 8-2. Schematic Symbols (cont)

## SCHEMATIC DIAGRAMS
















Value Has Changed +	Plug-In Connection, Male and Female 
Screw Driver Adjustment 	Plug-In Connection, Transmission Line 
Front Panel Designation 	Soldered-In Jumper 
Rear Panel Designation 	Interconnection Information 
Rear Panel Screw Driver Adjustment 	Coax Connector, Female 
Earth Ground 	Coax Connector, Male 
Chassis Ground 	Coax Cable, Soldered In 
Common Connection (PCB Ground) 	
Non-Plug-In Connection 	

Figure 8-2. Schematic Symbols (cont)






Figure 8-3. Synthesizer Block Diagram

# SCHEMATIC DIAGRAMS






Figure 8-4. Output Block Diagram










Figure 8-5. A1A1 Display PCA (cont)

## SCHEMATIC DIAGRAMS



**Figure 8-6. A2A1 Synthesizer PCA**




- NOTES: (UNLESS OTHERWISE SPECIFIED),
- ALL RESISTANCES ARE IN OHMS.  
ALL RESISTORS ARE 1/4W  
ALL RESISTORS ARE 5%.
  - ALL CAPACITANCES ARE IN MICROFARADS.  
ALL CAPACITORS ARE 50V.
  - ALL CHOKES ARE 6-TURN BEADS.
  - ALL DIODES ARE 1N4448.
  - ALL INDUCTOR VALUES ARE IN MICROHENRIES.
  - SYMBOLS DRAWN WITH DASHED LINES INDICATE COMPONENTS PRINTED ON CIRCUIT BOARD.
  - THE SYMBOL "•" INDICATES TRANSMISSION LINES OF OTHER THAN 50 OHM IMPEDANCE WHICH CONSTITUTE CIRCUIT ELEMENTS. 50 OHM TRANSMISSION PATHS ARE NOT INDICATED.
  - PARTS IN SHADED AREAS ARE OPTIONAL AND ARE NOT TO BE INSTALLED.

LINE ARE TO BE CUT WHEN U21, R47, R48 AND R49 ARE INSTALLED.

Figure 8-6. A2A1 Synthesizer PCA (cont)




● DIGITAL ●



8-12





# SCHEMATIC DIAGRAMS






Figure 8-6. A2A1 Synthesizer PCA (cont)



6060A-1618



FROM SYNTHESIZER A2A1


REFERENCE	DESIGNATIONS
LAST USED	NOT USED
R33	PI-200
C38	
Q5	
CR4	
L1	
P204	
W2	W1

- NOTES: (UNLESS OTHERWISE SPECIFIED.)
1. ALL RESISTOR VALUES ARE IN OHMS, 5%.
  2. ALL CAPACITOR VALUES ARE IN MICROFARADS.
  3. ALL RESISTORS ARE 1/8W.

6060A-1018


Figure 8-7. A2A2 VCO PCA


# SCHEMATIC DIAGRAMS



6060A-1624

Figure 8-8. A2A4 Output PCA




- NOTES: (UNLESS OTHERWISE SPECIFIED)
1. ALL RESISTOR VALUES ARE IN OHMS.  
ALL RESISTORS ARE 1/4W, 5%.
  2. ALL CAPACITOR VALUES ARE IN MICROFARADS.
  3. ALL CHOKES ARE 10 TURN BEADS.
  4. THE SYMBOL "•" INDICATES TRANSMISSION LINES OF OTHER THAN 50 OHM IMPEDANCE WHICH CONSTITUTE CIRCUIT ELEMENTS.  
50 OHM TRANSMISSION PATHS ARE NOT INDICATED.
  5. CR126 AND CR202 ARE A MATCHED PAIR.
  6. SYMBOLS SHOWN IN DOTTED LINES REPRESENT COMPONENTS WHICH ARE PRINTED ON THE CIRCUIT BOARD.
  7. SYMBOLS SHOWN IN  ARE OPTIONAL COMPONENTS AND ARE NOT TO BE INSTALLED.

6060A-1024  
(1 of 4)

Figure 8-8. A2A4 Output PCA (cont)


# SCHEMATIC DIAGRAMS




6060A-1024  
(2 of 4)

Figure 8-8. A2A4 Output PCA (cont)






**Figure 8-8. A2A4 Output PCA (cont)**




REFERENCE DESIGNATIONS.	
LAST USED	NOT USED
C416	C1-100, C150, C158-C200, C233, C257, C276, C278-300, C315, C316, C323-400.
CR403	CR1-100, CR122, CR131-200, CR211-300, CR303-400.
L231	L1-100, L117-200, L219.
Q403	Q1-100, Q107-200, Q216-300, Q308-400.
R422	R1-100, R160-200, R247, R257, R260, R273-300, R325-400.
RT301	RT1-300
U405	U1-100, U102-200, U202-300, U312-400.
Z401	Z1-300, Z302-400.
PI13	PI-100, PI03, PI05, PI09-112.
TP11	—
W 1	—

Figure 8-8. A2A4 Output PCA (cont)





6060A-1046



- NOTES: (UNLESS OTHERWISE SPECIFIED).
1. ALL RESISTORS ARE 1/8 W, 0.5%.
  2. ALL CAPACITANCES ARE IN MICROFARADS.
  3. SYMBOLS DRAWN WITH DASHED LINES INDICATE COMPONENTS PRINTED ON CIRCUIT BOARD.
  4. THE SYMBOL "I" INDICATES TRANSMISSION LINES OF OTHER THAN 50 OHM IMPEDANCE WHICH CONSTITUTE CIRCUIT ELEMENTS. 50 OHM TRANSMISSION PATHS ARE NOT INDICATED.

REFERENCE DESIGNATIONS,	
LAST USED	NOT USED
J2	
R21	
K7	
P7	

6060A-1646

Figure 8-9. A2A6A4 Attenuator PCA

SCHEMATIC DIAGRAMS





Figure 8-10. A2A6A5 Relay Driver PCA



OPTION SWITCH SETTINGS (SI)


SWITCH SECTION IN "ON" POSITION	OPTION INSTALLED
1	SUBHARMONIC REFERENCE OPTION -131
3	LOW RATE FM OPTION -651
4	REAR OUTPUT OPTION -830

ALL OTHER SWITCH SECTIONS SHALL BE IN "OFF" POSITION

6060A-1628

Figure 8-11. A2A7 Controller PCA

SCHEMATIC DIAGRAMS



- NOTES: (UNLESS OTHERWISE SPECIFIED.)
1. ALL RESISTOR VALUES ARE IN OHMS.  
ALL CAPACITOR VALUES ARE IN MICROFARADS.
  2. ALL CAPACITORS ARE .22μF.  
ALL RESISTORS ARE 1/4W, 5%.

REFERENCE DESIGNATIONS	
LAST USED	NOT USED
U44 C61 Z5	U6 U12 U13 U19 U28
R15 E15 S1	U29 U32 U39 U43
CR1 L2	C8 C9 C14 C15 C17 C26
	C27 C32 C33 C36-C38
	C43 C46-C49
	E5 E13 E14

6060A-1028  
(1 of 3)

Figure 8-11. A2A7 Controller PCA (cont)




Figure 8-11. A2A7 Controller PCA (cont)

SCHEMATIC DIAGRAMS





Figure 8-11. A2A7 Controller PCA (cont)



6060A-1631

A3A1 REFERENCE DESIGNATIONS	
LAST USED	UNUSED
R13	R5
C22	U3
CR10	
U6	
S1	
TP11	


NOTES: UNLESS OTHERWISE SPECIFIED.

- ALL RESISTANCES IN OHMS.  
ALL RESISTORS 1/4W, 5%.
- ALL CAPACITANCES IN MICROFARADS.

5 RATING OF F1:

1.5A WHEN AC INPUT IS 100/120 VAC  
.75A WHEN AC INPUT IS 200/240 VAC


6 THERMAL PROTECTOR INTERNAL TO T1.




6060A-1031

Figure 8-12. A3A1 Power Supply PCA

SCHEMATIC DIAGRAMS



6060A-1632




NOTES : (UNLESS OTHERWISE SPECIFIED.)

1. ALL RESISTOR VALUES ARE IN OHMS
2. ALL CAPACITOR VALUES ARE IN MICROFARADS

6060A-1032

Figure 8-13. A3A2A1 High-Stability (Ovened) Reference PCA






6060A-1623

NOTES:(UNLESS OTHERWISE SPECIFIED.)

1. ALL RESISTORS ARE 1/8W.  
ALL RESISTORS ARE 5%.  
ALL RESISTOR VALUES ARE IN OHMS.
2. ALL CAPACITOR VALUES ARE IN MICROFARADS.
3. ALL DIODES ARE IN4448.
4. ALL TRANSISTORS ARE MPS6520.

REFERENCE DESIGNATIONS	
LAST USED	NOT USED
C16	C13
CR3	
Q3	R9,10,24
R26	
TP4	
U7	U6
J2	



6060A-1023

Figure 8-14. A2A3 Sub-Harmonic Reference PCA

## SCHEMATIC DIAGRAMS






Figure 8-15. A3A3A1 IEEE-488 Interface PCA



6060A-1629


TO  
CONTROLLER  
A2A7




- NOTES: (UNLESS OTHERWISE SPECIFIED).
1. ALL RESISTORS ARE 1/4W, 5%.  
ALL RESISTOR VALUES ARE IN OHMS.
  2. ALL CAPACITOR VALUES ARE IN MICROFARADS.

6060A-1029


Figure 8-16. A2A8 Non-Volatile (Store/Recall) Memory PCA



6060A-1651



OPTION SWITCH SETTINGS		
SWITCH	NORMAL FM	LOW RATE FM
SI-1	CLOSED	OPEN
SI-2	OPEN	CLOSED
SI-3	CLOSED	OPEN
SI-4	CLOSED	OPEN
SI-5	_____	_____
SI-6	OPEN	CLOSED




NOTES: (UNLESS OTHERWISE SPECIFIED)

1. ALL RESISTOR VALUES ARE IN OHMS
2. ALL RESISTORS ARE 1/4W, 5%, CF.
3. ALL CAPACITOR VALUES ARE IN MICROFARADS.
4. S1 IS SHOWN SET IN LOW RATE FM POSITIONS.

REFERENCE DESIGNATOR	
LAST USED	NOT USED
C7	C5
R13	R10,12
P1	
S1	
U1	

6060A-1051


**Figure 8-17. A2A9 Low-Rate FM PCA**




6060A-1647

ALL COMPONENTS SHOWN  
IN DASHED LINES ARE  
MOUNTED ON FAR SIDE.

FROM RELAY DRIVER / RPP CONTROLLER  
A2A5A5



NOTES: UNLESS OTHERWISE SPECIFIED,


1. ALL RESISTANCES ARE IN OHMS.  
ALL RESISTORS ARE 1/8W, 0.5%.
2. ALL CAPACITANCES ARE IN MICROFARADS.
3. SYMBOLS DRAWN WITH DASHED LINES  
INDICATE COMPONENTS PRINTED ON  
CIRCUIT BOARD.
4. THE SYMBOL  INDICATES TRANSMISSION  
LINES OF OTHER THAN 50 OHM IMPEDANCE  
WHICH CONSTITUTE CIRCUIT ELEMENTS.  
50 OHM TRANSMISSION PATHS ARE NOT  
INDICATED.

REFERENCE DESIGNATIONS	
HIGHEST	NOT USED
P11	
K8	
R22	
C7	
CR9	
J2	


6060A-1047

Figure 8-18. A2A5A4 Attenuator/RPP PCA

SCHEMATIC DIAGRAMS




6060A-1645



6060A-1045  
(1 of 2)

Figure 8-19. A2A5A5 Relay Driver/RPP PCA (cont)



6060A-1045  
(2 of 2)

Figure 8-19. A2A5A5 Relay Driver/RPP PCA (cont)

FLUKE 6060A OPERATOR INFORMATION CARD

REJECTED ENTRY CODES (Press the [STATUS] key to display codes)

- 000 000 000 indicates no rejected entries.
- 001 000 000 = FM Deviation not between 0 and 99.9 kHz (9.99 kHz with option-651)
- 002 000 000 = FM Deviation Step not between 0 and 99.9 kHz (9.99 kHz with option-651)
- 004 000 000 = AM Depth not between 0 and 99%
- 010 000 000 = AM Depth Step not between 0 and 99%
- 020 000 000 = IEEE-488 command syntax error
- 040 000 000 = IEEE-488 input value out of range
- 100 000 000 = Special function requires IEEE option
- 200 000 000 = IEEE edit or step beyond allowed range
- 000 001 000 = Frequency not between 0.1 and 1050 MHz
- 000 004 000 = Frequency Step not between 0 and 1050 MHz
- 000 040 000 = Invalid memory location
- 000 100 000 = Invalid data in memory
- 000 200 000 = Special function not allowed
- 000 000 001 = Output amplitude not between 10 nV and 2V
- 000 000 002 = Insufficient resolution for units conversion
- 000 000 004 = Units conversion to volts not allowed with reference in volts
- 000 000 010 = Units conversion to dB not allowed with reference in volts
- 000 000 020 = Amplitude Step not between 0 and 166 dB or 0 and 1999V
- 000 000 040 = Units conversion of Amplitude Step not allowed
- 000 000 100 = Amplitude step and current amplitude display not in same units

UNCAL CODES (Press the [STATUS] key to display codes)

Flashing codes (denoted by \*) indicate abnormal operation or aberrated output. Non-flashing codes indicate operation outside specified range.

- 000 000 000 indicates no UNCAL conditions.
- 001 000 000 = FM Dev < 100 Hz ( < 10 Hz with option -651)
- 002 000 000 = Excess FM Deviation for output freq < .4 MHz
- \* 004 000 000 = Excess FM Deviation, main or reference PLL unlocked
- 020 000 000 = AM depth > 90%
- \* 000 010 000 = Main or reference PLL unlocked
- 000 000 001 = Level vernier below calibrated range
- 000 000 002 = Peak (AM) amplitude > +13 dBm
- \* 000 000 004 = Amplitude unleveled
- \* 000 000 010 = Fixed-range level vernier at 0
- \* 000 000 020 = Fixed-range level vernier at full scale
- \* 000 000 040 = RPP tripped
- 000 000 100 = Level < -137 dBm
- 000 000 200 = Level correction disabled
- \* 000 000 400 = RF off


SPECIAL FUNCTION OPERATION (Press the [SPCL] key, then press the 2-digit code)

The two-digit code consists of a class numeric followed by a mode numeric. The activated modes of classes 2 through 9 are shown in the FREQUENCY display field while the [SPCL] key is pressed. For example, reading from left to right, 01000201 indicates that relative amplitude, slow key-repeat-rate, and amplitude fixed-range are selected.

Code	Function	Code	Function
00	Clears all special functions	20/21	Disable/enable relative freq.
02	Initiates self test	30/31	Disable/enable relative ampl
03	Display check	40	Not used
04	Key check	50	Not used
07/08	Set/reset SRQ	60	Not used
09	Display S/W rev & instr ID	70/71/72	Medium/fast/slow key-rep-rate
10	Display IEEE-488 address	80	Enable amplitude correction
11	Display self test results	81	Disable all level correction
12/13	Turn on/off Display	82	Disable attenuator correction
14	Initialize Memory	83-86	Program alternate 24 dB atten
15	Latch test	90/91	Disable/enable ampl fixed-rng

SELF TEST RESULTS (Press the [SPCL] [1] [1] keys to display the results)

The self test results are reported in the four display fields as follows:



000 000 000 000 indicates all tests passed.

MEMORY

Instrument settings may be stored in locations 01 through 07 (01 through 50 with option -570) and later recalled. Location 98 contains the Instrument Preset State.